

[Manuals.plus](#) /

› [DreamSky](#) /

› DreamSky Alarm Clock Radios for Bedrooms with Battery Backup, Large Big Numbers with Brightness Dimmer, USB Port, Bedside Digital FM Radio with Sleep Timer, Temperature, Adjustable Volume, Snooze Black

DreamSky DS206

DreamSky DS206 Alarm Clock Radio User Manual

Your comprehensive guide to setting up, operating, and maintaining your DreamSky DS206 Digital FM Alarm Clock Radio.

PRODUCT OVERVIEW

The DreamSky DS206 is a versatile digital alarm clock radio designed for bedrooms, featuring a large, dimmable display, FM radio, USB charging port, and battery backup. It provides essential timekeeping, alarm, and environmental information for a comfortable living space.



Figure 1: Front view of the DreamSky DS206 Alarm Clock Radio, displaying time and indoor temperature.

INITIAL SETUP

Power Connection

Connect the included DC adapter to the "IN" USB port on the back of the alarm clock and plug it into a standard wall outlet. The display will illuminate, indicating power is supplied.

Product Back View

DIMMER Knob: For brightness adjustment
USB (IN): For power on clock
USB (OUT): For charging other smart device.
Wire: Antenna



Figure 2: Rear view of the alarm clock, highlighting the USB IN port for power and the dimmer control.

Battery Backup Installation

For uninterrupted timekeeping during power outages, install 3 AAA batteries (not included) into the battery compartment on the bottom of the unit. These batteries serve as a backup and do not power the main display continuously.

Setting Time (12/24H Format)

1. Press and hold the **TIME SET** button until the hour digits begin to flash.
2. Use the **+** or **-** buttons to adjust the hour.
3. Press **TIME SET** again to confirm the hour and move to minute setting.
4. Use the **+** or **-** buttons to adjust the minutes.
5. Press **TIME SET** once more to save the time.
6. To switch between 12-hour and 24-hour (military) time format, briefly press the **12/24H TIME SET** button.

Your browser does not support the video tag.

Video 1: Demonstrates the unboxing, power connection, and setting of the time on the DreamSky DS206 Alarm Clock Radio.

Temperature Unit Selection

To toggle the indoor temperature display between Celsius (°C) and Fahrenheit (°F), briefly press the **°C/°F ALARM SET** button.

OPERATING INSTRUCTIONS

Display Brightness Control

The large LCD display features a 0% to 100% adjustable dimmer. Use the **DIMMER** knob located on the back of the unit to set your preferred brightness level, from completely off to fully bright.

0% to 100%

Adjustable Brightness Control



Figure 3: Visual representation of the 0% to 100% adjustable display brightness control.

FM Radio Operation

- To turn the FM radio on or off, press the **FM ON/OFF** button.
- Use the **- / <<** or **+ >>** buttons to tune to your desired FM station.
- Adjust the radio volume (L0 to L15) using the **VOLUME +** or **VOLUME -** buttons.
- To activate the sleep timer, press the **SLEEP** button repeatedly to cycle through sleep durations (10-120 minutes). The radio will automatically turn off after the selected time.

No AM Band

Tune to FM radio. Sit back and relax.
Enjoy your favorite music



Figure 4: The alarm clock supports FM radio only, with no AM band functionality.

Alarm Settings and Snooze

1. Press and hold the **ALARM SET** button until the alarm time flashes.
2. Use the **+** or **-** buttons to set the desired alarm hour and minutes.
3. Press **ALARM SET** again to select the alarm source: buzzer or FM radio.
4. If FM radio is selected, adjust the alarm volume using the **VOLUME +** or **VOLUME -** buttons. Buzzer volume has 3 levels.
5. Press **ALARM SET** to confirm.
6. To activate/deactivate the alarm, press the **ALARM ON/OFF** button.
7. When the alarm sounds, press the large **SNOOZE** button for an additional 8 minutes of sleep. The alarm will sound again after 8 minutes.
8. To turn off the alarm for the day, press any button other than **SNOOZE**.

Wake up to buzzer or radio

Buzzer –3 level volume(high/medium/low) optional

Radio– 0–15 level volume optional



Figure 5: The alarm can be set to wake you with either a buzzer or your preferred FM radio station.

Your browser does not support the video tag.

Video 2: Demonstrates setting the alarm and the progressive volume increase of the buzzer alarm.

USB Charging Port

The alarm clock features an extra USB "OUT" port on the back, allowing you to conveniently charge your smartphone or other smart devices without needing an additional wall adapter.

USB port to charge your cellphone ,tablet or other smart device.(USB cable is not included)



Figure 6: The integrated USB port allows for convenient charging of external devices.

MAINTENANCE

Care and Cleaning

To clean the unit, use a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the surface. Keep the device away from water and excessive moisture.

Battery Replacement

If the clock loses time during a power outage, the backup batteries may need to be replaced. Open the battery compartment on the bottom of the unit and replace the 3 AAA batteries, ensuring correct polarity.

TROUBLESHOOTING

Issue	Solution
Q: How do I set my favorite radio station as wake up alarm?	A: You cannot manually set a specific radio station as the wake-up alarm sound. However, if the radio is set as an alarm, it will play your last tuned-in station when the alarm goes off. Ensure your desired station is the last one listened to.
Q: Clock display does not light up?	A: Please check if the clock radio is plugged into a working outlet. Also, slide the dimmer wheel on the back of the unit to ensure it is not set to 0% brightness.
Q: Can I tune in AM station?	A: No, this device supports FM stations ONLY. It does not have an AM tuner.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	DS206
Display Type	Digital LCD with Blue Numbers
Display Size	4 Inches
Brightness Control	0% to 100% Adjustable Dimmer
Time Format	12H or 24H
Temperature Display	Indoor (°C or °F)
Radio Type	FM Only (87.5MHz to 108.0MHz)
Alarm Sound Options	Buzzer (3 levels) or FM Radio (1-15 levels)
Snooze Duration	8 Minutes
Sleep Timer	10-120 Minutes (FM Radio)
USB Port	1 x USB Output for Charging (5V)
Power Source	Corded Electric (DC adapter included)
Battery Backup	3 x AAA Batteries (not included)
Product Dimensions	5" (L) x 3.2" (W) x 2.7" (H)
Item Weight	12.3 ounces (350 Grams)

Product Dimension



Figure 7: Detailed product dimensions for the DreamSky DS206 Alarm Clock Radio.

WARRANTY AND SUPPORT

Warranty Information

This DreamSky Alarm Clock Radio comes with a **1-year replacement warranty** from the date of purchase.

Customer Support

For any warranty claims, technical assistance, or product inquiries, please contact DreamSky customer support:

- Email: info@dreamsky4u.com