

Manuals.plus /

- › SKMEI /
- › SKMEI Digital Watch Model 1295 User Manual

SKMEI 1295

SKMEI Digital Watch Model 1295 User Manual

Your guide to operating and maintaining your SKMEI Digital Watch.

1. INTRODUCTION

Thank you for choosing the SKMEI Digital Watch Model 1295. This watch is designed for an active lifestyle, featuring a digital display, pedometer, calorie tracking, and 50-meter water resistance. This manual provides detailed instructions to help you understand and utilize all functions of your new watch.



Image 1.1: Front view of the SKMEI Digital Watch Model 1295.

2. FEATURES OVERVIEW

The SKMEI Digital Watch Model 1295 offers a range of features to support your daily activities:

- **Digital Display:** Clear and easy-to-read digital time and date.
- **Pedometer:** Tracks steps, distance, and calories burned.
- **Dual Time:** Allows setting of a second time zone.
- **Alarm Function:** Daily alarm for reminders.
- **EL Backlight:** Electroluminescent backlight for visibility in low light conditions.
- **50M Water Resistance:** Suitable for daily use, including swimming and showering.
- **20-Day Data Storage:** Records daily activity data.
- **12/24 Hour Format:** Selectable time display format.



Image 2.1: Overview of watch functions.

3. WATCH COMPONENTS AND BUTTON FUNCTIONS

Familiarize yourself with the watch's buttons and their primary functions:



Image 3.1: Labeled diagram of watch buttons and display elements.

- **EL LIGHT Button:** Activates the backlight.
- **MODE Button:** Cycles through different watch modes (Time, Pedometer, Calorie, Alarm, Time2).
- **SET Button:** Used to enter setting mode and confirm selections.
- **ST/STP Button:** Starts/stops functions like stopwatch or pedometer reset.
- **ALARM:** Indicates alarm status.
- **DATE:** Displays the current date.
- **PEDOMETER:** Indicates pedometer function is active.
- **LOCK:** Indicates button lock status.

4. SETUP AND BASIC OPERATION

4.1 Setting Time and Date

1. In Time Mode, press and hold the **SET** button until the display flashes, indicating setting mode.
2. Use the **MODE** button to cycle through the settings (seconds, minutes, hours, 12/24H format, year, month, day).
3. Use the **ST/STP** button to adjust the flashing value.
4. Press the **SET** button again to confirm the current setting and move to the next, or to exit setting mode.

4.2 Activating Backlight

Press the **EL LIGHT** button to illuminate the display for a few seconds.

5. OPERATING MODES

Press the **MODE** button to cycle through the following display modes:



50M WATERPROOF

THIS WATCH CAN MEET YOUR DAILY USE WATERPROOF!



Image 5.1: Examples of different watch display modes.

5.1 Time Mode

This is the default display, showing the current time, day of the week, and date.

5.2 Pedometer Mode

In Pedometer Mode, the watch displays your total steps, distance traveled, and calories burned. The watch stores up to 20 days of data.



Image 5.2: Pedometer 3D feature display.

To Use the Pedometer:

1. Ensure the pedometer function is enabled (refer to setting instructions if needed).
2. Wear the watch on your wrist. The watch automatically detects and counts steps.
3. To view daily data, cycle to Pedometer Mode using the **MODE** button.
4. To reset daily data, press and hold the **ST/STP** button in Pedometer Mode.

5.3 Calorie Mode

This mode displays the estimated calories burned based on your activity tracked by the pedometer.

5.4 Alarm Mode

Set a daily alarm to alert you at a specific time.

To Set the Alarm:

1. In Alarm Mode, press and hold the **SET** button until the alarm time flashes.
2. Use the **MODE** button to select hours or minutes.
3. Use the **ST/STP** button to adjust the flashing value.
4. Press the **SET** button to confirm and exit.
5. Press the **ST/STP** button to toggle the alarm ON/OFF.

5.5 Time2 Mode (Dual Time)

This mode allows you to set and display a second time zone.

To Set Dual Time:

1. In Time2 Mode, press and hold the **SET** button until the time flashes.
2. Use the **MODE** button to select hours or minutes.
3. Use the **ST/STP** button to adjust the flashing value.
4. Press the **SET** button to confirm and exit.

6. WATER RESISTANCE

The SKMEI Digital Watch Model 1295 features a 50-meter (5ATM) water resistance rating. This means it is suitable for:

- Washing hands
- Rain exposure
- Showering (cold water)
- Swimming in shallow water

Important: Do not press any buttons while the watch is submerged in water. Avoid exposure to hot water, steam, or extreme temperature changes, as this can compromise the water resistance seals.



Image 6.1: Water resistance capabilities.

7. MAINTENANCE

To ensure the longevity and optimal performance of your SKMEI watch, follow these maintenance guidelines:

- **Cleaning:** Wipe the watch case and band regularly with a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- **Avoid Extreme Temperatures:** Do not expose the watch to extreme heat or cold, as this can affect battery life and internal components.
- **Impact Protection:** While durable, avoid dropping the watch or subjecting it to strong impacts.
- **Battery Replacement:** When the display dims or functions become erratic, the battery may need replacement. It is recommended to have this done by a professional to maintain water resistance.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight.

8. TROUBLESHOOTING

If you encounter any issues with your watch, refer to the following common problems and solutions:

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable). If not, try resetting the watch by removing and reinserting the battery (professional assistance recommended).
- **Pedometer readings are inaccurate:** Ensure the watch is worn securely on your wrist. Movement patterns can affect accuracy. Recalibration may be required (refer to advanced settings if available).
- **Water inside the watch:** Immediately stop using the watch and seek professional repair. Do not attempt to dry it yourself.

9. SPECIFICATIONS

Detailed technical specifications for the SKMEI Digital Watch Model 1295:

Feature	Specification
Brand	SKMEI
Model Number	1295
Movement Type	Digital (Quartz)
Case Material	Plastic
Case Diameter	49 Millimeters
Band Material Type	Plastic
Band Color	Green
Dial Color	White
Dial Glass Material	Mineral
Water Resistance Depth	50 Meters
Item Weight	70 Grams
Package Dimensions	9.14 x 9.14 x 6.6 cm
First Available	8 January 2018



Image 9.1: Watch dimensions and basic information.

10. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. For specific warranty terms and conditions, please

refer to the documentation provided at the time of purchase or contact SKMEI customer support. For technical assistance or service inquiries, please visit the official SKMEI website or contact your retailer.