

OGAWA OG0960

OGAWA EZ Tone OE-0960 Home Gym

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the OGAWA EZ Tone OE-0960 Home Gym. This advanced oscillator utilizes whole-body vibration technology to assist in fitness and well-being. This manual provides essential information for the safe and effective use of your device, including setup, operation, maintenance, and troubleshooting.

Please read this manual thoroughly before operating the device and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- **Power Supply:** Connect the device only to a 220V-240Vac, 50/60Hz power outlet. Ensure the power cord is not damaged or pinched.
- **Placement:** Place the unit on a stable, level surface. Ensure adequate space around the device for safe operation.
- **User Weight:** Do not exceed the maximum recommended user weight (consult your physician before use if you have pre-existing medical conditions).
- **Children and Pets:** Keep children and pets away from the device during operation.
- **Maintenance:** Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel for assistance.
- **Emergency Stop:** Familiarize yourself with the power switch location for immediate shutdown if necessary.

3. Package Contents

Carefully unpack all components and check against the list below. If any items are missing or damaged, contact your retailer.

- OGAWA EZ Tone OE-0960 Main Unit
- Power Cord

- Instruction Manual (this document)

4. Setup


1. **Unpacking:** Remove the OGAWA EZ Tone OE-0960 from its packaging.
2. **Placement:** Position the unit on a firm, level floor. Ensure there is sufficient space around the device for safe movement.
3. **Power Connection:** Insert the power cord into the power inlet on the device, then plug the other end into a grounded 220V-240Vac, 50/60Hz electrical outlet.



Figure 1: OGAWA EZ Tone OE-0960 Home Gym main unit. This image shows the compact design and the platform where the user stands for vibration exercises.

5. Operating Instructions

The OGAWA EZ Tone OE-0960 features push-button controls and an LCD display for easy operation.

1. **Power On:** Press the power button (usually marked with  or **I/O**) to turn on the device. The LCD display will illuminate.
2. **Select Mode:** Use the mode selection buttons to choose your desired vibration program or intensity level. Refer to the on-screen display for current settings.

3. **Start Exercise:** Step onto the platform. The device will operate for a preset duration of 10 minutes per session.
4. **Adjust Intensity:** If available, use the intensity adjustment buttons to increase or decrease the vibration intensity during your session.
5. **Power Off:** After your session, press the power button again to turn off the device. Unplug the power cord from the wall outlet when not in use for extended periods.

Note: Each session is automatically timed for 10 minutes. Do not exceed recommended usage times.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your OGAWA EZ Tone OE-0960.

- **Cleaning:** Disconnect the power cord before cleaning. Wipe the surface of the device with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and moisture. Ensure the power cord is neatly coiled and not under strain.
- **Inspection:** Periodically inspect the power cord for any signs of damage. If damage is found, discontinue use and contact customer support.

7. Troubleshooting

If you encounter issues with your OGAWA EZ Tone OE-0960, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Power cord not properly connected; no power from outlet.	Ensure the power cord is securely plugged into both the device and a working electrical outlet. Check the circuit breaker.
Vibration is weak or inconsistent.	Incorrect mode/intensity setting; device overloaded.	Adjust the intensity setting. Ensure the user weight does not exceed the device's capacity.
Unusual noise during operation.	Loose component; device not on a level surface.	Ensure the device is on a stable, level surface. If the noise persists, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact OGAWA customer support.

8. Specifications

Feature	Detail
Brand	OGAWA
Model Number	OG0960
Type	Home Gym (Whole Body Vibration)
Color	Black
Weight	18.9 kg
Power Source	220V-240Vac
Alternating Current	50/60Hz
Power Consumption	85W
Timer	10 minutes (automatic session duration)
Material	Alloy Steel, Aluminum
Type of Controls	Push Button
Display Type	LCD
Operation Mode	Automatic

9. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official OGAWA website. Keep your proof of purchase for warranty claims.

OGAWA Official Website: www.ogawaworld.net