



[Manuals.plus](#) /

› [Arshia](#) /

› Arshia 20-in-1 Air Fryer Instruction Manual (Model AF145-2226)

Arshia AF145-2226

Arshia 20-in-1 Air Fryer Instruction Manual

Model: AF145-2226

1. INTRODUCTION

Thank you for choosing the Arshia 20-in-1 Multi Air Fryer. This appliance utilizes advanced Rapid Air Technology to prepare a variety of dishes with significantly less oil, promoting healthier cooking. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new air fryer. Please read all instructions carefully before first use and retain this manual for future reference.



Image 1: The Arshia 20-in-1 Air Fryer in its closed position, showcasing its green and black design.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure adequate ventilation around the appliance during operation.

3. PRODUCT OVERVIEW

3.1 Main Unit

The Arshia 20-in-1 Air Fryer features a robust design with a transparent lid, allowing you to monitor your cooking progress. The main unit houses the heating element and fan for rapid air circulation.



Image 2: The Arshia Air Fryer with its lid open, revealing the interior cooking chamber and heating element.

3.2 Control Panel

The digital control screen provides intuitive operation with a range of preset functions, temperature, and timer settings.



Image 3: Close-up of the digital control panel, showing various preset cooking options and temperature/timer controls.

- **Digital Display:** Shows time, temperature, and selected preset.
- **Preset Functions:** 20 pre-programmed settings for various food types.
- **Temperature Control:** Adjustable from 50°C to 250°C.
- **Timer Control:** Adjustable from 1 to 60 minutes.
- **Automatic Switch-Off:** The appliance automatically turns off when the timer completes.

3.3 Included Accessories

Your Arshia Air Fryer comes with a comprehensive set of accessories to enhance your cooking experience.



Image 4: All included accessories for the Arshia Air Fryer, laid out for clear identification.

- **Dual Rack:** For cooking multiple items or elevating food.
- **Baking Cage:** Ideal for roasting nuts, coffee beans, or small items.
- **Fork:** For handling hot food or accessories.
- **Fish Basket:** Designed for cooking fish or delicate items.
- **Frying Pan:** For general frying and baking.
- **Steamer Pan:** For steaming vegetables or other foods.
- **Tong:** For safe handling of hot food and accessories.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove the air fryer and all accessories from the packaging. Retain packaging for storage or transport if needed.
2. **Clean:** Before first use, wash all removable accessories (Dual Rack, Baking Cage, Fork, Fish basket, Frying pan, Steamer pan, Tong) with warm soapy water. Wipe the interior and exterior of the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance, and above it, for proper ventilation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 200°C to burn off any manufacturing residues. A slight odor may be present, which is normal and will dissipate. Ensure the area is well-ventilated during this process.

5. OPERATING INSTRUCTIONS

5.1 General Operation

1. **Prepare Food:** Place your food inside the cooking chamber, using appropriate accessories as needed. Do not overfill.
2. **Close Lid:** Ensure the lid is securely closed before starting.

3. **Power On:** Plug in the appliance. The digital display will illuminate.
4. **Select Cooking Method:** You can choose between preset functions or manual settings.

5.2 Using Preset Functions

The Arshia Air Fryer offers 20 preset functions for common dishes.

1. Press the "Menu" button repeatedly or use the dedicated preset buttons (if available on your model) to cycle through the 20 preset options.
2. Once the desired preset is selected, the display will show the default time and temperature for that function.
3. Press the "Start/Pause" button to begin cooking.

Note: Default preset times and temperatures can often be adjusted manually after selection if desired.

5.3 Manual Temperature and Timer Settings

For custom cooking, set the temperature and time manually.

1. Press the "Temp" button, then use the "+" and "-" buttons to adjust the temperature between 50°C and 250°C.
2. Press the "Time" button, then use the "+" and "-" buttons to adjust the cooking time between 1 and 60 minutes.
3. Press the "Start/Pause" button to begin cooking.

5.4 During Cooking

- You can pause cooking at any time by pressing the "Start/Pause" button. Press it again to resume.
- To check food, carefully open the lid. The appliance will pause automatically. Close the lid to resume cooking.
- Some recipes may require shaking or turning food halfway through cooking. Use the provided tong or fork for this.

5.5 End of Cooking

When the timer reaches zero, the appliance will automatically switch off and emit an audible signal.

1. Carefully open the lid.
2. Using the tong or other heat-resistant utensils, remove the cooked food from the air fryer.
3. Unplug the appliance from the wall outlet and allow it to cool completely before cleaning.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your Arshia Air Fryer. Always unplug the appliance and allow it to cool completely before cleaning.

- **Main Unit:** Wipe the exterior with a damp cloth. Do not immerse the main unit in water or any other liquid. The interior cooking chamber, which has a non-stick coating, can be wiped with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could damage the non-stick surface.
- **Accessories:** All removable accessories (Dual Rack, Baking Cage, Fork, Fish basket, Frying pan, Steamer pan, Tong) can be washed in warm soapy water. Rinse thoroughly and dry completely before storing.
- **Dishwasher Safety:** The main unit is **not** dishwasher safe. Removable accessories are generally hand-wash recommended to preserve their finish and lifespan, though some may be top-rack dishwasher safe (refer to specific accessory care if provided).
- **Storage:** Ensure the appliance and all accessories are clean and dry before storing. Store in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your Arshia Air Fryer, consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Power outlet not functioning. Lid not closed properly.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Close the lid completely until it clicks into place.
Food is not cooked evenly.	Overfilled cooking chamber. Food not shaken/turned. Incorrect temperature/time.	Do not overfill the basket; cook in smaller batches if necessary. Shake or turn food halfway through cooking. Adjust temperature and time according to recipe or food type.
White smoke coming from the appliance.	Grease residue from previous use. High-fat food being cooked.	Clean the cooking chamber and accessories thoroughly after each use. For high-fat foods, drain excess fat during cooking. This is usually harmless.
Food is not crispy.	Too much moisture in food. Not enough oil (for certain foods). Overcrowding.	Pat food dry before air frying. Lightly brush or spray food with a small amount of oil. Cook in smaller batches to allow for better air circulation.

8. SPECIFICATIONS

Feature	Detail
Brand	Arshia
Model Name/Number	AF145-2226
Capacity	10 Liters
Color	Green
Wattage	1800W
Control Method	Touch (Digital)
Min Temperature Setting	50°C
Max Temperature Setting	250°C
Air Frying Technology	Rapid Air Circulation
Material (Outer)	Plastic
Inner Material	Heat-resistant Plastic with Non-stick Coating
Item Weight	8.83 Kilograms

Feature	Detail
Included Components	Dual Rack, Baking Cage, Fork, Fish basket, Frying pan, Steamer pan, Tong
Dishwasher Safe	No (Main Unit)



Image 5: Diagram illustrating the approximate dimensions of the Arshia Air Fryer.

9. WARRANTY AND SUPPORT

Your Arshia 20-in-1 Air Fryer (Model AF145-2226) comes with a minimum **1-year manufacturer warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, warranty service, or inquiries about replacement parts, please contact Arshia customer service. Contact information can typically be found on the official Arshia website or on your product packaging.

Note: The warranty may not cover damage caused by improper use, neglect, unauthorized repairs, or normal wear and tear.