

[Manuals.plus](#) /

› [Sandinrayli](#) /

› Sandinrayli 2.0HP 600W Folding Treadmill Electric Motorized Power Running Jogging Fitness Machine User Manual

Sandinrayli 9100248

Sandinrayli 2.0HP 600W Folding Treadmill User Manual

Model: 9100248

INTRODUCTION

This manual provides essential information for the safe and effective operation, assembly, and maintenance of your Sandinrayli 2.0HP 600W Folding Treadmill. Please read this manual thoroughly before initial use and retain it for future reference.

SAFETY INFORMATION

WARNING: To reduce the risk of serious injury, read all important precautions and instructions in this manual before using the treadmill. Sandinrayli assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

- Always ensure the safety key is correctly connected to the operating panel before starting the treadmill.
- Keep children and pets away from the treadmill during operation.
- Place the treadmill on a flat, stable surface with adequate clearance around it.
- Wear appropriate athletic footwear during use.
- If you feel faint, dizzy, or experience pain, stop exercising immediately.
- Do not use the treadmill if it is damaged or malfunctioning.
- Maximum user weight capacity: 220 lbs.

PRODUCT COMPONENTS



Figure 1: Key components of the Sandinrayli Folding Treadmill, including the computer, safety key, heart inductor, tensile knob, upright tubes, motor cover, running belt, side rails, power switch, fix knobs, wheels, and end caps.

Computer: Displays exercise data.

Safety Key: Essential for operation and emergency stop.

Heart Inductor: Measures heart rate.

Tensile Knob: Used for adjusting or securing parts.

Upright Tubes: Support the console and handlebars.

Motor Cover: Protects the motor.

Running Belt: The moving surface for exercise.

Side Rails: Provide a stable surface when not on the running belt.

Power Switch: Turns the treadmill on/off.

Fix Knob: Secures the treadmill in folded or unfolded positions.

Wheels: For easy transportation when folded.

End Caps: Protective covers.

SETUP AND ASSEMBLY

The treadmill is largely pre-assembled. Follow these steps to complete the setup:

1. **Unpacking:** Carefully remove the treadmill from its packaging. Retain packaging materials for future storage or transport.
2. **Unfolding:** Place the treadmill on a flat, stable surface. Gently lift the console assembly until it locks into the upright position. Secure any locking pins or knobs as indicated in the assembly diagram.
3. **Connecting Power:** Ensure the power switch is in the OFF position. Plug the power cord into a grounded 110V outlet.
4. **Safety Key Placement:** Attach the safety key clip to your clothing and insert the safety key into its designated slot on the console. The treadmill will not operate without the safety key properly inserted.



Figure 2: The Sandinrayli Folding Treadmill ready for use, showing the console, handlebars, and running deck.

OPERATING INSTRUCTIONS

Starting the Treadmill

1. Ensure the safety key is in place and the power cord is connected.
2. Turn on the power switch, usually located near the base of the treadmill.
3. Step onto the side rails, not the running belt.
4. Press the "START" button on the console. The belt will begin to move at a low speed.

Adjusting Speed and Programs

- **Speed Adjustment:** Use the "+" and "-" buttons on the console to increase or decrease the running speed. The speed range is 0.6 MPH to 6 MPH (1 km/h to 10 km/h).
- **Preset Programs:** The treadmill features 12 preset programs. Press the "PROGRAM" button to cycle through these programs. Each program offers a different speed and incline profile to vary your workout.
- **LCD Display:** The 3-inch LCD display shows real-time data including Time, Speed, Distance, Calories burned, and Heartbeat (if using the heart rate sensors on the handlebars).

Adjusting Running Angles

The treadmill is equipped with two adjustable supporting feet on its tail to simulate running on different slopes. Adjust these feet manually to change the incline angle before starting your workout.



Figure 3: Illustration of the treadmill's folding capability for storage.

Stopping the Treadmill

- Press the "STOP" button on the console to gradually slow down and stop the running belt.
- In an emergency, pull the safety key from the console. The treadmill will stop immediately.
- After stopping, turn off the power switch and unplug the power cord when not in use.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Cleaning:** Wipe down the treadmill surfaces with a damp cloth after each use. Avoid using abrasive cleaners.
- **Running Belt Adjustment:** If the running surface becomes loose or shifts to one side, it can be adjusted by turning the bolts on both sides of the rear roller evenly. Small adjustments (quarter or half turns) are recommended. Refer to the diagram in the assembly section for bolt locations.
- **Lubrication:** Periodically lubricate the running deck under the belt as per manufacturer recommendations (lubricant not included, typically silicone-based).
- **Storage:** When not in use, the treadmill can be folded to save space. Ensure it is securely locked in the folded position.



Figure 4: The treadmill in its upright folded position for compact storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Treadmill does not start.	Power cord not plugged in; Power switch off; Safety key not inserted.	Check power connection; Turn on power switch; Insert safety key fully.
Running belt slips or is off-center.	Belt tension too loose; Belt alignment incorrect.	Adjust belt tension and alignment using the rear roller bolts (small, even turns).
Unusual noise during operation.	Loose components; Lack of lubrication; Foreign object.	Inspect for loose bolts/screws and tighten; Lubricate running deck; Check for and remove any obstructions.
Display not working.	Loose cable connection; Power issue.	Check all cable connections to the console; Ensure stable power supply.

SPECIFICATIONS

Feature	Detail
Model	9100248
Color	Black
Material	Heavy-Duty Steel Frame, ABS Control Panel, PVC Running Belt
Horsepower	2.0 HP
Rated Power	600W
Voltage	110V
Speed Range	0.6 - 6 MPH (1 - 10 km/h)
Unfolded Dimensions	51.2"L x 45.7"W x 24"H
Folded Dimensions	50"L x 24"W x 27.6"H
Running Surface Dimensions	14.2" x 39.4"
Running Belt Dimension	40"L x 15"W
LCD Display	3" (Time, Speed, Distance, Calories, Heartbeat)
Number of Programs	12 Preset Programs
Weight Capacity	220 lbs
Machine Weight	Approx. 68 lbs



Figure 5: Detailed dimensions of the Sandinrayli Folding Treadmill in both unfolded and folded states.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Sandinrayli customer service. Details are typically provided with your purchase documentation or on the official Sandinrayli website. Please have your model number (9100248) and purchase date available when contacting support.

Note: This treadmill has been adjusted into good condition before shipping. In the event of daily use, regular maintenance and small adjustments may be required.

