

Dekala ACA-002-B

Dekala Sunrise Alarm Clock User Manual

Model: ACA-002-B

1. INTRODUCTION

Thank you for purchasing the Dekala Sunrise Alarm Clock. This device is designed to enhance your wake-up experience with a simulated sunrise, natural sounds, and customizable lighting. Please read this manual carefully to ensure proper use and maintenance of your new alarm clock.



Image: The Dekala Sunrise Alarm Clock with its full-screen light illuminated in a warm yellow hue, displaying the time 08:30 AM on its digital interface.

2. PRODUCT FEATURES

- **Sunrise Simulation:** Gradually brightens from 10% to 100% over 10-60 minutes before your alarm time.
- **Dual Alarms:** Set two separate alarms for different schedules (e.g., weekdays and weekends).
- **7 Natural Alarm Sounds:** Choose from a variety of soothing sounds including Steam, FM Radio, Beep, Wind Bell, Piano, Rain, Bird, and Ocean.
- **Snooze Function:** Provides an additional 9 minutes of sleep, repeatable up to 5 times.
- **FM Radio:** Built-in FM radio with automatic channel scanning.
- **Atmosphere Color Light:** Offers multiple light colors and stepless dimming for mood lighting.
- **USB Charging Port:** Conveniently charge your mobile phone or other devices.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Dekala Wake Up Light
- 1 x Charging Cable (1.2m / 47.24in)
- 1 x Power Adapter
- 1 x User Manual

Product Appearance Details




Image: A visual representation of the Dekala Sunrise Alarm Clock package contents, showing the main unit, charging cable, power adapter, and the user manual.

4. PRODUCT LAYOUT AND PARTS IDENTIFICATION

Familiarize yourself with the various buttons, ports, and features of your alarm clock:

Package List

Wake Up Light*1
Charging Cable*1
Adapter*1
User Manual*1



Image: A comprehensive diagram labeling all control buttons and ports on the Dekala Sunrise Alarm Clock, including Time Setting/Dimmer, Volume, FM Radio, Snooze/Lamp/FM Radio/Selector, Music, Alarm 1, Alarm 2, Sleep Aid, Power Out interface, Power In interface, Speaker, and FM Antenna.

- **Time Setting / Dimmer:** Adjusts time and display brightness.
- **Volume +/-:** Controls sound volume.
- **FM Radio:** Activates and tunes FM radio.
- **Snooze / Lamp / FM Radio / Selector:** Multi-function button for snooze, light control, and selection.
- **Music:** Selects natural sounds.
- **Alarm 1 / Alarm 2:** Buttons to set and activate individual alarms.
- **Sleep Aid:** Activates sleep aid function.
- **Power In Interface:** Connects to the power adapter.

- **Power Out Interface (USB):** For charging external devices.
- **Speaker:** Audio output.
- **FM Antenna:** For improved FM radio reception.

5. SETUP

1. **Power Connection:** Connect the provided power adapter to the "Power In" interface on the back of the alarm clock and plug it into a wall outlet.
2. **Battery Installation (Optional):** The device requires CR5 batteries (not included) for backup power in case of a power outage. Locate the battery compartment and insert the batteries, ensuring correct polarity.
3. **Initial Power On:** The display will light up once connected to power.

6. OPERATING INSTRUCTIONS

6.1. Setting the Time

1. Press the "Time Setting" button (often combined with Dimmer).
2. Use the rotary knob or +/- buttons to adjust the hour. Press the "Time Setting" button again to confirm.
3. Adjust the minute using the rotary knob or +/- buttons. Press "Time Setting" to confirm.
4. Select 12-hour or 24-hour format if prompted.

6.2. Setting Alarms (Alarm 1 & Alarm 2)

The clock supports two independent alarms.

1. Press the "Alarm 1" or "Alarm 2" button to activate and enter alarm setting mode.
2. **Set Alarm Time:** Use the rotary knob or +/- buttons to set the desired hour and minute. Press the alarm button again to confirm each step.
3. **Set Sunrise Simulation Duration:** Choose the duration for the light to gradually brighten (e.g., 10, 20, 30, 45, 60 minutes).
4. **Select Wake-up Sound:** Choose from the 7 natural sounds or FM radio. Use the Music button or rotary knob to cycle through options.
5. **Set Sound Volume:** Adjust the alarm sound volume using the Volume +/- buttons.
6. Press the alarm button one last time to save and exit. The alarm icon will appear on the display.

Wake up to the sounds of nature

7 Wake Up Alarm Sounds are optional



Steam



Fm Radio



Beep



Wind Bell



Piano



Rain



Bird



Ocean



Image: A visual representation of the seven optional wake-up alarm sounds available on the Dekala Sunrise Alarm Clock, including Steam, FM Radio, Beep, Wind Bell, Piano, Rain, Bird, and Ocean.

6.3. Snooze Function

When the alarm sounds, press the large "Snooze" button on top of the clock. The alarm will pause for 9 minutes and then sound again. This can be repeated up to 5 times.

Snooze Function

One click snooze function take a nap every 9minutes up to 5 times




Image: An illustration detailing the snooze function, indicating that a single tap activates snooze, stopping sunlight and sound, and provides 9 minutes of extra sleep, repeatable up to 5 times.

6.4. FM Radio Operation

1. Extend the FM antenna for better reception.
2. Press the "FM Radio" button to turn on the radio.
3. Press and hold the "FM Radio" button to auto-scan and save available stations.
4. Use the +/- buttons to switch between saved stations.
5. Press the "FM Radio" button again to turn off the radio.

6.5. Atmosphere Color Light

The alarm clock can be used as a bedside lamp with various color options.

1. Press the "Lamp" button (often combined with Snooze/Selector) to turn on the light.
2. Press the "Lamp" button repeatedly to cycle through different colors or activate color-changing mode.
3. Use the +/- buttons (often Brightness Up/Down) to adjust the brightness of the light.
4. Press and hold the "Lamp" button to turn off the light.



Image: The Dekala Sunrise Alarm Clock displaying a warm orange light, with an overlay showing a spectrum of multiple light colors and a stepless dimming bar, illustrating its atmosphere color light capabilities.

6.6. USB Charging Port

The USB port on the back of the alarm clock can be used to charge your mobile phone or other small electronic devices.

- Connect your device's USB charging cable to the "Power Out" interface on the alarm clock.
- Ensure the alarm clock is powered on.



Image: A Dekala Sunrise Alarm Clock with a mobile phone connected to its USB port, demonstrating its capability to charge external devices.

7. MAINTENANCE

- **Cleaning:** Wipe the surface of the alarm clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If not in use for an extended period, disconnect the power adapter and store the device in a cool, dry place.

- **Avoid Water:** Keep the device away from water and high humidity.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power connection or power outage.	Ensure power adapter is securely plugged in. Check power outlet. If using backup batteries, ensure they are correctly installed and not depleted.
Alarm does not sound.	Alarm not activated, volume too low, or incorrect time set.	Verify alarm is enabled (icon visible). Increase alarm volume. Double-check alarm time settings.
FM radio reception is poor.	Antenna not extended or interference.	Fully extend the FM antenna. Try repositioning the clock to reduce interference.
Light is not working.	Light function not activated or brightness set to minimum.	Press the Lamp button to turn on the light. Increase brightness using the +/- buttons.

9. SPECIFICATIONS

Feature	Specification
Brand	Dekala
Model Number	ACA-002-B
Dimensions (L x W x H)	12.19 x 3.81 x 16.5 cm (4.8 x 1.5 x 6.5 inches)
Weight	320 Grams (0.7 lbs)
Material	Plastic, Acrylonitrile Butadiene Styrene
Display Type	Digital
Special Features	Alarm, Snooze, Sunrise Simulation, FM Radio, USB Charging Port
Power Source	Corded Electric (Battery backup requires CR5 batteries, not included)

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or contact the retailer where you purchased the Dekala Sunrise Alarm Clock. Please note that information regarding spare parts availability is not provided.



[\[pdf\]](#) User Manual

Dekala Sunrise™ Instruction Model ACA 002 B Manual Dekala Product Instruction Sunrise Alarm Clock Store v 1650699562 cdn shopify s files 1 0574 0386 7313 |||
...

lang: score:40 filesize: 690.99 K page_count: 16 document date: 2022-04-23



[\[pdf\]](#) User Manual Instructions Specifications Guide

Dekala V2 0 20230227 User Manual Amazon Sunrise Alarm Clock for Heavy Sleepers Wake Up Light with Sunset Simulation Dual Alarms Natural Sounds Snooze Sleep Aid FM Radio 7 Colors Night Bedroom Ideal Gift Home Kitchen C1y HA mwpL m media amazon images I |||
Dekala Sunrise Alarm Clock **ACA-002-B** Instructions Please read the instructions carefully before use and keep it in proper storage V2.0 Instruction Videos Support dekalastore.com If you need any assistance please feel free to contact us CONTENT What s Included 02 Get Started 02 Product Over...
lang:en score:27 filesize: 4.55 M page_count: 17 document date: 2023-03-10