

## Orium 11304

# Orium 11304 Vibrating Alarm Clock User Manual

Model: 11304

## INTRODUCTION

---

Thank you for choosing the Orium 11304 Vibrating Alarm Clock. This device is designed to provide a reliable and effective alarm solution, particularly beneficial for individuals with hearing impairments or those who prefer a gentle, non-auditory wake-up. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your alarm clock.

## SAFETY INFORMATION

---

- Read all instructions carefully before using the device.
- Keep the device away from water and moisture.
- Do not expose the device to extreme temperatures or direct sunlight.
- Use only the provided power adapter.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Dispose of batteries responsibly according to local regulations.

## PACKAGE CONTENTS

---

Please check the package for the following items:

- Orium 11304 Digital Alarm Clock Unit
- Vibrating Pad
- Power Adapter
- CR2032 Battery (pre-installed for backup)
- User Manual (this document)



Image: The Orium 11304 alarm clock unit with its large digital display and the accompanying vibrating pad. This image illustrates the main components included in the package.

## PRODUCT FEATURES

- **Dual Alarm System:** Set two independent alarms (A1 and A2).
- **Large Digital Display:** Clear, easy-to-read digits for time and alarm settings.
- **Powerful Vibrating Pad:** For silent, effective wake-up, ideal for heavy sleepers or individuals with hearing difficulties.
- **Loud Audible Alarm:** Up to 102 dB sound power for those who prefer an audible alarm.
- **Adjustable Volume:** Customize the alarm sound level.
- **Adjustable Display Contrast:** Optimize screen visibility.
- **Mains Powered:** For continuous operation.
- **Battery Backup:** Requires 3 x LR03 (AAA) batteries (not included) for time and alarm settings retention during power outages. Includes 1 x CR2032 battery for internal clock memory.
- **Compact Design:** Suitable for bedside tables or desks.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Power:** Plug the power adapter into the DC input port on the back of the alarm clock, then plug the adapter into a standard wall outlet. The display will light up.
3. **Install Backup Batteries (Optional but Recommended):** Open the battery compartment on the bottom of the unit. Insert 3 x LR03 (AAA) batteries (not included) according to the polarity markings. These batteries provide backup power for time and alarm settings in case of a power interruption. The CR2032 battery for internal clock memory is pre-installed.
4. **Connect Vibrating Pad:** Plug the vibrating pad's cable into the designated port on the back of the alarm

clock.

5. **Placement:** Place the alarm clock on a stable surface, such as a bedside table. Position the vibrating pad under your pillow or mattress for optimal effect.



Image: The Orium 11304 alarm clock placed on a bedside table next to a lamp, demonstrating a typical setup. The vibrating pad is visible on the bed.

## OPERATING INSTRUCTIONS

---

### Setting the Time

1. Press and hold the "TIME SET" button (usually located on the top or back).
2. While holding "TIME SET", use the "HOUR" and "MINUTE" buttons to adjust the current time.
3. Release "TIME SET" to confirm.

### Setting Alarms (A1 and A2)

1. Press the "ALARM 1" or "ALARM 2" button once to display the current alarm time.
2. Press and hold the "ALARM 1" or "ALARM 2" button until the alarm time starts flashing.
3. Use the "HOUR" and "MINUTE" buttons to set the desired alarm time.
4. Press the "ALARM 1" or "ALARM 2" button again to confirm and activate the alarm. An indicator (e.g., A1 or A2 icon) will appear on the display.
5. To deactivate an alarm, press the corresponding "ALARM" button until the indicator disappears.

### Adjusting Alarm Mode (Sound, Vibrate, Both)

The alarm clock typically offers different modes for waking up. Consult the icons on the device for specific button functions.

- **Vibration Only:** Ideal for silent wake-up.
- **Sound Only:** For a traditional audible alarm.
- **Vibration + Sound:** Combines both for maximum effectiveness.

*Note:* The vibrating pad should be placed under your pillow or mattress for optimal effect.



Image: A person demonstrating the portability of the vibrating pad by placing it in a pocket, indicating it can be positioned discreetly for personal use.

## Snooze Function

When the alarm sounds or vibrates, press the "SNOOZE" button (usually a large button on top) to temporarily stop the alarm. The alarm will sound/vibrate again after a few minutes (typically 5-9 minutes).

## Stopping the Alarm

To stop the alarm completely for the day, press any other button besides "SNOOZE" (e.g., "ALARM 1" or "ALARM 2" button, or a dedicated "ALARM OFF" button if available).

## Adjusting Display Contrast

Locate the "CONTRAST" button or dial (if available) on the unit. Adjust it to your preferred display brightness level.

## Adjusting Volume

If using the audible alarm, locate the "VOLUME" button or dial. Adjust it to your desired sound level.

## MAINTENANCE

---

- **Cleaning:** Wipe the alarm clock and vibrating pad with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If the backup batteries (3 x LR03 AAA) are depleted, replace them promptly to ensure time and alarm settings are retained during power outages. The CR2032 battery for internal clock memory typically lasts for several years and does not require frequent replacement.
- **Storage:** If storing the device for an extended period, remove all batteries to prevent leakage.

## TROUBLESHOOTING

---

| Problem                                       | Possible Cause  | Solution   |
|---|---|--|
| Display is blank.                             | No power connection or power outage.                    | Ensure the power adapter is securely plugged in. Check if backup batteries are installed and charged during a power outage.  |
| Alarm does not sound/vibrate.                 | Alarm not activated, incorrect mode, or volume too low. | Verify alarm is set and activated (A1/A2 icon visible). Check alarm mode (sound, vibrate, or both). Increase volume if using audible alarm. Ensure vibrating pad is connected. |
| Time/Alarm settings reset after power outage. | Backup batteries are dead or not installed.             | Install or replace the 3 x LR03 (AAA) backup batteries.  |
| Vibrating pad is not working.                 | Pad not connected or faulty.                            | Ensure the vibrating pad cable is securely plugged into the alarm clock. Test with alarm. If still not working, contact support.   |

## SPECIFICATIONS

---

- **Model:** Orium 11304
- **Display Type:** Digital
- **Alarm Type:** Dual (Audible, Vibration, or Both)
- **Audible Alarm Volume:** Up to 102 dB
- **Power Source:** Mains powered (AC adapter included)

- **Backup Batteries:** 3 x LR03 (AAA) (not included) for time/alarm settings, 1 x CR2032 (included) for internal clock memory.
- **Dimensions:** Approximately 6.5 cm (L) x 10 cm (H) (based on product info, assuming 6.5l x 10H centimètres refers to the main unit)
- **Color:** Black
- **Usage:** Indoor

## WARRANTY AND SUPPORT

---

The Orium 11304 Vibrating Alarm Clock comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation provided with your purchase or contact your retailer. For technical support or inquiries, please contact Orium customer service through their official website or the contact information provided by your seller.