

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Divoom](#) /

› [Divoom Mocha Retro Portable Bluetooth Speaker SB-122 User Manual](#)

Divoom SB-122

Divoom Mocha Retro Portable Bluetooth Speaker User Manual

Model: SB-122 | Brand: Divoom

INTRODUCTION

The Divoom Mocha Retro Portable Bluetooth Speaker delivers 40W stereo sound with 360-degree audio. Its robust design includes a convenient carrying strap, making it suitable for various indoor and outdoor environments. The speaker features Bluetooth 5.0 connectivity and a long-lasting battery for extended playtime.

PACKAGE CONTENTS

Please ensure all items are present in the package:

- 1 x Divoom Mocha Retro Portable Bluetooth Speaker
- 1 x USB Charging Cable

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Figure 1: Front view of the Divoom Mocha speaker.



Figure 2: Top view with control buttons.

Control Buttons:

- **Power Switch:** ON/OFF
- **Volume -:** Decrease volume
- **Volume +:** Increase volume
- **Play/Pause:** Play or pause audio playback
- **Next Track:** Skip to the next song
- **Previous Track:** Go to the previous song

SETUP

1. Charging the Speaker

Before initial use, fully charge the Divoom Mocha speaker. Use the provided USB charging cable. Connect the smaller end of the USB cable to the charging port on the speaker and the larger end to a standard USB power adapter (not included) or a computer's USB port. The battery indicator LEDs will illuminate to show charging status and turn off or change color when fully charged.

2. Powering On/Off

Locate the power switch on the speaker. Slide the switch to the 'ON' position to power on the device. You will hear an audible confirmation. To power off, slide the switch to the 'OFF' position.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

To connect your Divoom Mocha speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and within 30 feet (10 meters) of your device.
2. Activate Bluetooth on your mobile device (smartphone, tablet, laptop, etc.).
3. On your device, search for available Bluetooth devices. Select 'Divoom Mocha' from the list.
4. Once paired, the speaker will provide an audible confirmation, and its Bluetooth indicator light will stabilize.

2. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, two Divoom Mocha speakers can be paired together:

1. Power on both Divoom Mocha speakers.
2. The speakers will automatically attempt to pair with each other for TWS mode. An audible prompt will confirm successful TWS connection.
3. Once TWS paired, connect your Bluetooth device to one of the speakers as described in the 'Bluetooth Pairing' section. Audio will now play in stereo across both speakers.

3. Audio Playback

After successful pairing, you can control audio playback:

- **Play/Pause:** Press the Play/Pause button on the speaker or your device.
- **Volume Adjustment:** Use the Volume +/- buttons on the speaker or your device's volume controls.
- **Track Navigation:** Use the Next Track and Previous Track buttons on the speaker to skip songs.

4. Auxiliary Input

To connect a device without Bluetooth, use the 3.5mm AUX input:

1. Connect one end of a 3.5mm audio cable (not included) to the AUX port on the speaker.
2. Connect the other end of the cable to the headphone jack or audio output of your device.
3. The speaker will automatically switch to AUX mode.

MAINTENANCE

Cleaning

Wipe the exterior of the speaker with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal components. Ensure the charging port and AUX port are free from dust and debris.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Avoid storing in areas with high humidity.

Battery Care

To maximize the lifespan of the built-in lithium-ion battery, avoid fully discharging it frequently. Charge the speaker regularly, even if it has not been used for some time. Do not expose the battery to excessive heat.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable. Verify the power switch is in the 'ON' position.
Cannot pair via Bluetooth.	Ensure the speaker is powered on and in pairing mode. Turn off and then on Bluetooth on your device. Move your device closer to the speaker. Disconnect the speaker from any other previously paired Bluetooth devices.
No sound during playback.	Check the volume levels on both the speaker and your connected device. Ensure the speaker is correctly paired via Bluetooth or connected via the AUX cable. Verify the audio source is playing.
Sound is distorted or unclear.	Reduce the volume on both the speaker and your device. Ensure the speaker is within the Bluetooth range (30 feet/10 meters) of your device. Check for potential interference from other electronic devices.
TWS pairing fails.	Ensure both speakers are powered on and not connected to any other Bluetooth devices. Power cycle both speakers and try again. Place them close to each other during pairing.

TECHNICAL SPECIFICATIONS



Figure 3: Divoom Mocha speaker dimensions.

Feature	Detail
Model	SB-122

Feature	Detail
Material	Metal
Speaker Type	Outdoor, Surround Sound
Special Features	Bluetooth, Portable
Compatible Devices	Smartphone, Tablet
Color	Mocha Red
Product Dimensions	5D x 10W x 5H Centimeters (Approx. 26.11 x 12 x 15.09 cm)
Item Weight	300 Grams
Waterproof	Yes
Control Method	Touch
Wireless Communication Technology	Bluetooth
Speaker Size	1 Inches
Power Source	Battery Powered
Number of Batteries	1 Lithium Ion (included)
Audio Driver Type	Dynamic Driver
Bluetooth Range	30 Feet
Audio Wattage	40 Watts
Battery Average Life	20 Hours
Charging Time	3 Hours
Battery Capacity	10000 Milliamp Hours

WARRANTY AND SUPPORT

The Divoom Mocha Retro Portable Bluetooth Speaker is covered by a manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your product packaging or visit the official Divoom website. For technical support, troubleshooting assistance, or service inquiries, please contact Divoom customer support through the channels provided in your product documentation.