

[Manuals.plus](#) /

> [ciciglow](#) /

> Ciciglow 2.4G Wireless 29-Key Numeric Keypad with LCD Display User Manual

ciciglow CiCiglowombp7v36ix

Ciciglow 2.4G Wireless 29-Key Numeric Keypad with LCD Display User Manual

Model: CiCiglowombp7v36ix

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Ciciglow 2.4G Wireless 29-Key Numeric Keypad with LCD Display. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

The keypad features 2.4G wireless connectivity, a 29-key layout, and an integrated LCD display. It is designed for compatibility with PC, Android, and iMac systems.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Ciciglow 2.4G Wireless 29-Key Numeric Keypad
- 1 x USB Receiver
- 1 x Micro USB Data Cable
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your numeric keypad.



Figure 3.1: Top view of the Ciciglow Numeric Keypad.



Figure 3.2: Side view showing the Micro USB charging port and power switch.

4. SETUP INSTRUCTIONS

4.1 Connecting the Keypad

1. **Charge the Keypad:** Before initial use, ensure the keypad is fully charged. Connect the provided Micro USB cable to the keypad's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). Refer to Section 6 for charging details.
2. **Insert USB Receiver:** Locate the USB receiver included in the package. Plug the USB receiver into an

available USB port on your computer or compatible device.

3. **Power On the Keypad:** Slide the power switch on the side of the keypad to the "ON" position.
4. **Automatic Connection:** The keypad will automatically connect to the USB receiver. No additional drivers are required for most operating systems (Plug and Play).



Figure 4.1: Keypad connected to a laptop, demonstrating compatibility.

The 2.4G wireless connection offers an open distance of up to 10 meters (approximately 33 feet).

5. OPERATING INSTRUCTIONS

5.1 Basic Keypad Functions

The keypad features 29 keys, including numeric keys, arithmetic operators, and navigation keys. The integrated LCD display shows numerical input.

- **Numeric Keys (0-9, 000):** For entering numerical data.
- **Arithmetic Operators (+, -, *, /):** For performing calculations.
- **Enter Key:** Confirms input or performs an action.
- **Back Space Key:** Deletes the last character entered.
- **Num Lock:** Toggles the numeric lock function.
- **A/C (All Clear):** Clears the current display on the LCD.
- **Navigation Keys (Home, End, PgUp, PgDn, Arrows):** For navigating within documents or spreadsheets.
- **Ins (Insert):** Toggles insert mode.
- **Del (Delete):** Deletes characters.

5.2 LCD Display Usage

The LCD display shows the numbers you type, functioning as a basic calculator display. Use the A/C button to clear the display.

5.3 Compatibility

The keypad is compatible with various operating systems, including Windows, Android, and iMac systems. Ensure your device has an available USB port for the receiver.

6. CHARGING THE KEYPAD

The keypad is equipped with a rechargeable battery. To charge:

1. Connect the Micro USB data cable to the charging port on the keypad.
2. Connect the other end of the Micro USB cable to a standard USB power source.
3. Ensure the keypad power switch is in the "ON" position for fast charging.

A full charge typically takes 3-4 hours. The keypad offers a standby time of approximately 60 days on a full charge.



Figure 6.1: Charging the keypad with the Micro USB cable.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keypad. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, store the keypad in a cool, dry place. The USB receiver can be stored in the keypad's integrated storage compartment to prevent loss.

- **Water Resistance:** The keypad is designed with some water resistance; however, avoid submerging it in liquids or exposing it to excessive moisture.
- **Non-slip Design:** The back of the keypad features non-slip mats to ensure stability on your desktop.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keypad not responding	<ul style="list-style-type: none"> ◦ Keypad is off. ◦ Low battery. ◦ USB receiver not properly connected. ◦ Out of range. 	<ul style="list-style-type: none"> ◦ Ensure the power switch is ON. ◦ Charge the keypad. ◦ Reconnect the USB receiver to a different USB port. ◦ Move the keypad closer to the USB receiver (within 10m).
Keys not typing correctly	<ul style="list-style-type: none"> ◦ Num Lock is off. ◦ Software conflict. 	<ul style="list-style-type: none"> ◦ Press the "Num Lock" key. ◦ Restart your computer/device.
LCD display is blank	<ul style="list-style-type: none"> ◦ Low battery. ◦ Keypad is off. 	<ul style="list-style-type: none"> ◦ Charge the keypad. ◦ Ensure the power switch is ON.

9. SPECIFICATIONS

Model Number	CiCiglowombp7v36ix
Brand	Ciciglow
Number of Keys	29
Connectivity	2.4G Wireless (USB Receiver)
Wireless Range	Up to 10 meters
Interface	Micro USB (for charging)
Compatible Devices	PC, Android, iMac Systems
Material	Acrylonitrile Butadiene Styrene (ABS), Plastic
Product Dimensions (L x W x H)	6.1" x 3.5" x 0.8" (15.5 x 8.8 x 2 cm)
Item Weight	0.15 Kilograms
Charging Time	3-4 hours
Standby Time	60 days
Special Features	LCD Display, Non-slip, Fast Charge, Waterproof (splash-resistant)

10. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

This video demonstrates the Ciciglow Numeric Keypad, showcasing its design, features, and compatibility with various devices. It highlights the 2.4G wireless connection and the integrated LCD display.

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Ciciglow customer service directly. Keep your purchase receipt for warranty claims.

For further assistance, you may visit the [Ciciglow Store on Amazon](#).