

[manuals.plus](#) /› [Roxicosly](#) /› [Roxicosly Loud Alarm Clock with Bed Shaker User Manual](#)

Roxicosly CR1001EM

Roxicosly Loud Alarm Clock with Bed Shaker User Manual

Model: CR1001EM | Brand: Roxicosly

INTRODUCTION

This manual provides detailed instructions for the Roxicosly Loud Alarm Clock with Bed Shaker. Designed for heavy sleepers, individuals with hard of hearing, and those who prefer a strong wake-up method, this alarm clock features a 7.5-inch large LED display, dual alarms, a USB charging port, and multiple wake-up modes including a powerful bed shaker. Please read this manual thoroughly to ensure proper use and optimal performance of your device.



Image: The Roxicosly Loud Alarm Clock with its bed shaker and a smartphone connected for charging.

KEY FEATURES

1. Multiple Wake-up Modes

The alarm clock offers three distinct wake-up modes to suit individual preferences: a loud buzzer, a powerful bed shaker, or a combination of both. This ensures effective waking for heavy sleepers or those with hearing impairments.

3 Wake-up Modes

Switch the alarm mode according to personal needs



Image: Illustration of the three wake-up modes available on the alarm clock.

The bed shaker features a 71-inch long cord, allowing flexible placement under a pillow or mattress for discreet and effective vibration without disturbing others.

2. Large LED Display with Adjustable Brightness

Equipped with a 7.5-inch large LED display, the time is clearly visible from a distance. The screen brightness can be adjusted across 5 levels, from dim to bright, to prevent disturbance during sleep or ensure visibility during the day.

Large Display with 5-level Dimmer

Easily view the time & Set brightness to your desired level



Image: The large LED display with its dimensions and visual representation of 5 brightness levels.

3. Dual Alarms and Snooze Function

Set two independent alarms, ideal for couples or different daily schedules. The large snooze button on top provides an extra 9 minutes of sleep before the alarm reactivates.

Dual Alarms with 5-level Volume

Set 2 separate alarms for different schedules




Image: The alarm clock displaying dual alarm settings and volume adjustment options.

Big Snooze & USB Charging Port

Lightly touch the snooze button to enjoy extra 9-min sleep



Image: A user activating the large snooze button for additional sleep.

4. USB Charging Port and Battery Backup

A built-in 5V/1A USB charging port allows convenient and safe charging of your smartphone or other devices overnight. The clock operates primarily via AC power, but two AAA batteries (not included) provide backup for time and alarm settings during power outages, ensuring your alarm still triggers.

Battery Backup

Plug in Alarm Clock, batteries only for memory function

2 AAA batteries (not included) to maintain the time and trigger the alarm in case of power failure.



12/24H & DST



Image: The back of the alarm clock, highlighting the battery backup compartment and power connection.

5. 12/24H Format and DST Function

Easily switch between 12-hour and 24-hour time formats. The Daylight Saving Time (DST) function is also available for quick adjustments.

6. Easy Operation and Versatile Placement

The alarm clock features intuitive buttons for straightforward setup and operation, making it suitable for users of all ages. Its sleek design allows it to blend seamlessly into various room styles, including bedrooms, living rooms, and offices.



Image: The alarm clock positioned on a bedside table, demonstrating its compact size and aesthetic appeal.

SETUP GUIDE

- 1. Power Connection:** Plug the alarm clock into an AC power outlet using the provided adapter. The display will light up.
- 2. Battery Backup Installation:** Open the battery compartment on the back of the clock. Insert two AAA 1.5V batteries (not included), ensuring correct polarity. These batteries will preserve time and alarm settings during a power interruption.
- 3. Connect Bed Shaker:** Plug the bed shaker's cable into the designated port on the back of the alarm clock. Place the shaker under your pillow or mattress.

4. **Set Time:** Press the "SET TIME" button. Use the "HOUR" and "MIN" buttons to adjust the current time. Press "SET TIME" again to confirm.
5. **Set 12/24H Format:** Press the "12/24H" button to toggle between 12-hour and 24-hour display formats.
6. **Daylight Saving Time (DST):** Press and hold the "DST" button to activate or deactivate the DST function.

OPERATING INSTRUCTIONS

Setting Alarms (Dual Alarms)

1. **Set Alarm 1:** Press the "ALARM1" button. Use the "HOUR" and "MIN" buttons to set the desired alarm time. Press "ALARM1" again to confirm.
2. **Set Alarm 2:** Press the "ALARM2" button. Use the "HOUR" and "MIN" buttons to set the desired alarm time. Press "ALARM2" again to confirm.
3. **Activate/Deactivate Alarm:** After setting, the alarm will be active. To deactivate, press the corresponding "ALARM1" or "ALARM2" button until the alarm icon disappears from the display.

Selecting Wake-up Mode

Press the "BUZZ/VIB" button repeatedly to cycle through the three wake-up modes:

- **Buzzer Only:** Only the loud buzzer will sound.
- **Bed Shaker Only:** Only the bed shaker will vibrate.
- **Buzzer & Shaker:** Both the buzzer and bed shaker will activate simultaneously.

Note: Ensure the bed shaker is plugged in for vibration modes to function.

Your browser does not support the video tag.

Video: Demonstrates the different wake-up modes and features of the Roxicosly Loud Alarm Clock.

Adjusting Volume

The buzzer volume is 4-level adjustable. Press the "VOL" button to increase or decrease the volume to your preferred level. The sound will gradually increase to avoid sudden startling.

Snooze Function

When the alarm sounds, lightly press the large "SNOOZE/OK" button on top to activate the snooze function for an additional 9 minutes of sleep. The alarm will sound again after 9 minutes.

Adjusting Display Brightness

Press the "DIMMER" button repeatedly to cycle through the 5 levels of screen brightness, from the lowest (dimmest) to the highest (brightest).

USB Charging

Connect your smartphone or other USB-powered device to the "CHARGE OUT" USB port on the back of the clock to charge it safely.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the alarm clock. Avoid using abrasive cleaners or solvents, as they may damage the finish.

- Storage:** If storing the clock for an extended period, remove the AAA backup batteries to prevent leakage. Store in a cool, dry place.
- Handling:** Handle the bed shaker and its cable with care to prevent damage. Avoid sharp bends or excessive pulling on the cable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank.	No AC power or power outage.	Ensure the power adapter is securely plugged into both the clock and a working outlet. If there's a power outage, the display will go blank, but the alarm will still trigger if backup batteries are installed.
Alarm does not sound/vibrate.	Alarm not activated, incorrect mode selected, or bed shaker not connected.	Ensure the alarm icon is visible on the display. Check the wake-up mode setting ("BUZZ/VIB" button) to ensure the desired mode (buzzer, shaker, or both) is selected. Verify the bed shaker is securely plugged into the clock.
Time/Alarm settings are lost after power outage.	Backup batteries are not installed or are depleted.	Install two fresh AAA batteries in the battery compartment. Replace old batteries if necessary.
USB charging not working.	Device not properly connected or clock not powered.	Ensure the USB cable is securely connected to both the clock's USB port and your device. Confirm the alarm clock is powered via AC adapter.

SPECIFICATIONS

Feature	Detail
Brand	Roxicosly
Model Number	CR1001EM
Display Type	Digital LED
Display Size	7.5 inches (6.82"W x 3.39"H)
Brightness Levels	5-level adjustable dimmer
Wake-up Modes	Loud buzzer, Strong vibrator, Both
Vibrator Cable Length	71 inches
Alarm Volume	4-level adjustable
Snooze Duration	9 minutes
Time Format	12H/24H selectable
Power Source	Corded Electric (AC adapter included)
Battery Backup	2 x AAA batteries (not included) for time/alarm memory

Feature	Detail
USB Charging Port	5V/1A output
Material	Plastic (Acrylonitrile Butadiene Styrene)
Item Weight	7.04 ounces

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user manual provided with your product or visit the Roxicosly official website. You can also find the user manual PDF [here](#).

Manufacturer: Wuhan Wismco E-commerce Co., Ltd.

© 2024 Roxicosly. All rights reserved.