

[Manuals.plus](#) /

› [XTREME](#) /

› Energizer Connect Wireless Smart WiFi Security Camera User Manual

XTREME B08BV25X6K

Energizer Connect Wireless Smart WiFi Security Camera User Manual

Model: B08BV25X6K

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Energizer Connect Wireless Rechargeable Battery-Powered Smart WiFi Security Camera. This camera is designed for both indoor and outdoor use, offering 1080p video, motion detection, two-way audio, and night vision capabilities to enhance your home security.



Image: The Energizer Connect Smart WiFi Battery Camera shown with its retail packaging, highlighting its key features.

SETUP

1. Initial Charging

Before first use, fully charge the camera's built-in 5,000 mAh rechargeable battery. Connect the included 13-foot weatherproof Micro-USB cable to the camera's charging port and a compatible USB power adapter (not included). The charging indicator light will provide status.

2. Download the Energizer Connect App

Download the **Energizer Connect App** from the Apple App Store or Google Play Store. This app is essential for controlling and managing your camera.

3. Pairing the Camera


Open the Energizer Connect App and follow the on-screen instructions to add a new device. Ensure your mobile device is connected to a 2.4GHz Wi-Fi network, as the camera operates on this frequency. The app will guide you through the pairing process, which typically involves scanning a QR code displayed on your phone with the camera.

EASY SETUP



Back View

1 CHARGE



2 PAIR



3 MOUNT

Free Download:
Energizer Connect App



Image: Visual representation of the three easy setup steps: charging the camera, pairing it with the app on a smartphone, and mounting it.

4. Mounting the Camera

The camera comes with a magnetic bracket for easy placement. Choose a suitable location indoors or outdoors. The camera is weatherproof (IP65 rated), allowing for outdoor installation. Secure the magnetic mount to a flat surface, then attach the camera to the mount. The magnetic connection allows for flexible angle adjustment.

13ft Weatherproof
micro USB Cable



Magnetic Mount

Back View

Image: A detailed view of the camera's magnetic mount and its back panel, showing the Micro USB port and the 13ft weatherproof cable.

OPERATING THE CAMERA

Live Video Viewing

Access live 1080p HD video feed from your camera anytime, anywhere, through the Energizer Connect App on your smartphone. This allows for real-time monitoring of your property.



Image: The camera positioned to illustrate its capability for both indoor and outdoor surveillance, providing 1080p Full HD video.

Motion Detection Alerts

The camera features PIR motion detection. When motion is detected, you will receive instant alerts on your connected devices via the Energizer Connect App. You can adjust sensitivity settings within the app.

Two-Way Audio

Utilize the built-in microphone and speaker for two-way communication. This allows you to speak to visitors or deter unwanted guests directly through the app.



Image: A visual demonstrating the two-way audio feature, showing a user communicating with a delivery person at their door via the camera and smartphone app.

Night Vision

The camera is equipped with night vision capabilities, providing clear video recordings even in low-light conditions or complete darkness.



Image: The camera's night vision capability is illustrated, showing a clear, black-and-white view of an outdoor patio area in the dark.

Storage Options

Recordings can be stored in two ways:

- **Cloud Storage:** Optional subscription plans are available for cloud storage of your video and audio recordings.
- **MicroSD Card:** The camera supports local storage via a compatible microSD card (not included). Insert the card into the designated slot on the camera.

RECORD VIDEO+AUDIO

CLOUD STORAGE
Optional subscription plans available when plugged in

microSD card slot*

*microSD card not included (up to 128GB)

Image: This image displays the camera's storage options, including cloud storage subscription details and the physical microSD card slot for local recording.

Voice Control Integration

The Energizer Connect Camera is compatible with Amazon Alexa and Google Assistant, allowing for convenient voice control functionality.

MAINTENANCE

Battery Recharging

The camera's 5,000 mAh battery provides extended use. When the battery level is low, recharge it using the provided 13-foot weatherproof Micro-USB cable. Battery life varies based on usage and environmental factors.

CABLE FREE

Built-in **5000 mAh**
Rechargeable Battery



Image: The camera's cable-free design is highlighted, emphasizing its built-in 5000 mAh rechargeable battery and Wi-Fi connectivity.

Cleaning

To maintain optimal performance, periodically clean the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the camera's surface or lens.

Weather Resistance

The camera has an IP65 rating, meaning it is protected against dust and low-pressure water jets. While weatherproof, avoid submerging the camera in water or exposing it to extreme weather conditions beyond its rating.



Image: The camera is shown with water droplets, illustrating its IP65 weather-resistant design suitable for outdoor environments.

TROUBLESHOOTING

Connectivity Issues

- **No Connection/Frequent Disconnections:** Ensure your Wi-Fi network is 2.4GHz. Check Wi-Fi signal strength at the camera's location. Move the camera closer to the router or consider a Wi-Fi extender. Restart your router and the camera.
- **App Not Connecting:** Ensure the Energizer Connect App is updated to the latest version. Check your phone's internet connection.

Battery Not Holding Charge

- Ensure the charging cable is securely connected to both the camera and the power source.
- Verify the power adapter is functioning correctly.
- Extreme temperatures can affect battery performance. Operate the camera within recommended temperature ranges.

Motion Detection Not Working

- Check motion detection settings in the Energizer Connect App. Ensure it is enabled and sensitivity is adjusted appropriately.
- Ensure there are no obstructions blocking the camera's view or the PIR sensor.

Poor Video Quality

- Clean the camera lens.
- Ensure adequate lighting for optimal video quality, especially during the day.
- Check your Wi-Fi signal strength; a weak signal can affect streaming quality.

SPECIFICATIONS

Feature	Detail
Brand	XTREME
Model Number	B08BV25X6K
Video Capture Resolution	1080p
Power Source	Battery Powered (5000 mAh Lithium Ion)
Connectivity Protocol	Wi-Fi (2.4GHz)
Indoor/Outdoor Usage	Indoor, Outdoor (IP65 Weatherproof)
Special Features	Motion Sensor, Night Vision, 2-Way Audio
Controller Type	Amazon Alexa, Google Assistant
Mounting Type	Wall Mount (Magnetic Bracket)
Item Weight	11.4 ounces (0.71 Pounds)
Manufacturer	Energizer Connect
UPC	805106870843

WARRANTY AND SUPPORT

Warranty Information

For detailed warranty information regarding your Energizer Connect Smart WiFi Security Camera, please refer to the documentation included with your product or visit the official Energizer Connect website. Warranty terms and conditions may vary.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact Energizer Connect customer support. Contact information can typically be found on the product packaging, the Energizer Connect website, or within the Energizer Connect App.

© 2024 XTREME. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question