

## Delimano B08H26G671

# Delimano Air Fryer Instruction Manual

**Model:** B08H26G671

**Brand:** Delimano

## 1. INTRODUCTION

---

The Delimano Air Fryer is an innovative kitchen appliance designed to prepare delicious, crispy meals with significantly less oil than traditional deep frying methods. Utilizing rapid hot air circulation, this air fryer allows you to enjoy your favorite fried foods in a healthier way. Its user-friendly design, adjustable temperature, and built-in timer make cooking convenient and efficient.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow adequate air circulation.
- Do not block the air inlet or outlet openings.
- Do not touch hot surfaces. Use handles or knobs.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance features an auto shut-off function to prevent overheating and burning of food.

## 3. PRODUCT COMPONENTS

---

Familiarize yourself with the main parts of your Delimano Air Fryer:

- Main Unit
- Temperature Control Dial (80-200°C)
- Timer Dial (up to 30 minutes)

- Removable Frying Basket
- Basket Handle
- Air Inlet and Outlet Vents



Figure 3.1: Front view of the Delimano Air Fryer, highlighting the control dials.



Figure 3.2: Detailed view of the temperature and timer dials, along with the basket handle.

## 4. SETUP

Before first use, follow these steps:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the frying basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a damp cloth.
4. Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and above the appliance, for proper ventilation.

## 5. OPERATING INSTRUCTIONS

Follow these steps to operate your Delimano Air Fryer:

1. Plug the power cord into a grounded wall outlet.
2. Carefully pull the frying basket out of the air fryer.
3. Place the ingredients into the frying basket. Do not exceed the MAX fill line or the recommended capacity (2.5L).
4. Slide the frying basket back into the air fryer. Ensure it clicks securely into place.
5. Turn the temperature control dial to the desired temperature (80-200°C).
6. Turn the timer dial to the desired cooking time (up to 30 minutes). The appliance will start heating immediately.
7. During cooking, some ingredients may require shaking or turning halfway through the cooking time. Pull out the basket by the handle, shake or turn the food, and then slide the basket back in. The air

fryer will resume cooking automatically.

8. When the timer reaches zero, a bell will ring, indicating that the cooking process is complete. The appliance will automatically shut off.
9. Carefully pull the basket out and check if the food is cooked to your preference.
10. Empty the food from the basket into a serving dish.



Figure 5.1: The air fryer in operation, demonstrating the removal of the basket with cooked french fries.

## 6. COOKING GUIDE

The Delimano Air Fryer is suitable for a variety of foods. The 2.5L capacity can accommodate up to 700g of french fries or 500g of steaks or chicken wings. Below are general guidelines; actual times and temperatures may vary based on food quantity and desired crispness.



Figure 6.1: Examples of various foods that can be prepared in the air fryer, including chicken, fries, noodles, and muffins.

### Common Food Items & Settings:

- **French Fries:** For crispy results, preheat to 180-200°C (350-390°F) and cook for 15-25 minutes, shaking the basket halfway through.
- **Chicken Wings/Drumsticks:** Cook at 180-200°C (350-390°F) for 20-30 minutes, turning halfway.
- **Steaks:** Cook at 180°C (350°F) for 10-15 minutes, flipping halfway, depending on desired doneness.
- **Muffins/Baked Goods:** Follow recipe instructions, typically 160-180°C (320-350°F) for 10-20 minutes.



Figure 6.2: Perfectly air-fried french fries.



Figure 6.3: Crispy air-fried chicken.



Figure 6.4: Air-fried muffins.



Figure 6.5: Air-fried noodles.

## 7. CLEANING AND MAINTENANCE

---

Clean the appliance after every use.

- Unplug the appliance and allow it to cool down completely before cleaning.
- The main unit is not dishwasher safe. Wipe the exterior with a damp cloth.
- The removable frying basket and pan have a non-stick coating. Clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak the basket and pan in hot water with some dish soap for approximately 10 minutes.
- Do not use metal kitchen utensils or abrasive cleaning materials to clean the non-stick coating, as this may damage it.
- Clean the inside of the appliance with hot water and a non-abrasive sponge.
- Store the appliance in a dry, cool place when not in use.

## 8. TROUBLESHOOTING

---

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	The appliance is not plugged in.	Ensure the power plug is securely inserted into a grounded wall outlet.
	The timer is not set.	Turn the timer dial to the desired cooking time.
Food is not cooked evenly.	Too much food in the basket.	Reduce the amount of food per batch.
	Food was not shaken/turned.	Shake or turn the food halfway through the cooking time.

Problem	Possible Cause	Solution
White smoke comes from the appliance.	Grease residue from previous use.	Clean the basket and pan thoroughly after each use.

## 9. SPECIFICATIONS

Feature	Specification
Brand	Delimano
Model	B08H26G671
Colour	White
Capacity	2.5 litres
Power / Wattage	1500 watts
Control Method	Push Button (Dials)
Non-stick Coating	Yes
Dishwasher Safe	No (for main unit)
Date First Available	17 Oct. 2020
Manufacturer	Studio Moderna

## 10. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.