



Manuals.plus /

› SHW /

› SHW 36-Inch Height Adjustable Standing Desk Riser Converter (Model OD-82B-K) Instruction Manual

## SHW OD-82B-K

# SHW 36-Inch Height Adjustable Standing Desk Riser Converter

Model: OD-82B-K

## IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Retain this manual for future reference.

- Do not exceed the maximum weight capacity of 30 lbs (13.6 kg). Overloading can cause instability and potential injury.
- Always follow assembly instructions carefully to ensure safety and stability.
- Keep the desk riser on a stable, level surface. Avoid placing it on uneven or unstable surfaces.
- Ensure all components are securely fastened before use. Periodically check for loose connections.
- Keep hands and fingers clear of moving parts during height adjustment to prevent pinching.
- Do not allow children to operate the desk riser without adult supervision.

## PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with assembly.

- Main Desk Riser Unit (Pre-assembled base and main desktop)
- Monitor Shelf
- Storage Basket (Optional attachment)
- Assembly Hardware (Screws, Allen wrench)
- Instruction Manual

## SETUP AND ASSEMBLY

The SHW 36-Inch Standing Desk Riser Converter requires minimal assembly. All necessary tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, flat, and protected surface.
2. **Attach Monitor Shelf:** Align the monitor shelf with the designated attachment points on the main desk riser unit. Secure it using the provided screws and Allen wrench. Ensure it is firmly attached.



*Image: Fully assembled SHW 36-Inch Standing Desk Riser with monitor shelf in place.*

- 3. Install Storage Basket (Optional):** If desired, attach the storage basket underneath the monitor shelf using the provided hardware. Ensure it slides smoothly.



Image: Detailed view of the monitor shelf and optional storage basket, including dimensions.

4. **Position the Riser:** Place the assembled desk riser onto your existing desk or workstation. Ensure it is centered and stable.

## OPERATING INSTRUCTIONS

This desk riser features a pneumatic spring system for smooth and easy height adjustment.

### 1. To Raise the Desk:

- Remove any items that might obstruct the lifting mechanism.
- Locate the adjustment levers on both sides of the main desktop.
- Simultaneously press and hold both levers.
- Gently lift the desktop to your desired standing height. The pneumatic spring will assist in the upward movement.
- Release both levers to lock the desk at the chosen height. Ensure it is securely locked before placing items on it.



*Image: Illustration of raising the desk riser by pressing the side levers.*


## **2. To Lower the Desk:**

- Ensure the area below the desk is clear.
- Simultaneously press and hold both adjustment levers.
- Gently apply downward pressure to the desktop to lower it to your desired sitting height. Control the descent to avoid sudden drops.
- Release both levers to lock the desk at the chosen height.



*Image: Close-up of the ergonomic adjustment lever for height control.*

For optimal ergonomic positioning, adjust the desk so your arms are at a 90-degree angle when typing, whether sitting or standing.



*Image: Ergonomic guide illustrating proper posture for sitting and standing at a workstation.*

## MAINTENANCE

Regular maintenance helps ensure the longevity and proper function of your desk riser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

- **Mechanism Care:** Keep the lifting mechanism free of dust and debris. Do not apply lubricants unless specifically instructed by the manufacturer.

## TROUBLESHOOTING

---

If you encounter issues with your SHW Standing Desk Riser, refer to the following common solutions:

- **Desk does not adjust smoothly:**
  - Ensure both adjustment levers are pressed simultaneously and fully.
  - Check for any obstructions in the lifting mechanism.
  - Verify that the weight on the desk does not exceed the 30 lbs (13.6 kg) capacity.
- **Desk feels unstable:**
  - Confirm that the desk riser is placed on a flat, stable surface.
  - Check and tighten all assembly screws.
  - Ensure the desk is locked securely at the desired height after adjustment.

If problems persist, please contact SHW customer support.

## SPECIFICATIONS

---

<b>Brand</b>	SHW
<b>Model Number</b>	OD-82B-K
<b>Product Dimensions (D x W x H)</b>	24"D x 36"W x 16"H (Maximum Height)
<b>Height Adjustment Range</b>	4 inches to 16 inches
<b>Maximum Weight Capacity</b>	30 lbs (13.6 kg)
<b>Item Weight</b>	36 Pounds (16.3 kg)
<b>Material</b>	Engineered Wood (Top), Alloy Steel (Base)
<b>Color</b>	Black
<b>Assembly Required</b>	No (Minimal assembly for shelf/basket)

## WARRANTY AND SUPPORT

---

The SHW 36-Inch Height Adjustable Standing Desk Riser Converter comes with a Limited Warranty.

For warranty claims, technical support, or further inquiries, please visit the official SHW store or contact their customer service department.

Official SHW Store: [SHW Store on Amazon](#)