

[Manuals.plus](#) /

> [yema](#) /

> yema Rechargeable Personal Wand Massager Model 009 User Manual

## yema 009

# yema Rechargeable Personal Wand Massager Model 009 User Manual

Your guide to safe and effective use.

## INTRODUCTION

---

Thank you for choosing the yema Rechargeable Personal Wand Massager Model 009. This device is designed to provide targeted relief for muscle tension and soreness in areas such as the neck, back, shoulders, feet, and legs. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

## SAFETY INFORMATION

---

- **Do not use** the massager while charging.
- **Do not soak** the massager in water. While it is water-resistant for easy cleaning, immersion can cause damage.
- Keep out of reach of children.
- Consult a physician before use if you have any medical conditions, are pregnant, or have a pacemaker.
- Discontinue use immediately if you experience any discomfort or pain.
- Use only the provided charging cable.

## PRODUCT OVERVIEW

---

The yema Rechargeable Personal Wand Massager features a flexible, body-safe silicone head and an ergonomic handle for comfortable use. Below is an illustration of the product.



**Figure 1:** yema Rechargeable Personal Wand Massager. This image displays the massager's design, highlighting its flexible silicone head and the main body with control buttons. The device is purple.

## Components:

- **Flexible Silicone Head:** Provides a soft touch and conforms to body contours.
- **Control Panel:** Buttons for power, vibration patterns, and speed adjustment.
- **Charging Port:** Located at the base of the handle, protected by a cover.

## SETUP: CHARGING INSTRUCTIONS

---

Before first use, fully charge your yema massager.

1. Locate the charging port at the base of the massager handle.
2. Gently open the protective cover of the charging port.
3. Insert the small end of the provided USB charging cable into the massager's charging port.
4. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
5. The indicator light on the massager will illuminate to show it is charging.
6. Allow approximately **2 hours** for a full charge. The indicator light will change or turn off once charging is complete.
7. Once fully charged, disconnect the cable and securely close the charging port cover to maintain water resistance.

A full charge provides many hours of use, making it convenient for travel.

## OPERATING INSTRUCTIONS

---

Follow these steps to operate your yema massager:

1. **Power On:** Press and hold the power button (usually marked with a power symbol) for a few seconds until the massager turns on. It will typically start on a low setting.

2. **Change Vibration Patterns:** Press the pattern button (often marked with a wave or mode symbol) to cycle through the **20 different vibration patterns**.
3. **Adjust Speed:** Use the speed adjustment buttons (often marked with '+' and '-' or up/down arrows) to select from **8 multi-speeds** for your desired intensity.
4. **Apply:** Gently apply the flexible silicone head to the desired area of your body (neck, back, shoulders, feet, legs).
5. **Power Off:** Press and hold the power button again for a few seconds until the massager turns off.

## CARE AND MAINTENANCE

---

Proper care ensures the longevity and hygiene of your massager.

- **Cleaning:** The silicone head is water-resistant. Clean the massager after each use with a damp cloth or wet wipes. **Do not use harsh chemicals or abrasive cleaners.**
- **Drying:** Ensure the massager is completely dry before storing or recharging.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures. The included travel bag is ideal for discreet storage and transport.
- **Charging Port:** Always ensure the charging port cover is securely closed when not charging to prevent water ingress.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Massager does not turn on.	Battery is depleted.	Charge the massager for 2 hours.
Massager not charging.	Charging cable not properly connected or faulty.	Ensure the USB cable is securely connected to both the massager and the power source. Try a different USB port or adapter.
Weak vibration.	Low battery or speed setting is too low.	Recharge the massager. Increase the speed setting using the control buttons.
Buttons are unresponsive.	Device might be locked or experiencing a temporary glitch.	Ensure the device is not in a locked mode (if applicable, check product specific instructions for lock feature). Try fully charging the device. If issue persists, contact customer support.

## SPECIFICATIONS

---

- **Model Name:** 009
- **Brand:** yema
- **Material:** Body-safe Silicone
- **Vibration Patterns:** 20
- **Speed Levels:** 8
- **Power Source:** Rechargeable Lithium-ion Battery (USB charging)
- **Charging Time:** Approximately 2 hours
- **Water Resistance:** Yes (Splash-proof, do not immerse)

- **ASIN:** B08MTS19NM

## WARRANTY AND SUPPORT

---

Your yema Rechargeable Personal Wand Massager Model 009 comes with a **60-day guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact yema customer support through the retailer's platform where you purchased the item. Please have your purchase details and model number (009) ready when contacting support.

