

[Manuals.plus](#) /

› [Geeni](#) /

› Geeni Glimpse Indoor Security Camera User Manual (Model GN-CW036-199)

Geeni GN-CW036-199

Geeni Glimpse Indoor Security Camera User Manual

Model: GN-CW036-199

[Introduction](#) [What's in the Box](#) [Key Features](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The Geeni Glimpse Indoor Security Camera provides 1080p HD video surveillance for your home. Designed for ease of use, it features two-way audio, motion detection alerts, and night vision capabilities. This manual will guide you through the setup, operation, and maintenance of your camera to ensure optimal performance.

Key Features



HDLive Video



Motion Sensor



2-Way Audio



Night Vision



Swivel Design



Motion Zone



microSD Slot



Cloud Storage



Multiview



Image: Front view of the Geeni Glimpse Indoor Security Camera.

2. WHAT'S IN THE BOX

Your Geeni Glimpse Indoor Security Camera package includes the following components:

- Camera Body
- Wires and Connectors (Power Adapter and USB Cable)
- Complete Kit for installation

3. KEY FEATURES

The Geeni Glimpse camera offers a range of features for comprehensive indoor surveillance:

- **1080p HD Video:** Provides clear, high-definition live video and recordings.
- **2-Way Audio:** Communicate with individuals near the camera using the built-in microphone and speaker.
- **Motion Detection:** Receive instant alerts on your smartphone when motion is detected.
- **Night Vision:** Equipped with IR LEDs for clear surveillance up to 20 feet in low-light or dark conditions.

- **135° Wide-Angle Lens:** Captures a broad view of the monitored area.
- **Swivel Design:** Allows for flexible positioning and angle adjustment.
- **Local Storage:** Supports microSD card for continuous recording (card not included).
- **Cloud Storage:** Optional cloud storage available for recorded footage.
- **Smart Home Integration:** Compatible with Amazon Alexa and Google Home for voice control.



Image: Visual representation of the camera's key features.

4. SETUP GUIDE

Follow these steps to set up your Geeni Glimpse camera:

4.1. Download the Geeni App

Search for and download the "Geeni" app from the Apple App Store or Google Play Store on your smartphone.

4.2. Power On the Camera

Connect the camera to a power source using the provided USB cable and power adapter. The camera will power on and indicate its status, usually with a blinking LED light.

4.3. Connect to Wi-Fi


1. Open the Geeni app and create an account or log in.
2. Tap the "+" icon to add a new device.
3. Select your Geeni Glimpse camera from the list of available devices.
4. Follow the in-app instructions to connect the camera to your **2.4GHz Wi-Fi network**. Ensure your phone is also connected to the same 2.4GHz network during setup.
5. The app may display a QR code. Hold your phone with the QR code in front of the camera lens until you hear a confirmation sound.
6. Once connected, the camera's LED indicator will change, and you will see the camera in your Geeni app.

SIMPLE SETUP


1. Download App



2. Power On



3. Connect



Follow the step-by-step in-app instructions to be up and running with your new smart product.

Image: Simplified setup steps for the Geeni Glimpse camera.

4.4. Mounting the Camera

The camera can be placed on a flat surface or mounted on a wall. Its swivel design allows for flexible positioning to achieve the desired viewing angle.



Image: The Geeni Glimpse camera mounted on a wall, demonstrating its adjustable neck.

5. OPERATING INSTRUCTIONS

5.1. Live View

Once connected, open the Geeni app and select your camera to view live 1080p HD video from anywhere, anytime.



Image: Live video feed from the camera displayed on a smartphone.

5.2. Two-Way Audio

Tap the microphone icon in the app to speak through the camera's built-in speaker. Tap the speaker icon to hear audio from the camera's environment.



Image: Demonstrating the two-way audio function of the camera.

5.3. Motion Detection

The camera's sensitive motion sensor detects movement and sends real-time notifications to your phone. You can adjust motion sensitivity settings within the Geeni app.



Image: A smartphone screen showing a notification for detected motion.

5.4. Night Vision

The camera automatically switches to night vision mode in low-light conditions, providing clear black and white footage up to 20 feet.



Image: The camera monitoring a room in low light conditions using night vision.

5.5. Recording and Storage

The Geeni Glimpse supports local storage via a microSD card (up to 128GB, sold separately) for continuous recording. You can also subscribe to cloud storage services for secure backup of your video footage.



Image: Options for video storage, including cloud and microSD card.

5.6. Voice Control

Integrate your Geeni Glimpse camera with Amazon Alexa or Google Home for convenient voice commands, such as viewing the camera feed on compatible smart displays.




Image: The camera feed displayed on a smart home device via voice command.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Geeni Glimpse camera, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Software Updates:** Regularly check the Geeni app for firmware updates. Keeping your camera's software up-to-date ensures access to the latest features and security enhancements.
- **Placement:** Ensure the camera is placed in a stable indoor environment, away from direct sunlight, extreme temperatures, and moisture.

7. TROUBLESHOOTING

If you encounter issues with your Geeni Glimpse camera, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Camera not connecting to Wi-Fi	Incorrect Wi-Fi password, 5GHz network, weak signal, camera too far from router.	Ensure you are connecting to a 2.4GHz Wi-Fi network. Verify the Wi-Fi password. Move the camera closer to the router. Reset the camera and try the setup process again.
Camera frequently disconnects from Wi-Fi	Weak Wi-Fi signal, network interference, router issues, firmware bug.	Improve Wi-Fi signal strength (e.g., use a Wi-Fi extender, reposition router). Check for and install any available firmware updates via the Geeni app. Power cycle the camera and your Wi-Fi router.
No motion detection alerts	Motion detection disabled, sensitivity too low, app notifications off.	Enable motion detection in the Geeni app. Adjust motion sensitivity to a higher level. Check your phone's notification settings for the Geeni app.
Poor video quality	Low bandwidth, dirty lens, poor lighting.	Ensure stable internet connection. Clean the camera lens gently. Improve lighting in the monitored area if possible.
Two-way audio not working	Microphone/speaker muted in app, volume too low, app permissions.	Check audio settings in the Geeni app to ensure microphone and speaker are enabled and volume is adequate. Verify app permissions on your smartphone.

7.1. Official Product Video

Your browser does not support the video tag.

Video: An overview of the Geeni Glimpse Indoor 1080P Home Security Camera, demonstrating its features and functionality.

8. SPECIFICATIONS

Detailed technical specifications for the Geeni Glimpse Indoor Security Camera:



Image: Dimensions and key camera specifications.

Feature	Detail
Model Name	GN-CW036-199
Connectivity Technology	Wireless (Wi-Fi)
Indoor/Outdoor Usage	Indoor
Video Capture Resolution	1080p
Field Of View	135 degrees
Night Vision Range	20 feet
Special Features	Motion Sensor, Night Vision
Compatible Devices	Desktop, Laptop, Smartphone, Tablet
Controller Type	Amazon Alexa, Google Assistant, Vera
Power Source	Corded Electric (6 watts)
Item Dimensions (L x W x H)	3.14 x 3.14 x 4.52 inches
Material	Polycarbonate (PC)
Alert Type	Motion Only
Video Encoding	H.264

9. WARRANTY & SUPPORT

9.1. Warranty Information

Geeni products typically come with a limited manufacturer's warranty. Please refer to the product packaging or the official Geeni website for the most current and detailed warranty information regarding your Geeni Glimpse Indoor Security Camera.

9.2. Customer Support

For further assistance, technical support, or to report any issues, please visit the official Geeni support website or contact their customer service department. Contact details can usually be found on the Geeni website or within the Geeni app's help section.