

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Motorola](#) /

> [Motorola One Vision XT1970-2 User Manual](#)

Motorola XT1970-2

Motorola One Vision XT1970-2 User Manual

Model: XT1970-2

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Motorola One Vision XT1970-2 smartphone. Please read this guide thoroughly before operating your device. The Motorola One Vision features a 6.3-inch CinemaVision 21:9 Full HD+ display, a dual 48MP Quad Pixel rear camera with Night Vision, and a 25MP front camera. It is designed for use with GSM carriers globally.

2. WHAT'S IN THE BOX

Verify that your package contains the following items:

- Motorola One Vision XT1970-2 Smartphone
- Adapter (Charging)

Additional accessories may be sold separately.

3. DEVICE OVERVIEW



Figure 3.1: Front and Back View of the Motorola One Vision. This image displays the phone from both the front, showing the display and front camera, and the back, highlighting the dual rear camera system, fingerprint sensor, and Motorola logo.



Figure 3.2: Rear View of the Motorola One Vision. This image focuses on the back of the device, showcasing the dual camera module, LED flash, circular fingerprint sensor, and the 'android one' branding.



Figure 3.3: Side View of the Motorola One Vision. This image illustrates the right side of the phone, where the power button and volume rocker are located.

4. SETUP

4.1. Inserting SIM and microSD Cards

1. Locate the SIM tray on the side of your device.
2. Insert the SIM ejector tool (not included, use a thin pin if necessary) into the small hole on the tray to open it.
3. Place your Nano-SIM card(s) and/or microSD card into the tray with the gold contacts facing down. Ensure they are correctly seated.
4. Carefully push the tray back into the slot until it clicks into place.

4.2. Initial Charging and Power On

Before first use, it is recommended to fully charge your device. Use the provided adapter for optimal charging performance, including TurboPower capabilities.

- Connect the adapter to your phone's charging port and plug it into a power outlet.
- To power on, press and hold the Power button on the side of the device until the Motorola logo appears.
- Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

5. OPERATING INSTRUCTIONS

5.1. Basic Navigation

- **Touch:** Tap an item on the screen to select it.
- **Swipe:** Drag your finger across the screen to scroll or move between screens.
- **Pinch:** Use two fingers to zoom in or out on photos and web pages.
- **Home Screen:** Tap the Home button (or swipe up from the bottom if using gesture navigation) to return to the main screen.

5.2. Camera Usage

Your Motorola One Vision features a powerful camera system.

- **Rear Camera:** The 48MP Quad Pixel sensor with optical stabilization and Night Vision mode enhances low-light photography. Open the Camera app and select 'Night Vision' for improved night shots.
- **Front Camera:** The 25MP front camera utilizes Quad Pixel technology for brighter selfies.
- **Video Recording:** Select video mode within the Camera app to record videos.

5.3. Connectivity

- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi* to connect to available wireless networks.
- **Cellular Data:** Ensure your SIM card is active and mobile data is enabled in *Settings > Network & internet > Mobile network*. This device is compatible with GSM 4G LTE networks (e.g., T-Mobile, AT&T) but **not** with CDMA carriers (e.g., Sprint, Verizon Wireless).
- **Bluetooth:** Pair with other Bluetooth devices via *Settings > Connected devices > Bluetooth*.

5.4. Battery Management

The 3500 mAh battery provides extended usage. Utilize TurboPower for rapid charging, providing up to 7 hours of use with just 15 minutes of charging.

- To view battery usage, go to *Settings > Battery*.
- Enable Battery Saver mode to extend battery life when needed.

6. MAINTENANCE

6.1. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals, abrasive cleaners, or compressed air.
- Keep ports free of dust and debris.

6.2. Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Go to *Settings > System > System updates*.

6.3. Battery Care

- Avoid exposing the device to extreme temperatures.
- Do not puncture or damage the battery.
- Use only approved charging accessories.

7. TROUBLESHOOTING

7.1. Common Issues

- **Device not turning on:** Ensure the battery is charged. Press and hold the Power button for at least 10-15 seconds.
- **Charging issues:** Check the charging cable and adapter for damage. Try a different power outlet.
- **No network signal:** Verify your SIM card is properly inserted and active. Ensure you are within a GSM network coverage area. Remember, this device is not compatible with CDMA carriers.
- **Apps crashing:** Try clearing the cache for the problematic app (*Settings > Apps & notifications > App info > [App Name] > Storage & cache > Clear cache*).

7.2. Factory Reset

If you experience persistent issues, a factory reset may resolve them. **Warning:** This will erase all data on your phone. Back up important data before proceeding.

1. Go to *Settings > System > Reset options*.
2. Select *Erase all data (factory reset)*.
3. Confirm your decision and follow the on-screen instructions.

8. SPECIFICATIONS

Feature	Specification
Model Number	XT1970-2
Operating System	Android
RAM	4 GB
Memory Storage Capacity	128 GB
Screen Size	6.3 Inches
Resolution	1920 x 1080 (Full HD+)
Rear Camera	48 MP (Quad Pixel)
Front Camera	25 MP
Battery Capacity	3500 Milliamp Hours
CPU Model	Samsung Exynos 4210
CPU Speed	1.6 GHz
Product Dimensions	6 x 4 x 2 inches

Feature	Specification
Item Weight	1 pounds
Wireless Communication	Cellular (4G), Wi-Fi, Bluetooth
Cellular Technology	4G (GSM Unlocked)

9. WARRANTY AND SUPPORT

As this device is a renewed product, warranty coverage may differ from new products. Please refer to the specific warranty information provided by the seller, **thegadgetdeals**, or the Amazon Renewed program at the time of purchase. Typically, Amazon Renewed products come with a 90-day refund or replacement policy.

For technical support or further assistance, please contact the seller directly through your Amazon order history or refer to the Amazon Renewed support pages.