

Uten UTEN-AIR FRYERS-A1649

Uten 5.8 Quart Air Fryer Instruction Manual

MODEL: UTEN-AIR FRYERS-A1649

Your guide to healthy and efficient cooking.

Introduction

Welcome to the Uten 5.8 Quart Air Fryer. This appliance is designed to help you prepare delicious and healthier meals with significantly less oil. By utilizing rapid hot air circulation, it cooks food evenly, ensuring a crispy exterior and tender interior. This manual provides essential information for safe operation, maintenance, and optimal use of your new air fryer.

Enjoy your favorite foods without added calories, saving oil, money, and even cooking time!

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not place the air fryer directly against a wall or other appliances. Ensure there is at least 4 inches of free space on the back and sides, and 4 inches above the appliance.
- Do not cover the air inlet and air outlet openings while the appliance is operating.

- Do not fill the basket with oil as this may cause a fire hazard.
- Always ensure the basket is properly inserted before operating.

Product Components

The Uten 5.8 Quart Air Fryer consists of the following main components:

- Main Unit (housing the heating element and fan)
- Removable Non-Stick Fry Basket
- Timer Knob (0-60 minutes)
- Temperature Knob (80-200°C)
- Power Indicator Light
- Heating Indicator Light



Figure 1: Uten 5.8 Quart Air Fryer - Front View

360° RAPID AIR CIRCULATION

Circulate hot air around your food to cook evenly and lock in moisture without any oil and grease.



Figure 2: Internal view illustrating 360° Rapid Air Circulation for even cooking.

Before First Use

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Thoroughly clean the basket and pan with hot water, some dishwashing liquid, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a moist cloth.
4. Place the air fryer on a stable, horizontal, and level surface. Ensure the surface is heat-resistant.
5. Position the air fryer away from walls or other appliances to allow for proper air circulation from the rear vent.

Operating Your Air Fryer

1. Preheating

To preheat the air fryer, simply turn the timer knob to the desired preheating time (typically 3-5 minutes) and the temperature knob to the desired cooking temperature. The air fryer will begin heating automatically.

2. Loading the Basket

Carefully pull the air fryer's handle to slide out the basket. Place your food inside the non-stick basket. Do not overfill the basket to ensure even cooking.

3. Setting Temperature and Time

Once the food is loaded, slide the basket back into the main unit. Use the temperature knob to set the desired cooking temperature (80-200°C) and the timer knob to set the cooking time (0-60 minutes). The appliance will automatically start the cooking process.



Figure 3: Easy-to-use manual knobs for precise control.

4. Cooking Process

During cooking, the hot air circulates rapidly to cook your food. For best results, especially with larger quantities or certain foods, shake the basket halfway through the cooking time. The timer will ding when the set time has elapsed. Carefully remove the basket and transfer the cooked food.

Video: Demonstrates the Uten 5.8 Quart Air Fryer in operation, including loading food, setting controls, and showing cooked

Cooking Guide

The following table provides general guidelines for cooking various foods. Cooking times and temperatures may vary based on food quantity, thickness, and desired crispiness. Always use a food thermometer to ensure food is cooked to a safe internal temperature.




Figure 4: Quick reference cooking chart for common air fryer recipes.

Recommended Cooking Times & Temperatures

Food Item	Temperature (°C)	Time (Minutes)
Fish	80	10-14
Fries	200	16-20
Steak	200	8-12
Bread	180	15-18
Cake	160	20-25
Vegetables	150	10-14

Cleaning and Maintenance

Regular cleaning of your air fryer will ensure its longevity and optimal performance.

1. Unplug the appliance and allow it to cool down completely before cleaning.
2. To remove the basket from the pan: Open the clear plastic lid on the handle and press the button to release the basket. Lift the basket out of the pan.
3. The removable non-stick basket and pan are dishwasher safe. Alternatively, you can wash them with hot water, dishwashing liquid, and a non-abrasive sponge.
4. Wipe the exterior of the appliance with a damp cloth. Do not use harsh abrasive cleaners or scouring pads.
5. Clean the interior of the appliance with a non-abrasive sponge or cloth.

6. Ensure all parts are thoroughly dry before reassembling and storing the appliance.



Figure 5: Steps for easy basket removal and cleaning.

Troubleshooting

If you encounter any issues with your Uten Air Fryer, please refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Timer not set.	Ensure the power cord is securely plugged into a grounded wall outlet. Turn the timer knob to the desired cooking time.
Food not cooked evenly.	Basket is overfilled; Food not shaken.	Reduce the amount of food in the basket. Shake the basket halfway through the cooking process.
White smoke coming from the appliance.	Grease residue from previous use; High fat content food.	Clean the basket and pan thoroughly after each use. For high-fat foods, consider draining excess fat during cooking.
Food is not crispy.	Not enough oil (for certain foods); Temperature too low; Cooking time too short.	Lightly spray or brush food with oil. Increase temperature or cooking time as needed.

Specifications

- **Brand:** Uten
- **Model Name:** UTEN-AIR FRYERS-A1649
- **Capacity:** 5.5 Liters (5.8 Quart)
- **Output Wattage:** 1700 Watts
- **Voltage:** 110 Volts

- **Control Method:** Knob, Manual
- **Special Feature:** Temperature Control (80-200°C)
- **Product Dimensions:** 14.4"D x 14.2"W x 11.8"H
- **Item Weight:** 13.95 Pounds
- **Material:** Plastic (Outer), PTFE or Ceramic (Inner)
- **Has Nonstick Coating:** Yes
- **Is Dishwasher Safe:** Yes (Basket)
- **Air Frying Technology:** Hot Air Circulation

Warranty and Customer Support

Your Uten Air Fryer has passed CE and RoHS certification, ensuring its quality and safety. We are committed to providing excellent customer service.

If you have any questions or concerns about the product, please feel free to contact us via Amazon Messages or the after-sales email provided in your purchase documentation. We aim to resolve all inquiries within 24 hours.