

RuenTech SW022/ID206 Compatible Band

RuenTech Smart Watch Band Instruction Manual

For YAMAY SW022 and ID206 Smart Watches

1. INTRODUCTION

This manual provides instructions for the RuenTech Quick Release Soft Silicone Adjustable Wristband, designed for compatibility with YAMAY SW022 and ID206 smartwatches. These bands are made from durable silicone and feature a quick-release pin mechanism for easy installation and removal. Please note that these bands are not compatible with YAMAY SW020, SW021, SW023, or SW025 models.

2. SETUP: BAND INSTALLATION

Follow these steps to properly install your RuenTech replacement watch band:

1. **Prepare the Watch:** Turn your smartwatch over to access the band attachment points.
2. **Insert First Pin Side:** Take one end of the new band. Insert one side of the quick-release pin into the corresponding notch on the watch lug.
3. **Angle the Band:** Ensure the band and watch are held at approximately a 90-degree angle to facilitate proper alignment.
4. **Engage Second Pin Side:** Press the small pull-rod (the quick-release lever) inward. While holding the pull-rod, slide the other end of the band into place between the watch lugs. Release the pull-rod once the pin is aligned and seated.
5. **Verify Security:** Gently sway both ends of the installed band to confirm that they are firmly attached and the pins are securely locked into the watch lugs. Repeat the process for the second band piece.



Image 1: Assortment of RuenTech silicone quick-release watch bands in black, white, teal, red, gray, and dark teal. One black band is shown attached to the back of a black smartwatch, illustrating the quick-release pin mechanism. The bands feature a classic buckle closure and multiple adjustment holes.

3. OPERATING: WEARING AND ADJUSTMENT

Once installed, wear the watch band by inserting the free end through the buckle and securing it with the metal pin. Adjust the band to a comfortable fit on your wrist using the available holes. Ensure the watch is snug enough for accurate sensor readings but not so tight as to restrict circulation.

4. MAINTENANCE

To ensure the longevity and hygiene of your silicone watch band, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the band with mild soap and water. Rinse thoroughly and dry with a soft cloth. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the band in a cool, dry place away from direct sunlight to prevent material degradation.
- **Avoid Extreme Conditions:** While silicone is durable, prolonged exposure to extreme temperatures or chemicals may affect its integrity.

5. TROUBLESHOOTING

Band Detaches Easily

If the band frequently detaches from your smartwatch, consider the following:

- **Verify Installation:** Re-check the installation steps (Section 2). Ensure both ends of the quick-release pin are fully seated within the watch lugs. You should hear or feel a slight click when the pin locks into place.
- **Check Compatibility:** Confirm that your smartwatch model is indeed YAMAY SW022 or ID206. These bands are specifically designed for these models and may not fit others correctly.
- **Inspect Pins:** Examine the quick-release pins for any signs of damage or bending. If a pin appears faulty, contact customer support.

6. SPECIFICATIONS

- **Material:** Silicone
- **Clasp Type:** Tang Buckle (Stainless Steel)
- **Compatibility:** YAMAY SW022, YAMAY ID206 (Not compatible with SW020, SW021, SW023, SW025)
- **Manufacturer:** RuenTech

7. WARRANTY AND SUPPORT

For any issues or inquiries regarding your RuenTech watch band, please utilize the following support method:

- **Contact Seller:** Log in to your Amazon account, navigate to 'Your Orders', find the specific order ID for this product, and click 'Contact seller'.

© 2023 RuenTech. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question