

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BAKALI](#) /

› [BAKALI Air Fryer 3.2L Instruction Manual](#)

BAKALI D01433

BAKALI Air Fryer 3.2L Instruction Manual

Model: D01433

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your BAKALI 3.2 Liter Air Fryer. Please read these instructions carefully before first use and retain them for future reference.



Image: The BAKAJI 3.2L Air Fryer displayed on a kitchen counter, surrounded by a variety of prepared dishes, showcasing its versatility.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Allow adequate space around the appliance for proper ventilation.

PRODUCT OVERVIEW

The BAKAJI Air Fryer utilizes rapid hot air circulation to cook food with little to no oil, offering a healthier alternative to traditional frying. It features a digital touch display for easy operation.



Image: Front and rear views of the air fryer, highlighting its compact design, digital control panel, and ventilation system.

Key Features:

- **Capacity:** 3.2 Liters
- **Power:** 1300 Watts
- **Temperature Range:** 80-200°C (176-392°F)
- **Timer:** Up to 30 minutes
- **Control:** Digital Touch Display

- **Cooking Technology:** 360° Hot Air Circulation
- **Material:** Plastic, Steel



Image: Visual representation of the air fryer's core features: 360° hot air circulation, adjustable temperature (80-200°C), 1300W power, and oil-free cooking capability.

**80% di Olio in meno
rispetto alle normali friggitrici**



Image: A visual comparison illustrating the air frying method, which uses significantly less oil, compared to traditional deep frying.

SETUP AND FIRST USE

- Unpacking:** Carefully remove the air fryer and all packaging materials. Ensure all parts are present and undamaged.
- Initial Cleaning:** Before first use, clean the frying basket and pan with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Do not immerse the main unit in water.
- Placement:** Place the appliance on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides, and 10 cm (4 inches) above the appliance to allow for proper air circulation.
- Preheating (Optional):** For optimal results, preheat the air fryer for 3-5 minutes at the desired cooking temperature before adding food.

OPERATING INSTRUCTIONS

General Operation:

1. Plug the power cord into a grounded wall outlet.
2. Carefully pull the frying basket out of the air fryer.
3. Place the ingredients into the frying basket. Do not exceed the MAX fill line.
4. Slide the frying basket back into the air fryer.
5. Use the digital touch display to set the desired temperature and cooking time.
6. Press the start button to begin cooking.
7. Some ingredients may require shaking halfway through the cooking time. Pull out the basket, shake, and slide it back in. The air fryer will resume cooking.
8. When the cooking time has elapsed, the appliance will beep. Carefully pull out the basket and remove the food.

Preset Programs:

The BAKAJI Air Fryer comes with 8 pre-set cooking programs for common dishes, accessible via the digital touch display.



Image: The air fryer's digital control panel displaying icons for 8 pre-programmed cooking functions, including fries, cake, pizza, shrimp, chicken, steak, fish, and bacon.

- Fries
- Frozen Foods
- Wings
- Steak
- Potatoes
- Fish
- And more...

Select the desired program, and the air fryer will automatically set the optimal temperature and time. You can adjust these settings manually if needed.



Image: The air fryer with its cooking basket partially removed, revealing a batch of perfectly cooked, golden-brown fries.

MAINTENANCE AND CLEANING

Clean the appliance after every use. Always unplug the appliance and allow it to cool down completely before cleaning.

- Basket and Pan:** The frying basket and pan have a non-stick coating. Clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak the basket and pan in hot water with some dish soap for about 10 minutes.
- Interior:** Wipe the inside of the appliance with a damp cloth and mild liquid soap.
- Exterior:** Clean the exterior of the appliance with a damp cloth. Do not use abrasive cleaning agents or scouring pads.
- Heating Element:** Clean the heating element with a cleaning brush to remove any food residues.
- Storage:** Ensure all parts are clean and dry before storing the appliance.

Parti removibili per una facile pulizia



Rivestimento interno e griglia con rivestimento antiaderente



Image: A sequence of images demonstrating the removal of the air fryer's basket and internal grill for thorough and easy cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Basket is overloaded; food not shaken.	Do not overload the basket. Shake ingredients halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and pan thoroughly after each use. For fatty foods, absorb excess oil before cooking.
Food is not crispy.	Too much moisture; insufficient cooking time/temperature.	Pat food dry before cooking. Increase cooking time or temperature slightly.

SPECIFICATIONS

Brand: BAKAJI

Model: D01433

Color: Black

Product Dimensions: 27 x 30 x 32 cm (10.6 x 11.8 x 12.6 inches)

Capacity: 3.2 Liters

Wattage: 1300 Watts

Voltage: 240 Volts

Material: Plastic, Steel

Automatic Shut-off: Yes

Special Feature: Timer

Item Weight: 3 Kilograms (6.6 lbs)

CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact your retailer or the BAKAJI customer service. Refer to your purchase documentation for specific contact details.

This product is covered by a standard return policy. Please consult the seller's return policy for details regarding returns and replacements.

