

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

AMIR B09F5SL8K6

AMIR Digital LED Alarm Clock

USER MANUAL

Model: B09F5SL8K6

Introduction

Thank you for purchasing the AMIR Digital LED Alarm Clock. This clock features a large LED display, adjustable brightness, temperature display, voice control, and multiple alarm modes. This manual provides detailed instructions on how to set up, operate, and maintain your new alarm clock.



Figure 1: Front view of the AMIR Digital LED Alarm Clock. The clock features a large, clear red LED display.

Package Contents

- 1 x AMIR Digital LED Alarm Clock
- 1 x USB Power Cable (1 meter)

- 1 x User Manual

Note: AAA batteries and AC adapter are not included.



Figure 2: The AMIR Digital LED Alarm Clock, its USB power cable, and the user manual as found in the package.

Setup

1. Powering the Device

The clock can be powered in two ways:

1. **USB Cable Power:** Connect the provided USB cable to the clock's power input and plug the other end into a USB power adapter (not included) or a USB port on a computer. The display will remain continuously on when powered by USB.
2. **Battery Power:** Insert 3 x AAA batteries (not included) into the battery compartment on the back of the clock. When powered by batteries, the display will automatically turn off after 16 seconds to conserve energy. You can activate the display by making a sound (voice control) or touching the clock.

Note: Using both USB power and batteries provides a memory function, retaining time settings during power outages.

2. Button Functions

Familiarize yourself with the buttons located on the back of the clock:

- **DOWN:** Decreases values, adjusts brightness.
- **UP:** Increases values, adjusts brightness.
- **LIGHT/SNOOZE:** Adjusts brightness, activates snooze function.
- **MODE:** Switches between clock, date, and temperature modes.
- **ALARM:** Enters alarm setting mode.



Figure 3: Overview of the clock's dimensions and button layout.

3. Initial Time Setting

1. Press and hold the **MODE** button for 3 seconds to enter time setting mode. The hour digits will flash.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press **MODE** again to switch to minute setting. The minute digits will flash.
4. Use the **UP** or **DOWN** buttons to adjust the minute.
5. Press **MODE** to confirm and exit time setting.

4. 12/24H Format Selection

While in time setting mode (after step 1 above), press the **UP** button to toggle between 12-hour and 24-hour formats.

5. Temperature Display

The clock automatically displays the temperature. To switch between Celsius (°C) and Fahrenheit (°F), press the **DOWN** button while in temperature display mode (press **MODE** until temperature is shown).

Operating Instructions

1. Adjusting Brightness

The clock offers three levels of brightness (Bright, Medium, Low) and a Night Mode.

- **Manual Adjustment:** Press the **UP** or **DOWN** buttons (not in setting mode) to cycle through Bright, Medium, and Low brightness levels.
- **Night Mode:** In Night Mode, the display automatically dims between 18:00 (6 PM) and 6:00 (6 AM). To activate/deactivate Night Mode, press and hold the **MODE** button until "OFF" or "ON" appears. You can also customize the night mode time period by pressing **MODE** again after activating Night Mode.
- **Display Off:** To completely turn off the display while sleeping, press and hold the **LIGHT/SNOOZE** button for more than 3 seconds. Press any button to turn it back on.

ADJUSTABLE BRIGHTNESS

Anti-interference function The display can be turned off completely




Figure 4: Visual representation of the three adjustable brightness levels.

2. Setting the Alarm

The clock supports three alarm modes: Monday-Friday, Monday-Saturday, and Everyday.

1. Press and hold the **ALARM** button for 3 seconds to enter alarm setting mode. The hour digits will flash.
2. Use the **UP** or **DOWN** buttons to adjust the alarm hour.
3. Press **ALARM** again to switch to minute setting. The minute digits will flash.
4. Use the **UP** or **DOWN** buttons to adjust the alarm minute.
5. Press **ALARM** again to select the snooze duration (1-60 minutes). Use **UP** or **DOWN** to adjust.
6. Press **ALARM** again to select the alarm mode:
 - **1-5**: Monday to Friday
 - **1-6**: Monday to Saturday
 - **1-7**: Everyday


Use **UP** or **DOWN** to select.

7. Press **ALARM** to confirm and exit alarm setting.

THREE ALARM MODES



1-5 MONDAY TO FRIDAY



1-6 MONDAY TO SATURDAY



1-7 EVERYDAY




Figure 5: The three available alarm modes for customized wake-up schedules.

3. Snooze Function

When the alarm sounds, press the **LIGHT/SNOOZE** button to activate the snooze function. The alarm will sound again after the set snooze duration (1-60 minutes). To cancel the alarm completely, press any other button.

EASY SNOOZE

SNOOZE FUNCTION ALLOWS YOU TO ASK FOR 1~60 MINUTE EXTRA SLEEP TIME.



Figure 6: The snooze function allows for additional sleep time after the alarm sounds.

4. Voice Control & Power Saving Mode (Battery Powered Only)

When the clock is powered solely by AAA batteries, it enters a power-saving mode where the display turns off after 16 seconds of inactivity. You can activate the display by:

- Making a sound (e.g., clapping hands, knocking on the table).
- Touching the clock.

The clock's internal time and temperature tracking continue even when the display is off in power-saving mode.

SOUND CONTROL & POWER SAVING

Wake up the clock by sound or touch when powered only by 3AAA batteries (not included)



Figure 7: The clock's display can be activated by sound or touch when running on battery power.

Maintenance

- **Cleaning:** Wipe the clock surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If using batteries, replace them when the display becomes dim or the clock functions become erratic. Ensure correct polarity when inserting new batteries.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Display is off or dim.	Running on battery power in power-saving mode. Low batteries. USB cable not properly connected. Display brightness set to "Off".	Make a sound or touch the clock to activate display. Replace AAA batteries. Check USB cable connection and power source. Press any button to turn display back on.
Alarm does not sound.	Alarm is not set or is deactivated. Alarm volume is too low (not applicable for this model, but common).	Verify alarm settings and ensure it is enabled for the desired days. Ensure the clock is powered.
Voice control not working.	Clock is powered by USB cable. Insufficient sound level.	Voice control only works when powered by batteries. Make a louder sound or try touching the clock.

Specifications

Brand	AMIR
Model	B09F5SL8K6
Display Type	Digital LED
Color	Red (LED display)
Power Source	Wired Electric (USB) and Battery Powered (3x AAA, not included)
Special Features	Alarm, Adjustable Brightness, Temperature Display, Night Mode, Snooze, Voice Control
Product Dimensions	16L x 6H cm (approx. 6.3 x 2.36 inches)
Weight	160 g (approx. 0.35 lbs)

Warranty and Support

This product comes with a standard manufacturer's warranty. For warranty claims or technical support, please contact the retailer or manufacturer directly. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the AMIR official website or contact their customer service.