

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mesqool](#) /

› [Mesqool Powerful Alarm Clock with Bed Shaker User Manual](#)

### Mesqool CR1018i

## Mesqool Powerful Alarm Clock with Bed Shaker User Manual

Model: CR1018i

### INTRODUCTION

Thank you for choosing the Mesqool Powerful Alarm Clock with Bed Shaker. This innovative device combines a digital alarm clock with a large LED mirror display, offering multiple wake-up options and convenient features. Designed for heavy sleepers, children, and teenagers, it ensures you wake up on time with customizable settings. Please read this manual carefully to understand all features and ensure proper operation.



Mesqool Alarm Clock with Bed Shaker and USB Charging

Key features include dual alarms, three wake-up modes (buzzer, vibration, or both), an 8.7-inch LED mirror display with adjustable brightness, a USB charging port for mobile devices, and battery backup for settings during power outages.

## SETUP

### Package Contents

- 1 x Mesqool Alarm Clock
- 1 x Bed Shaker
- 1 x USB Power Cable
- 1 x Power Adapter
- 1 x User Manual

### Power Connection

Connect the provided USB power cable to the DC IN 5V port on the back of the alarm clock. Plug the other end into the power adapter, and then plug the adapter into a standard wall outlet. The display will light up, indicating the clock is powered on.



Connecting the power cable to the alarm clock.

### **Battery Backup Installation**


The alarm clock includes a built-in button battery for backup. This battery ensures that your time and alarm settings are retained during a power outage. No user installation is typically required for this battery, but if replacement is ever needed, locate the battery cover on the back of the unit, open it, and replace the button battery with a new one of the same type.



Battery backup compartment on the back of the alarm clock.

### **Overview of Controls and Ports**

Familiarize yourself with the buttons and ports on the alarm clock for easy operation.



Front and back view of the alarm clock with labeled controls.

## OPERATING INSTRUCTIONS

### Setting Time and 12/24 Hour Format

To set the time, press the 'TIME' button. Use the 'HOUR' and 'MINUTE' buttons to adjust the hour and minute. Press 'TIME' again to confirm. To switch between 12-hour and 24-hour format, press the 'TIME 12H/24H' button located on the back or side of the unit, or as indicated in the control overview.


# 12/24 Hours Format DST



12 H



24 H



Time display in 12-hour and 24-hour formats.

## Setting Dual Alarms

This alarm clock allows you to set two independent alarms (Alarm 1 and Alarm 2). Press the 'ALARM 1' or 'ALARM 2' button to enter alarm setting mode. Use the 'HOUR' and 'MINUTE' buttons to set the desired alarm time. Press the respective 'ALARM' button again to confirm and activate the alarm. An alarm icon will appear on the display when active.

# DUAL ALARM SETTINGS

You can set two alarms a day,  
no longer worry about setting the alarm frequently.



Setting two distinct alarm times for different needs.

## Selecting Alarm Modes (Sound, Vibration, Both)

The alarm clock offers three wake-up modes: loud buzzer, strong vibration (bed shaker), or a combination of both. On the back of the unit, locate the switch labeled 'BUZZ', 'BUZZ/VIB', and 'VIB'. Slide the switch to your preferred mode. Connect the bed shaker to the 'VIBRATOR PORT' if you wish to use the vibration mode.

## 3 WAKE UP MODES



Bed Shaker Mode



Loud Buzzer Mode



Bed Shaker + Buzzer Mode



Choose your preferred wake-up method: buzzer, vibration, or both.

### Snooze Function

When the alarm sounds, press the large 'SNOOZE' button to temporarily silence the alarm and get an additional 9 minutes of sleep. The alarm will sound again after 9 minutes. To turn off the alarm completely, press the 'ALARM OFF' button.

# EASY SNOOZE FUNCTION

Press the big snooze button to get extra 9 minutes sleep.



Utilizing the snooze function for extra sleep.

## Adjusting Volume

The alarm volume can be adjusted to 7 different levels, ranging from 0dB to 110dB. Use the 'VOLUME/DST' button to cycle through the volume levels until you find a suitable setting. This allows for a personalized wake-up experience.

# 0-110dB ADJUSTABLE VOLUME

7 levels adjustable volume, there is always a suitable for you.



Adjusting the alarm volume to your preference.

## Adjusting Display Brightness

The 8.7-inch LED display features adjustable brightness with 7 levels. Press the 'DIMMER' button to cycle through the brightness settings. You can choose a bright display for daytime visibility or dim it significantly, even turning it off completely, for a comfortable sleeping environment at night.

## 8 LEVELS ADJUSTABLE BRIGHTNESS

Easily press the Dimmer button to adjust brightness according to different environment.  
Soft display screen, save power and energy.



Adjusting the LED display brightness for optimal viewing.

### Using the USB Charging Port

The alarm clock is equipped with a 5V/1A USB charging port (labeled 'CHARGING PORT 5V/1A') on the back. You can use this port to conveniently charge your smartphone, tablet, or other USB-powered devices while the alarm clock is plugged into power.



Charging a smartphone using the alarm clock's USB port.

## Mirror Function

The sleek surface of the alarm clock's display also functions as a mirror. This multi-purpose design allows it to be used as a convenient makeup mirror or simply as a decorative element in your bedroom or living space.

## Multi-function Mirror



The alarm clock's display doubles as a functional mirror.

## MAINTENANCE

To maintain your Mesqool alarm clock, wipe the display and body with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the surface. Ensure the device is unplugged before cleaning. Keep the bed shaker clean and free of debris.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off or flickering.	No power connection or loose cable.	Ensure the power adapter is securely plugged into the wall outlet and the clock. Check for power outages.

Problem	Possible Cause	Solution
Alarm does not sound/vibrate.	Alarm not set, alarm mode incorrect, or volume too low.	Verify alarm time is set and activated. Check the alarm mode switch (BUZZ/VIB). Increase volume. Ensure bed shaker is properly connected.
Time/settings lost after power outage.	Backup battery depleted or missing.	The internal button battery should retain settings. If not, it may need replacement.
USB charging not working.	Device not properly connected or power issue.	Ensure the alarm clock is powered on. Check the USB cable connection to both the clock and your device. Try a different USB cable.
Display too bright/dim.	Brightness setting needs adjustment.	Press the 'DIMMER' button to cycle through brightness levels.

## SPECIFICATIONS

Feature	Detail
Brand	Mesqool
Model Number	CR1018i
Color	Black/White
Product Dimensions (L x W x H)	20 x 4.4 x 10.2 cm
Item Weight	258 g
Material	Plastic
Display Type	Digital LED
Screen Size	8.7 inches
Power Source	Electric Cable (DC 5V/1A)
Battery Backup	Button battery (included)
Alarm Volume Levels	7 levels (0-110dB)
Display Brightness Levels	7 levels (adjustable dimmer)
Time Format	12H/24H selectable
USB Charging Output	5V/1A
Special Features	Dual Alarms, Bed Shaker, Mirror Function, USB Charging Port, Adjustable Brightness, Adjustable Volume

Feature	Detail
Room Type	Home Office, Kids Room, Bedroom, Study Room, Living Room

## WARRANTY AND SUPPORT

---

Mesqool is committed to providing high-quality products. For any questions, concerns, or technical support regarding your alarm clock, please refer to the contact information provided with your purchase or visit the official Mesqool website. Please retain your proof of purchase for warranty claims, if applicable.