Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Pabobo /
- > Pabobo Kid'Sleep Essential White Wake-Up Indicator User Manual

Pabobo CK0042-KSCE-WHITE

Pabobo Kid'Sleep Essential White Wake-Up Indicator User Manual

Model: CK0042-KSCE-WHITE

INTRODUCTION

The Pabobo Kid'Sleep Essential is an educational wake-up indicator designed to help children understand the difference between sleep time and wake-up time. It features a visual display with a rabbit character that changes position (sleeping or waking) to indicate whether it's still time to sleep or if it's time to get up. This device also includes a night light function with adjustable intensity and a projection feature, making it a versatile tool for establishing healthy sleep routines for children.



Figure 1: Front view of the Kid'Sleep Essential, illustrating the sleeping and waking rabbit indicators.

SAFETY INFORMATION

Please read all instructions carefully before using the Kid'Sleep Essential. Keep this manual for future reference.

- This product is not a toy. Adult supervision is recommended, especially for young children.
- Do not immerse the device in water or expose it to excessive moisture.
- Use only the specified battery type (3 AA batteries). Ensure correct polarity when inserting batteries.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the device will not be used for an extended period.
- Keep packaging materials away from children to prevent suffocation hazards.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

1. Unboxing and Components

Carefully remove all components from the packaging. Ensure the following items are present:

- Kid'Sleep Essential Wake-Up Indicator unit
- USB power cable (charger not always included, check packaging)
- Alternative decorative plate (moon design)
- User Manual (this document)

2. Battery Installation

The Kid'Sleep Essential operates on 3 AA batteries (not included). To install batteries:

- 1. Locate the battery compartment on the back of the unit.
- 2. Using a small screwdriver, open the battery compartment cover.
- 3. Insert 3 AA batteries, ensuring the correct positive (+) and negative (-) polarity as indicated inside the compartment.
- 4. Replace the battery compartment cover and secure it with the screw.

The device can also be powered via the included USB cable by connecting it to a compatible USB power adapter (e.g., phone charger) or a computer USB port.



Figure 2: Rear view of the Kid'Sleep Essential, highlighting the battery compartment and control panel.

3. Initial Time Setting

After installing batteries or connecting power, the display will activate. To set the current time:

- 1. Press and hold the "Time" button (often indicated by a clock icon) for 3 seconds to enter time setting mode. The hour display will flash.
- 2. Use the "+" and "-" buttons to adjust the hour.
- 3. Press the "Time" button again to confirm the hour and move to minute setting. The minute display will flash.
- 4. Use the "+" and "-" buttons to adjust the minutes.
- 5. Press the "Time" button one more time to confirm and exit time setting mode.

OPERATING INSTRUCTIONS

1. Wake-Up Indicator Function

The core function of the Kid'Sleep Essential is its visual wake-up indicator. A rabbit character is displayed, which is either

sleeping (indicating it's still sleep time) or awake (indicating it's time to get up).

- When the rabbit is in the **sleeping position**, the child should remain in bed.
- At the programmed wake-up time, the rabbit will automatically switch to thewaking position, signaling that it's okay
 to get up.



Figure 3: Visual guide to the wake-up indicator, demonstrating sleep and wake states.

2. Setting Wake-Up Time

To program the morning wake-up time:

- 1. Press and hold the "Wake" button (often indicated by a bell or sun icon) for 3 seconds. The hour display for the wake-up time will flash.
- 2. Use the "+" and "-" buttons to adjust the desired wake-up hour.
- 3. Press the "Wake" button again to confirm the hour and move to minute setting. The minute display will flash.
- 4. Use the "+" and "-" buttons to adjust the desired wake-up minutes.

5. Press the "Wake" button one more time to confirm and exit setting mode.

3. Setting Nap Time

The device also allows for programming a nap duration:

- 1. Press and hold the "Nap" button (often indicated by a crescent moon or 'Zz' icon) for 3 seconds. The nap duration display will flash.
- 2. Use the "+" and "-" buttons to adjust the desired nap duration (e.g., in hours and minutes).
- 3. Press the "Nap" button again to confirm and exit setting mode.

4. Light Intensity Adjustment

The screen's light intensity can be adjusted to 3 different levels:

- Locate the light intensity button (often indicated by a sun icon with rays).
- Press the button repeatedly to cycle through the 3 intensity levels. Select the level most comfortable for your child's room.

5. Projection Feature

The Kid'Sleep Essential can project a moon or sun image onto the ceiling, correlating with the sleep/wake status.

- When the rabbit is sleeping, a moon image is projected.
- When the rabbit is awake, a sun image is projected.
- To activate or deactivate the projection, locate the projection button (often indicated by a star or projector icon) and press it.





Figure 4: The device projecting a moon (left) and a sun (right) image.

6. Alarm Options (Silent / Bird Song)

The transition from sleeping to waking rabbit can be accompanied by an alarm or remain silent.

- Locate the alarm setting button (often indicated by a musical note or speaker icon).
- Press the button to toggle between silent mode and bird song alarm mode.

7. Parental Lock

To prevent children from accidentally changing settings, the Kid'Sleep Essential features a parental lock.

- To activate the parental lock, press and hold the "Lock" button (often indicated by a padlock icon) for 3 seconds. A lock icon may appear on the display.
- To deactivate the parental lock, press and hold the "Lock" button again for 3 seconds.

8. Night Light Mode (Alternative Plate)

The Kid'Sleep Essential comes with an alternative decorative plate featuring a moon design, which can be used for a dedicated night light function, especially suitable for newborns.

- To switch plates, gently remove the current front plate and insert the alternative moon plate.
- In this mode, the device functions primarily as a soothing night light.



Figure 5: The Kid'Sleep Essential with the alternative moon night light plate.

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure the device is unplugged and batteries are removed before cleaning.
- Storage: Store the device in a cool, dry place away from direct sunlight when not in use for extended periods.
- Battery Replacement: Replace batteries when the display dims or functions become erratic. Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	No batteries or dead batteries. Incorrect battery polarity. No power from USB.	Ensure 3 AA batteries are correctly inserted and charged. Connect to a working USB power source.
Rabbit indicator does not change.	Wake-up time not set correctly. Parental lock activated.	Verify wake-up time settings. Deactivate parental lock (press and hold lock button for 3 seconds).
Projection is dim or not visible.	Room is too bright. Projection feature is off.	Ensure the room is dark enough. Activate the projection feature using its dedicated button.
Alarm sound is not working.	Device is in silent mode.	Toggle the alarm setting to bird song mode.
Buttons are unresponsive.	Parental lock activated. Temporary software glitch.	Deactivate parental lock. If still unresponsive, remove batteries for 1 minute and reinsert to reset.

SPECIFICATIONS

Brand	Pabobo
Model Number	CK0042-KSCE-WHITE
Color	White
Dimensions (L x W x H)	19 x 8 x 18 cm (7.5 x 3.1 x 7.1 inches)
Weight	305 grams (0.67 lbs)
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	3 x AA Batteries (not included) or USB powered
Special Features	Silent clock, Illuminated display, Wake-up indicator, Night light, Projections, Parental lock
Display Type	Digital
Indoor/Outdoor Use	Indoor

WARRANTY AND SUPPORT

Pabobo products are designed for durability and reliability. For specific warranty details, please refer to the warranty card included with your product or visit the official Pabobo website.


• Spare Parts Availability: Spare parts are available for 1 year from the date of purchase.

• **Customer Support:** For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Pabobo customer support through their official website or the retailer where the product was purchased.


© 2024 Pabobo. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents - CK0042-KSCE-WHITE



Documents - Pabobo - CK0042-KSCE-WHITE



Kid Sleep Essential Sleeptrainer User Manual

Comprehensive guide to setting up and using the Pabobo Kid Sleep Essential sleeptrainer and night light, including programming, modes, and safety information. lang:fr score:31 filesize: 951.11 K page_count: 9 document date: 2025-05-15