

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Gourmia](#) /

› [Gourmia 2.2 Qt Compact Air Fryer GAF236W Instruction Manual](#)

Gourmia GAF236

Gourmia 2.2 Qt Compact Air Fryer GAF236W Instruction Manual

Model: GAF236W

IMPORTANT SAFEGUARDS

Before using your Gourmia Air Fryer, please read all instructions thoroughly to ensure safe and optimal operation. Keep this manual for future reference.

- Always place the appliance on a stable, heat-resistant surface.
- Do not immerse the cord, plug, or the appliance itself in water or other liquids.
- Supervise children closely when the appliance is in use.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before handling parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the appliance manufacturer, as this may cause injuries.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for anything other than its intended use.
- Ensure the basket is properly inserted before operating.

PRODUCT OVERVIEW

The Gourmia 2.2 Qt Compact Air Fryer GAF236W is designed for efficient and healthy cooking using FryForce 360° Technology.



Figure 1: The Gourmia 2.2 Qt Compact Air Fryer in white, shown with its basket pulled out containing cooked french fries.

Components:

- Main Unit
- Removable Fry Basket
- Crisper Tray
- Temperature Control Knob
- Timer Knob



Figure 2: The removable fry basket with its handle and the separate crisper tray, both designed for easy cleaning.

SETUP

Follow these steps before first use:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Thoroughly clean the fry basket and crisper tray with hot water, dish soap, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a damp cloth.
4. Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances, ensuring at least 4 inches of clear space on all sides.

OPERATING INSTRUCTIONS

Basic Operation:

1. Place the crisper tray inside the fry basket.
2. Add ingredients to the fry basket. Do not overfill.
3. Slide the fry basket back into the air fryer.
4. Plug the air fryer into an electrical outlet.
5. Turn the temperature control knob to your desired temperature (200°F to 400°F).
6. Turn the timer knob to your desired cooking time (up to 60 minutes). The air fryer will begin heating.
7. Some recipes may require shaking ingredients halfway through cooking. To do this, pull out the basket, shake, and reinsert. The air fryer will resume cooking.
8. When the timer reaches zero, the air fryer will automatically shut off. Carefully remove the basket and transfer food to a serving dish.



Figure 3: The Gourmia 2.2 Qt Compact Air Fryer in use, with its basket containing crispy fried chicken.

Temperature and Time Settings:

The air fryer features two mechanical knobs for precise control:

- **Temperature Knob:** Adjusts cooking temperature from 200°F to 400°F.
- **Timer Knob:** Sets cooking duration up to 60 minutes with an automatic shut-off feature.

COOKING GUIDELINES

For best results, consider the following tips:

- Preheat the air fryer for 3-5 minutes before adding ingredients for optimal crispiness.
- For even cooking, shake or flip smaller items halfway through the cooking process.
- Lightly spray food with oil for a crispier texture, especially for fresh ingredients.
- Avoid overcrowding the basket to allow hot air to circulate effectively. Cook in batches if necessary.
- Adjust cooking times and temperatures based on food quantity and desired doneness.

CARE AND MAINTENANCE

Cleaning the Air Fryer:

1. Unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the fry basket and crisper tray. These parts are dishwasher safe for convenient cleaning.
3. For manual cleaning, wash the basket and tray with hot water, dish soap, and a non-abrasive

sponge.

4. Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
5. Ensure all parts are thoroughly dry before reassembling and storing.

Storage:

Store the air fryer in a cool, dry place when not in use. Ensure it is clean and dry before storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded electrical outlet.
Food is not cooked evenly.	Basket is overcrowded; food not shaken.	Cook in smaller batches. Shake the basket halfway through cooking.
Food is not crispy.	Not enough oil; temperature too low.	Lightly spray food with oil. Increase temperature or cooking time.
White smoke coming from appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and crisper tray thoroughly. Remove excess oil from food.


PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	GAF236W
Capacity	2.2 Quarts
Wattage	1000 watts
Max Temperature	400°F (200°C)
Control Method	Knob (Temperature & Timer)
Non-Stick Coating	Yes
Dishwasher Safe Parts	Basket and Crisper Tray
Dimensions	13 x 12.75 x 10 inches
Item Weight	6.39 pounds

WARRANTY AND CUSTOMER SUPPORT

Gourmia products are manufactured to the highest standards. For any questions, technical assistance, or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official Gourmia website. Please retain your proof of purchase for warranty validation.

Related Documents - GAF236

 USER MANUAL RECIPES COOKING CHART GAF222	<p>Gourmia GAF222 Compact Air Fryer User Manual, Recipes, and Cooking Chart</p> <p>Comprehensive user manual for the Gourmia GAF222 Compact Air Fryer, including operating instructions, safety guidelines, troubleshooting tips, recipes, and a detailed cooking chart.</p>
 USER MANUAL GAF236	<p>Gourmia 2 Qt Compact Air Fryer User Manual (Model GAF236)</p> <p>Comprehensive user manual for the Gourmia 2 Qt Compact Air Fryer (Model GAF236), covering important safeguards, operating instructions, cooking tips, cleaning, troubleshooting, and warranty information.</p>
 User Manual GAF1290 All-In-One Air Fryer	<p>Gourmia GAF1290 All-In-One Air Fryer User Manual</p> <p>Comprehensive user manual for the Gourmia GAF1290 All-In-One Air Fryer, covering setup, operation, cooking presets, probe usage, rotisserie, cleaning, troubleshooting, and warranty information.</p>
 User Manual GAF858 8-QT / 7.6 L Digital Air Fryer	<p>Gourmia 8-QT / 7.6 L Digital Air Fryer User Manual</p> <p>This user manual provides comprehensive instructions for the Gourmia 8-QT / 7.6 L Digital Air Fryer (Model GAF858), covering setup, operation, cleaning, maintenance, troubleshooting, and warranty information. Learn how to use the control panel, select settings, and prepare various foods with this versatile kitchen appliance.</p>
	<p>Gourmia GPC-800 Air Fryer User Manual and Operating Guide</p> <p>Comprehensive user manual for the Gourmia GPC-800 air fryer, covering safety precautions, setup, operation, cleaning, maintenance, troubleshooting, and specifications. Learn how to use your Gourmia GPC-800 for delicious, healthy cooking.</p>
	<p>Gourmia GAF798 Air Fryer: Recipes and Cooking Guide</p> <p>Unlock the full potential of your Gourmia GAF798 Air Fryer with this recipe book and cooking chart. Featuring 30 unique recipes for breakfast, main courses, vegetables, snacks, and desserts, plus essential cooking charts for air frying and dehydrating.</p>

