

[Manuals.plus](#) /

> [ZAFRO](#) /

> ZAFRO 27-Quart 14-in-1 Air Fryer Oven Instruction Manual

## ZAFRO 27Qt 14-in-1 Air Fryer Oven

# ZAFRO 27-Quart 14-in-1 Air Fryer Oven Instruction Manual

Model: 27Qt 14-in-1 Air Fryer Oven

## 1. IMPORTANT SAFEGUARDS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating this appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls and other appliances to allow for proper air circulation.

## 2. PRODUCT OVERVIEW

---

The ZAFRO 27-Quart 14-in-1 Air Fryer Oven is a versatile kitchen appliance designed for air frying, roasting, dehydrating, and more. It features a large capacity and multiple preset functions for convenient cooking.

## Components and Accessories

- Main Air Fryer Oven Unit
- Baking Plate
- Rotisserie Fork Set
- Crumb Tray (removable)
- User Manual
- Recipe Book



Image: The ZAFRO Air Fryer Oven shown with its primary accessories, including the baking plate and rotisserie fork set.

### 3. BEFORE FIRST USE (SETUP)

1. **Unpack the Appliance:** Carefully remove all packaging materials, stickers, and labels from the air fryer oven and its accessories.
2. **Clean Components:** Wash the baking plate, rotisserie fork set, and crumb tray in warm, soapy water. Rinse thoroughly and dry completely. Wipe the interior and exterior of the main unit with a damp cloth.

3. **Placement:** Place the air fryer oven on a stable, level, and heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space on all sides and above the appliance for proper ventilation. Do not place it directly against a wall or under cabinets.
4. **Initial Burn-Off:** Before cooking food, run the appliance empty for approximately 15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor or smoke may be present during this initial use; this is normal. Ensure the area is well-ventilated.

## 4. OPERATING INSTRUCTIONS

---

### Control Panel Overview




Image: Detailed view of the ZAFRO Air Fryer Oven's digital control panel, highlighting various buttons and their functions.

- **Time/Temp Setting Dial:** Used to adjust cooking time and temperature.
- **Light Button:** Activates the interior light to monitor cooking progress.
- **Rotation Button:** Engages the rotisserie function for even cooking.
- **LED Display:** Shows current time, temperature, and selected preset.
- **Air Fry Button:** Selects the air frying mode.
- **Oven Button:** Selects the conventional oven mode.
- **Start/Cancel Button:** Initiates or stops the cooking process.
- **Function Dial:** Used to select from the 14 preset cooking functions.

### Basic Operation

1. **Power On:** Plug the appliance into a grounded electrical outlet. The display will illuminate.
2. **Select Function:** Use the Function Dial to choose a desired cooking preset (e.g., French fries, Chicken, Bake). Alternatively, press the 'Air Fry' or 'Oven' button for manual mode.
3. **Adjust Time and Temperature:** If using manual mode or adjusting a preset, use the Time/Temp Setting Dial to set the desired cooking time (1-60 minutes) and temperature (180°F to 400°F).
4. **Start Cooking:** Press the 'Start/Cancel' button to begin the cooking process.

5. **Monitor Cooking:** Use the 'Light' button to check food without opening the door.

6. **Stop Cooking:** Press the 'Start/Cancel' button again to pause or stop cooking. Unplug the appliance when finished.

## Using Preset Functions

The ZAFRO Air Fryer Oven includes 14 one-touch presets for common dishes:

- French Fries
- Ribs
- Shrimp
- Cake
- Chicken Leg
- Steak
- Fish
- Bake
- Pizza
- Toast
- Bacon
- Dehydrate
- Defrost

To use a preset, simply turn the Function Dial to select the desired icon on the display, then press 'Start/Cancel'. The appliance will automatically set the optimal time and temperature for that dish. You can adjust these settings manually after selecting a preset if needed.



Image: The control panel showing icons for different food presets, illustrating the appliance's versatility.

## Using the Rotisserie Function

The rotisserie function is ideal for cooking whole chickens or roasts, ensuring even browning and crispiness.

1. Secure the food onto the rotisserie spit according to the recipe.
2. Insert the rotisserie spit into the designated slots inside the oven.
3. Select the appropriate cooking function and set time/temperature.
4. Press the 'Rotation' button to activate the rotisserie mechanism.
5. Press 'Start/Cancel' to begin cooking.

## 5. COOKING GUIDELINES

---

For optimal results, consider the following general guidelines:

- **Preheating:** For best results, preheat the air fryer oven for 3-5 minutes before adding food.
- **Oil Usage:** While air frying uses significantly less oil than traditional deep frying, a light coating of oil on some foods can enhance crispiness and flavor.
- **Shaking/Flipping:** For even cooking, especially with smaller items like fries or wings, shake the basket or flip the food halfway through the cooking time.
- **Doneness:** Always ensure food is cooked to a safe internal temperature. Cooking times may vary based on food quantity, density, and desired crispiness.
- **Temperature Range:** The appliance operates within a temperature range of 180°F to 400°F.
- **Time Range:** Cooking times can be set from 1 to 60 minutes.

Refer to the included recipe book for specific cooking times and temperatures for various dishes.

## 6. CLEANING AND MAINTENANCE

---

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. **Before Cleaning:** Always unplug the air fryer oven from the power outlet and allow it to cool completely before cleaning.
2. **Cleaning Accessories:** The baking plate, rotisserie fork set, and crumb tray are nonstick. Wash them in warm, soapy water using a non-abrasive sponge. Rinse and dry thoroughly. **Note:** These accessories are **not** dishwasher safe.
3. **Cleaning the Interior:** Wipe the interior of the oven with a damp cloth and a mild detergent. For stubborn food residue, a non-abrasive sponge can be used. Ensure the interior is completely dry before next use.
4. **Cleaning the Exterior:** Wipe the exterior surface with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
5. **Storage:** Once clean and dry, store the appliance and its accessories in a cool, dry place.



Image: A person cleaning the interior of the air fryer oven with a cloth, demonstrating easy maintenance.

## 7. TROUBLESHOOTING

---

If you encounter issues with your ZAFRO Air Fryer Oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance fault.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker. If the issue persists, contact customer support.
Food is not cooking evenly.	Overcrowding; insufficient shaking/flipping; incorrect temperature/time.	Do not overcrowd the cooking area. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Grease residue from previous use; fatty foods cooking.	Clean the appliance thoroughly after each use. For fatty foods, place a small amount of water in the crumb tray to reduce smoke.
Food is not crispy.	Too much moisture; not enough oil; overcrowding.	Pat food dry before cooking. Lightly brush or spray with oil. Cook in smaller batches.

## 8. PRODUCT SPECIFICATIONS

---

Detailed specifications for the ZAFRO 27-Quart 14-in-1 Air Fryer Oven:

- **Capacity:** 27 Quarts
- **Wattage:** 1000 watts
- **Temperature Range:** 180°F to 400°F (82°C to 204°C)
- **Timer Range:** 1 to 60 minutes
- **Material:** Stainless Steel (Inner Material), Aluminum (Outer Material)
- **Control Method:** Touch Control

- **Nonstick Coating:** Yes (on accessories)
- **Dishwasher Safe:** No (for accessories)
- **Recommended Uses:** Roast, Dehydrate, Air Fry



Image: The ZAFRO Air Fryer Oven with key dimensions indicated, showing its compact design.

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or contact ZAFRO customer support. If you have any questions, require assistance, or need to report a problem, please reach out to the manufacturer's customer service department. Contact details can typically be found on the product packaging or the official ZAFRO website.