

[Manuals.plus](#) /

> [MOEO](#) /

> MOEO Folding Electric Treadmill User Manual

MOEO MOEO Foldable Electric Treadmill

MOEO Folding Electric Treadmill User Manual

Model: MOEO Foldable Electric Treadmill

INTRODUCTION



Figure 0: MOEO Folding Electric Treadmill in use and folded for storage.

This user manual provides essential information for the safe and effective operation, setup, and maintenance of your MOEO Folding Electric Treadmill. Designed for home use, this treadmill combines performance and comfort with a space-saving foldable design, making it ideal for any living space.

Please read this manual thoroughly before using the treadmill and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of serious injury, read all instructions before using the MOEO Folding Electric Treadmill.

- Always attach the safety key clip to your clothing before starting the treadmill. The treadmill will stop

immediately if the safety key is dislodged.

- Keep children and pets away from the treadmill at all times.
- Place the treadmill on a solid, level surface with at least 2 feet of clear space behind it.
- Do not operate the treadmill if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Wear appropriate athletic footwear and clothing. Do not use the treadmill barefoot.
- Do not exceed the maximum user weight capacity of 220 LBS (100 kg).
- Consult a physician before beginning any exercise program.
- Unplug the treadmill from the power outlet when not in use, before cleaning, or before performing any maintenance.

SETUP AND ASSEMBLY

The MOEO Folding Electric Treadmill is designed for minimal assembly, allowing for quick setup.



Figure 1: Treadmill folding design for easy storage and no assembly required.

1. **Unpacking:** Carefully remove the treadmill from its packaging.
2. **Unfolding:** The treadmill comes pre-assembled. To unfold, simply rotate the knob to release the locking mechanism and lower the running deck into position. Ensure it clicks securely into place.
3. **Placement:** Place the treadmill on a flat, stable surface. Ensure there is adequate space around the unit for safe operation and access.
4. **Power Connection:** Plug the power cord into a grounded 110V / 50Hz electrical outlet.

OPERATING INSTRUCTIONS

Control Panel and Display



Figure 2: Multi-functional LED Display and control panel.

The integrated LED display provides real-time feedback on your workout:

- **Time:** Duration of your workout.
- **Calorie:** Estimated calories burned.
- **Speed:** Current running speed (0.5-6.5 mph / 1-10 km/h).

- **Distance:** Total distance covered.
- **Step:** Number of steps taken.

The control panel also features buttons for starting/stopping, adjusting speed, and selecting programs. A convenient holder is provided for your mobile phone or tablet, allowing you to enjoy media during your workout.

Starting a Workout

1. Ensure the treadmill is plugged in and the safety key is properly inserted into its slot on the console.
2. Attach the safety key clip to your clothing.
3. Step onto the treadmill belt, placing your feet on the side rails.
4. Press the "Start" button. The treadmill will begin at a low speed.
5. Adjust the speed using the "+" and "-" buttons to your desired pace.

Using Preset Programs

The treadmill includes 12 pre-programmed workouts designed to vary speed and intensity. To select a program, press the "Program" button (or similar, based on typical treadmill controls) repeatedly until your desired program number is displayed. The treadmill will automatically adjust speed according to the program's profile.

Stopping a Workout

To stop the treadmill, press the "Stop" button. The belt will gradually slow down and come to a complete stop. In an emergency, pull the safety key from the console to immediately stop the treadmill.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your MOEO Folding Electric Treadmill.

- **Cleaning:** Wipe down the treadmill surfaces with a damp cloth after each use. Do not use abrasive cleaners or solvents.
- **Lubrication:** The running belt may require lubrication periodically (e.g., every 3-6 months depending on usage). Refer to the specific instructions for treadmill belt lubrication, typically involving lifting the belt and applying silicone lubricant to the deck.
- **Belt Adjustment:** If the running belt slips or drifts to one side, it may need adjustment. Use the provided Allen wrench to turn the rear roller bolts in small increments until the belt is centered and properly tensioned.
- **Storage:** When not in use, the treadmill can be easily folded for compact storage. Ensure the locking mechanism is engaged before moving or storing.

TROUBLESHOOTING

If you encounter issues with your treadmill, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Treadmill does not start.	Power cord not plugged in; Safety key not inserted; Circuit breaker tripped.	Ensure power cord is securely plugged in. Insert safety key fully. Check household circuit breaker.
Running belt slips.	Belt too loose; Belt needs lubrication.	Adjust belt tension (refer to Maintenance section). Lubricate the running deck.

Problem	Possible Cause	Solution
Treadmill makes unusual noise.	Loose components; Motor issue; Belt friction.	Check for loose bolts and tighten. If noise persists, contact customer support. Lubricate belt if friction is suspected.
Display not working.	Loose connection; Power issue.	Check all cable connections. Ensure power supply is stable.

If the problem persists after attempting these solutions, please contact MOEO customer support.

SPECIFICATIONS



Figure 3: Treadmill dimensions (unfolded and folded).

Feature	Detail
Brand	MOEO

Feature	Detail
Model Name	MOEO Foldable Electric Treadmill
Motor Power	1.5 HP
Speed Range	0.5 - 6.5 mph (1 - 10 km/h)
Running Surface (L x W)	41.3" x 14.9"
Unfolded Size (L x W x H)	49.2" x 25.5" x 45.6"
Folded Size (L x W x H)	51.1" x 25.5" x 7.9"
Maximum User Capacity	220 LBS
Rated Voltage	110V / 50Hz
Display Type	LED
Number of Programs	12 Preset Programs
Material	Alloy Steel
Color	Black
Input Power	220 Watts



Figure 4: Spacious running surface with shock-absorbing layers.

Powerful & Smooth Motor



1.5 HP Motor



Energy Saving



Low Noise



220LBS Capacity



Figure 5: Powerful and smooth 1.5 HP motor.

WARRANTY AND SUPPORT

The product information indicates that there is no specific warranty description provided. For any product-related inquiries, technical support, or assistance with your MOEO Folding Electric Treadmill, please contact MOEO customer service directly through their official channels or the retailer from whom you purchased the product. Please have your model name (MOEO Foldable Electric Treadmill) and any purchase details ready when contacting support.