

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Odokee](#) /

› [Odokee Digital Dual Alarm Clock \(Model UE218-Wood-1\) Instruction Manual](#)

Odokee UE218-Wood-1

Odokee Digital Dual Alarm Clock Instruction Manual

Model: UE218-Wood-1

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Odokee Digital Dual Alarm Clock, Model UE218-Wood-1. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Figure 1: Odokee Digital Dual Alarm Clock (Model UE218-Wood-1)

2. PRODUCT FEATURES

- **Easy Setup & Dimmable Display:** Intuitive controls with clearly labeled buttons. Large 1.6-inch white LED digits with 0-100% adjustable brightness via a dimmer dial.
- **Customizable Dual Alarms:** Set two independent alarms with 7-5-2 alarm modes (every day, weekdays, or weekends).
- **5 Alarm Sounds:** Choose from Beep, Birds Chirping, Buzzer, Soft Music, or Siren. Alarm volume is adjustable from 30dB to 110dB.
- **Easy Snooze:** A large, accessible snooze button provides an additional 9 minutes of rest.
- **USB Charging Port:** Integrated USB port for charging mobile devices.
- **Battery Backup:** Requires 3 AAA batteries (not included) to maintain time and alarm settings during power outages.
- **Time Display:** Supports both 12-hour and 24-hour time formats.

3. SETUP

3.1 Power Connection

1. Connect the provided AC adapter to the DC 5V input port on the back of the alarm clock.

2. Plug the AC adapter into a standard wall outlet. The display will light up.



Figure 2: Powering the Alarm Clock

3.2 Battery Backup Installation

For battery backup functionality, install 3 AAA batteries (not included) into the battery compartment located on the bottom of the clock. This ensures time and alarm settings are retained during a power outage. Note that the display will not remain continuously lit and the USB charging port will not function when operating solely on battery backup.

4. OPERATING INSTRUCTIONS

Dial Controls & Easy to Setup

Easily customize brightness/volume & Single button for single function makes setup very easy




Figure 3: Rear Controls Overview

4.1 Setting the Time

1. Press and hold the **TIME SET** button on the back of the clock. The hour digits will begin to flash.
2. Use the **HOUR** and **MIN** buttons on the top of the clock to adjust the hour and minute respectively.
3. Press **TIME SET** again to confirm the time.
4. To set the day of the week, press the **DAY OF WEEK** button repeatedly until the correct day is displayed.

4.2 12/24 Hour Format

Press the **12/24HR** button on the back of the clock to switch between 12-hour (with AM/PM indicator) and 24-hour time formats.



Figure 4: 12-Hour vs. 24-Hour Display

4.3 Setting Alarms (Alarm 1 & Alarm 2)

The clock features two independent alarms. The setup process is identical for both.

1. Press and hold the **ALARM 1 SET** or **ALARM 2 SET** button. The alarm hour digits will flash.
2. Use the **HOUR** and **MIN** buttons to set the desired alarm time.
3. Press the respective **ALARM SET** button again to confirm the time.
4. Next, the alarm mode will flash. Use the **ALARM SOUND** button to cycle through the 7-5-2 alarm modes:
 - **SAT-SUN:** Weekend alarm (Saturday and Sunday only).
 - **MON-FRI:** Weekday alarm (Monday to Friday only).
 - **MON-SUN:** All 7 days alarm.
5. Press the respective **ALARM SET** button again to confirm the alarm mode.
6. To activate or deactivate an alarm, press the **ON/OFF** button located on the front side of the clock corresponding to Alarm 1 or Alarm 2. An alarm icon (1 or 2) will appear on the display when active.

Dual Alarms with 7-5-2 Alarm Modes

Set two separate alarms for different schedules & Each alarm can be programmed for different alarm modes

SAT-SUN
Weekends

MON-FRI
Weekdays

MON-SUN
All 7 days




Figure 5: Dual Alarms with 7-5-2 Modes



Figure 6: Alarm 1 and Alarm 2 Indicators

4.4 Selecting Alarm Sounds

After setting the alarm time and mode, you can select one of five alarm sounds:

1. During alarm setting, after confirming the alarm mode, the current alarm sound will flash.
2. Press the **ALARM SOUND** button repeatedly to cycle through the available sounds: Beep, Birds Chirping, Buzzer, Soft Music, or Siren.
3. Press the respective **ALARM SET** button to confirm your selection.



5 Selectable Alarm Sounds

Wake up to your favorite sound



30dB



110dB

Adjustable Alarm Volume(30dB-110dB)

Figure 7: Selectable Alarm Sounds

4.5 Adjusting Alarm Volume

The alarm volume can be adjusted from 30dB (low) to 110dB (high) using the **VOLUME** dial located on the left side of the clock.

4.6 Snooze Function

When an alarm sounds, press the large **SNOOZE** button on the top of the clock to temporarily silence the alarm for 9 minutes. The alarm will sound again after 9 minutes.



**Easy Snooze
& Easy to Turn on/off 2 Alarms**

Simply press the large snooze button for 9 minutes extra rest and the two easy-to-reach front buttons turn off the alarms even when half-asleep

Figure 8: Using the Snooze Function

4.7 Adjusting Display Brightness (Dimmer)

The display brightness can be adjusted from 0% (fully dark) to 100% (very bright) using the **DIMMER** dial located on the right side of the clock.



Large Numbers with 0-100% Adjustable Dimmer

Easily customize the most comfortable brightness for optimal visibility



Figure 9: Display Brightness Adjustment

4.8 USB Charging Port

A USB charging port is located on the back of the clock. Connect your mobile device's USB cable to this port to charge it. This port is active only when the clock is powered by the AC adapter.



Figure 10: USB Charging Port in Use

5. BATTERY BACKUP FUNCTIONALITY

The battery backup feature requires 3 AAA batteries (not included). When AC power is interrupted, the batteries will preserve the time and alarm settings. The display will turn off to conserve battery power, but the internal clock will continue to run, and alarms will still activate at the set time. The USB charging port will not function during battery backup mode. It is recommended to use the battery backup only for power outage situations, as continuous use on batteries will drain them quickly.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or not lighting up.	No power, power outage, or dimmer set to 0%.	Ensure AC adapter is securely plugged in. Check power outlet. Adjust the DIMMER dial. If on battery backup, press any button to briefly illuminate the display.
Alarm does not sound.	Alarm not activated, volume too low, or incorrect alarm mode.	Ensure the alarm is activated (alarm icon visible). Adjust the VOLUME dial. Verify the alarm mode (7-5-2) is set correctly for the current day.
Time is incorrect.	Time not set correctly, or power interruption without battery backup.	Re-set the time using the TIME SET button. Install fresh AAA batteries for backup.
USB charging not working.	Clock is on battery backup, or cable/device issue.	Ensure the clock is connected to AC power. Try a different USB cable or device to rule out external issues.

7. SPECIFICATIONS

- **Brand:** Odokee
- **Model Number:** UE218-Wood-1
- **Display Type:** Digital LED (White)
- **Display Size:** 1.6 inches (digit height)
- **Product Dimensions:** 5.3"W x 2.9"H x 1.95"D (approximate, based on image a7e9cdcf-2bbb-4f2d-b58e-081cedcaeaaa)
- **Power Source:** Corded Electric (AC adapter included), 3x AAA batteries for backup (not included)
- **Alarm Sounds:** 5 selectable (Beep, Birds Chirping, Buzzer, Soft Music, Siren)
- **Alarm Volume:** Adjustable (30dB-110dB)
- **Display Brightness:** 0-100% adjustable dimmer
- **Snooze Duration:** 9 minutes
- **Time Format:** 12/24 hour selectable
- **Material:** Plastic (Acrylonitrile Butadiene Styrene)
- **Item Weight:** 6.3 ounces (178.6 Grams)





Figure 11: Product Dimensions


8. WARRANTY AND SUPPORT

Odokee products come with a hassle-free 18-month warranty. For any questions, issues, or warranty claims, please contact Odokee customer service. Odokee is dedicated to providing functional and stylish products and values customer feedback.

You can visit the official Odokee store for more information:[Odokee Store on Amazon](#).

Related Documents - UE218-Wood-1

 <p>Mode d'emploi Odokee UE218 : Configuration, Fonctionnalités et Dépannage Manuel d'utilisation complet pour le réveil Odokee UE218, couvrant la configuration, le réglage de l'heure, la configuration des alarmes, les options sonores, la fonction snooze, le contrôle de la luminosité, le mode sur piles, la charge USB et le dépannage.</p>
 <p>Odokee H03 Sunrise Alarm Clock & Sleep Sounds Machine User Manual Comprehensive user manual for the Odokee H03 All-in-One Sleep-Wake Solution, covering setup, time setting, alarm functions, sleep sounds, night light, Bluetooth connectivity, and troubleshooting.</p>
 <p>Odokee UE216-FM Digital Clock Radio User Manual Comprehensive user manual for the Odokee UE216-FM digital clock radio, covering setup, time setting, alarm functions, FM radio, night light, sleep timer, brightness control, battery operation, and troubleshooting.</p>
 <p>ODOKEE H03 User Manual - Alarm Clock and Bluetooth Speaker User manual for the ODOKEE H03, a bedside alarm clock with Bluetooth speaker, sleep timer, adjustable display, and nightlight. Includes setup, pairing, and operation instructions.</p>
 <p>Odokee H03 Sunrise Alarm Clock User Manual and Features Comprehensive user manual for the Odokee H03 Sunrise Alarm Clock Sound Machine. Learn how to set the time, alarms, sunrise simulation, night light, use Bluetooth, and sleep timer. Includes troubleshooting and warranty information.</p>



[Odokee UE268-QI User Manual: All-in-One Bedside Speaker with Wireless Charging](#)

Comprehensive user manual for the Odokee UE268-QI All-in-One Bedside Speaker, covering setup, features like alarm, FM radio, Bluetooth, wireless charging, and troubleshooting.