Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Tabtime /
- Tabtime Vibrating Alarm Reminder Watch User Manual

Tabtime Vibrating Watch Black Small

Tabtime Vibrating Alarm Reminder Watch User Manual

Model: Vibrating Watch Black Small Brand: Tabtime

INTRODUCTION

The Tabtime Vibrating Alarm Reminder Watch is designed to provide discreet, silent vibrating reminders throughout your day. Ideal for medication reminders, hydration alerts, potty training, or as a personal wake-up alarm, this watch ensures you stay on schedule without disturbing those around you. Its simple, two-button operation and comfortable design make it suitable for all ages and daily routines.





The Tabtime Vibrating Alarm Reminder Watch in black, showing the digital time.



The watch provides silent vibrations, ensuring only the wearer is alerted, perfect for shared sleeping spaces.

SETUP

Charging the Watch

The Tabtime Vibrating Alarm Reminder Watch features a built-in rechargeable battery. To charge:

- 1. Carefully remove the watch module from its silicone strap.
- 2. Connect the watch module to the included USB charging cable.
- 3. Plug the USB cable into any standard USB power source (e.g., computer, wall adapter).

A single charge typically powers the watch for 2-4 weeks, depending on the frequency of alarms set. It is recommended to charge weekly for optimal performance.



Fully rechargeable with the included USB cable Single charge powers it for 2–4 weeks use





Step 1: Remove the strap

Step 2: Plug into USB Port

Works with your usual power source



Steps for easy USB charging: remove the strap and plug into a USB port.

Setting the Time

The watch uses a simple two-button system for setting the time and alarms. To set the current time:

- 1. Press the right button to display the current time.
- 2. To change the time, hold down the right button for 3 seconds until the hour digits begin to flash.
- 3. Use the left and right buttons to adjust the hour.
- 4. Hold the right button for 3 seconds to confirm the hour.
- 5. The minute digits will now flash. Use the left and right buttons to adjust the minutes.
- 6. Hold the right button for 3 seconds to confirm the minutes and exit time setting mode.

OPERATING


The watch supports up to 10 personal vibrating alarms per day. To set an alarm:

- 1. Press the left button repeatedly to cycle through the alarm settings (A0 to A9).
- 2. Once you reach the desired alarm slot (e.g., A0), hold down the right button for 3 seconds until the hour digits begin to flash.
- 3. Use the left and right buttons to adjust the alarm hour.
- 4. Hold the right button for 3 seconds to confirm the hour.
- 5. The minute digits will now flash. Use the left and right buttons to adjust the alarm minutes.
- 6. Hold the right button for 3 seconds to confirm the minutes and activate the alarm.

The first alarm (A0) vibrates for 40 seconds. All subsequent alarms (A1-A9) vibrate for 20 seconds. To stop a vibrating alarm, press any button.

Typical Usage Scenarios

- Wake-Up Alarm: Set a silent vibrating alarm to wake you without disturbing others.
- Medication Reminders: Program multiple alarms to ensure you take your medication on time throughout the day.
- Hydration Reminders: Use alarms to remind yourself to drink water regularly.
- Potty Training: Set frequent reminders for children during potty training.
- Personal Reminders: Utilize for exercise, work breaks, or any other routine tasks.



The watch is versatile for various daily reminders, including waking up, taking medicine, personal tasks, and potty training.

MAINTENANCE

Cleaning and Care

To clean your Tabtime watch, gently wipe the silicone strap and watch module with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

Water Resistance

The Tabtime Vibrating Alarm Reminder Watch is **NOT water resistant**. Please ensure to remove the watch before showering, swimming, or engaging in any water-related activities to prevent damage.

TROUBLESHOOTING

Time is Inaccurate

If the time displayed on your watch is inaccurate even after adjustment, it is possible that an alarm was accidentally set instead of the current time. Follow the steps in the "Setting the Time" section to correctly set the time.

Watch Not Charging

Ensure the watch module is securely connected to the USB cable and the cable is plugged into a working USB power source. Try a different USB port or power adapter if issues persist. Verify that the watch module is correctly inserted into the charging cable's slot.

SPECIFICATIONS

Feature	Detail
Model Number	Vibrating Watch Black Small
Dimensions	10.2 x 4.65 x 0.83 inches
Weight	2.08 ounces
Battery	1 Lithium Ion battery (included)
Alarm Capacity	Up to 10 daily vibrating alarms
Strap Material	Silicone
Strap Sizes	Small (11-17 cm circumference), Large (16-22 cm circumference)
Country of Origin	China

Adjustable Fit for Every Wrist





Available in two sizes:

Small (11–17 cm) · Large (16–22 cm)

Comfortable and secure for all-day wear



The watch is available in two sizes to ensure an adjustable and comfortable fit for various wrist circumferences.



The watch is available in a variety of colors to suit personal preference.

WARRANTY AND SUPPORT

Warranty Information

The Tabtime Vibrating Alarm Reminder Watch comes with a 12-month product promise.

Customer Support

For additional support, setup videos, and frequently asked questions, please visit the official Tabtime website: amazon.com/tabtime.

You may also refer to the product packaging for manufacturer contact details and regulatory inquiries. UPC: 5060621950158



Product packaging displaying contact information and UPC for support.

© 2023 Tabtime. All rights reserved.

