

## CANMORE TW411

# CANMORE TW411 Golf GPS Watch Instruction Manual

Model: TW411 | Brand: CANMORE

## 1. INTRODUCTION

---

Welcome to the instruction manual for your CANMORE TW411 Golf GPS Watch. This device is designed to enhance your golf experience with precise GPS distances and integrated fitness tracking features. This manual provides comprehensive guidance on setting up, operating, maintaining, and troubleshooting your watch to ensure optimal performance and longevity.



Figure 1.1: The CANMORE TW411 Golf GPS Watch, showing a golf course layout with distances to the front, middle, and back of the green.

## 2. PRODUCT OVERVIEW

---

### 2.1 Key Features

- **Worldwide Course Database:** Preloaded with over 41,000 golf courses globally, with free weekly updates available.
- **Precise Golf Distances:** Provides accurate distances to the front, middle, and back of the green, shot distance measurement, and hazard distances.

- **Automatic Hole Progression:** Automatically changes holes as you play.
- **Integrated Fitness Tracker:** Includes functions such as pedometer, bubble meter, and alarm.
- **Enhanced Performance:** Features faster GPS acquisition, more accurate locating, 50% longer battery life, and an upgraded processor IC compared to previous models.
- **Durable Design:** Breathable, durable, and sweat-proof rubber wristband with a full ABS case and scratch-resistant screen.
- **High Visibility Display:** 1.36-inch wide surface LCD screen designed for high-contrast readability under various lighting conditions.
- **Lightweight:** Weighs only 52g, ensuring it does not interfere with your swing.
- **Lifetime Service:** Free weekly course updates and troubleshooting support with no subscription fees.

## 2.2 Components

The CANMORE TW411 Golf GPS Watch package typically includes:

- CANMORE TW411 Golf GPS Watch
- USB Charging Cable (with magnetic contacts)
- User Manual (this document)
- Lithium Polymer Battery (pre-installed)



Figure 2.1: The high-resolution display of the TW411 watch, ensuring clear readability.

# Long Battery Life

Up to 60 days in time mode, and 14 hours in GPS mode, keep up with your pace at any time.



**Up to 60 days**  
(Time mode)

**Up to 14 hours**  
(GPS mode)

Figure 2.2: The TW411 watch demonstrating its high visibility screen, even in bright sunlight conditions.

## 3. SETUP

---

### 3.1 Initial Charging

Before first use, fully charge your CANMORE TW411 watch. Connect the provided USB charging cable to the watch's charging contacts and a 5V USB power source. Ensure the magnetic contacts are properly aligned. Charging at higher voltages may damage the battery. A full charge typically takes a few hours.

**Important:** Only use a 5V USB power source for charging. Avoid disturbing the watch during charging to maintain proper contact.

### 3.2 Course Map Updates

To ensure the most accurate course data, it is recommended to regularly update the course maps. Course data is updated every two weeks. You can update your watch via USB connection on Windows, Mac, or Linux operating systems.

Refer to the Quick Start Guide included with your product for detailed instructions and links to the CANMORE website for updates and email subscription for update notifications.




Figure 3.1: The TW411 comes with over 40,000 preloaded courses, with weekly updates available.

### 3.3 Initial GPS Location

For the watch to acquire a GPS signal, ensure you are in an open area with no obstructions. Any coverage or hindrance may affect the GPS signal acquisition. Once powered on, the watch will automatically search for available satellites to determine your location and identify nearby golf courses.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Golf Mode

The TW411 automatically detects the course you are playing on and displays relevant information. Use the physical buttons on the watch to navigate through different screens and functions.

- **Green Distances:** The main screen displays distances to the front (F), middle (M), and back (B) of the green.
- **Shot Distance:** Measure the distance of your shots by marking your starting point and walking to your ball.
- **Hazard Distances:** View distances to various hazards on the course.
- **Automatic Hole Advance:** The watch will automatically advance to the next hole as you complete each one.



Figure 4.1: Display showing distances to the front, middle, and back of the green.

# High Visibility Under Sunlight



Figure 4.2: Screen indicating shot distance measurement in yards.



# Daily Activity



Figure 4.3: Display showing distances to various hazards on a golf hole.

## 4.2 Fitness Tracking

Beyond golf, the TW411 also functions as a fitness tracker:

- **Pedometer:** Tracks your daily steps.
- **Distance & Calories:** Estimates distance walked and calories burned.
- **Alarm:** Set alarms for various reminders.
- **Bubble Meter:** A digital level for precise alignment.

# High Resolution



Figure 4.4: The watch tracking daily activity including distance, steps, and calories burned.

## 4.3 Changing Units

The default display unit is yards. To change the unit to meters, navigate to "Setting > Unit" on your watch and select your preferred measurement unit.

## 5. MAINTENANCE

---

### 5.1 Cleaning

Regularly clean the charging connectors with a soft brush and cloth to prevent sweat and dirt buildup, which can affect charging performance. Clean the watch after exposure to sweat and dirt to maintain its condition.

### 5.2 Storage

Although the watch is IPX7 rated waterproof, for best performance and longevity, store the product in a cool, dry place

when not in use.

### 5.3 Battery Care

Always charge the watch using only a 5V USB power source. Charging at higher voltages can damage the internal battery. The watch features a long battery life, up to 60 days in time mode and 14 hours in GPS mode.



Figure 5.1: Battery life details for the TW411, showing up to 60 days in time mode and 14 hours in GPS mode.

## 6. TROUBLESHOOTING

---

### 6.1 GPS Signal Issues

- **"---" Display:** If the distance measurement displays "---" instead of figures, connect the watch to power and recharge it. Low battery levels can initiate a power reserve mode, reducing GPS range and preventing accurate

position location.

- **Signal Acquisition:** Ensure you are in an open area without obstructions when trying to acquire a GPS signal.

## 6.2 Charging and Power Issues

- **Not Charging:** Verify that the charging cable's magnetic contacts are clean and properly aligned with the watch's charging ports. Ensure the USB power source is 5V.
- **Sudden Shutdown:** If the watch shuts down unexpectedly, ensure it is fully charged. If issues persist, contact customer support.

## 6.3 General Operation

- **Unresponsive Buttons:** Ensure the watch is not in a locked mode. If unresponsive, try a soft reset (refer to the Quick Start Guide for specific instructions).

## 7. SPECIFICATIONS

---

Feature	Detail
Model Name	TW411
Brand	CANMORE
Item Weight	54 Grams (1.9 ounces)
Product Dimensions	1.85 x 1.85 x 0.57 inches
Display Size	1.36 Inches
Battery Type	1 Lithium Polymer battery (included)
Connectivity Technology	USB
Waterproof Rating	IPX7
Map Type	Worldwide (41,000+ preloaded courses)
Memory Storage Capacity	64 MB
Mounting Type	Wrist Mount

## 8. WARRANTY AND SUPPORT

---

CANMORE offers a "One Time Purchase, Lifetime Service" commitment for the TW411 Golf GPS Watch. This includes:

- Free weekly course updates with no subscription fees.
- Troubleshooting assistance for GPS connection, charging, shutdown, and other operational issues.
- Regular firmware updates to ensure your device has the latest features and improvements.

For further support, detailed information, or to access updates, please visit the official CANMORE website. You can also subscribe to email notifications for the latest product information and course updates.




Figure 8.1: CANMORE's commitment to lifetime service and support for their products.