

[Manuals.plus](#) /

> [Hisense](#) /

> Hisense 4.4 Cu. Ft. Freestanding Compact Refrigerator User Manual

## Hisense RR44D6ASE

# Hisense 4.4 Cu. Ft. Freestanding Compact Refrigerator

Model: RR44D6ASE

## IMPORTANT SAFETY INFORMATION

---

Read all instructions before using this appliance to reduce the risk of fire, electric shock, or injury to persons.

- **Electrical Safety:** Ensure the refrigerator is connected to a properly grounded outlet. Do not use extension cords or ungrounded adapters. Disconnect power before cleaning or servicing.
- **Flammable Refrigerant:** This appliance contains R-600A, a flammable refrigerant. Handle with care during transportation and installation to avoid damage to the refrigerant circuit. Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Ventilation:** Maintain adequate ventilation around the appliance to prevent overheating and ensure proper operation. Do not block ventilation openings.
- **Child Entrapment:** Old refrigerators are dangerous. Before you throw away your old refrigerator or freezer, take off the doors and leave the shelves in place so that children may not easily climb inside.
- **Cleaning:** Always unplug the refrigerator before cleaning. Use only mild, non-abrasive cleaners.

## PRODUCT OVERVIEW

---

The Hisense 4.4 Cu. Ft. Freestanding Compact Refrigerator is designed for efficient cooling in smaller spaces. It features a single door, adjustable temperature control, and wire shelving.



*Figure 1: Front view of the Hisense 4.4 Cu. Ft. Freestanding Compact Refrigerator.*

This image shows the Hisense 4.4 Cu. Ft. Freestanding Compact Refrigerator from the front. It features a sleek stainless silver finish with the Hisense logo subtly embossed near the top. The design is compact and freestanding, suitable for various small spaces.

## SETUP AND INSTALLATION

---

- 1. Unpacking:** Carefully remove all packaging materials, including foam and adhesive tape. Keep packaging materials out of reach of children.
- 2. Location:**
  - o Place the refrigerator on a firm, level floor that can support its weight when fully loaded.
  - o Allow at least 4 inches (10 cm) of space between the back and sides of the refrigerator and any adjacent walls or cabinets for proper air circulation.
  - o Avoid placing the appliance in direct sunlight or near heat sources like stoves, heaters, or radiators.
  - o The optimal ambient temperature for operation is between 50°F (10°C) and 109°F (43°C).
- 3. Leveling:** Adjust the leveling feet at the bottom front of the refrigerator to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.
- 4. Electrical Connection:** Plug the refrigerator into a dedicated, grounded 115V, 60Hz AC outlet. Do not use an adapter or extension cord.
- 5. Initial Cleaning:** Before first use, wipe the interior and exterior with a soft cloth dampened with a mild detergent

solution. Dry thoroughly.

6. **Initial Operation:** After plugging in, allow the refrigerator to operate for at least 2-3 hours before placing food inside to ensure it reaches the desired temperature.

## OPERATING INSTRUCTIONS

---

### Temperature Control

The temperature control dial is located inside the refrigerator compartment. It typically ranges from "1" (warmest) to "7" (coldest), with "4" or "5" being the recommended setting for normal use.

- Turn the dial to a higher number for colder temperatures.
- Turn the dial to a lower number for warmer temperatures.
- Allow several hours for the temperature to stabilize after adjusting the control.

### Food Storage

- Do not overload the refrigerator, as this can restrict airflow and reduce cooling efficiency.
- Store food in sealed containers to prevent odors and maintain freshness.
- Avoid placing hot food directly into the refrigerator; allow it to cool to room temperature first.

### Defrosting

This compact refrigerator may require manual defrosting. When frost accumulation on the evaporator reaches about 1/4 inch (6 mm) thick, defrost the unit.

1. Unplug the refrigerator from the power outlet.
2. Remove all food items and place them in a cooler or another refrigerated space.
3. Leave the door open to allow frost to melt naturally. You can place towels at the bottom to absorb water.
4. Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.
5. Once defrosted, clean and dry the interior thoroughly before plugging it back in and returning food.

## MAINTENANCE AND CARE

---

### Cleaning the Interior

- Unplug the refrigerator before cleaning.
- Wash the interior surfaces with a solution of two tablespoons of baking soda to one quart of warm water.
- Rinse with clean water and dry with a soft cloth.
- Clean removable parts like shelves and door bins in warm soapy water, rinse, and dry.

### Cleaning the Exterior

- Wipe the exterior with a clean, soft cloth dampened with mild detergent and water.
- For stainless steel finishes, use a stainless steel cleaner and polish, wiping in the direction of the grain.
- Clean the door gasket regularly to ensure a proper seal. Use warm soapy water and dry thoroughly.

### Power Outage

In case of a power outage, keep the refrigerator door closed as much as possible to maintain internal temperature. Food should remain safely chilled for several hours. Discard perishable food if the power outage is prolonged.

### Vacation Care

- **Short Vacations:** Leave the refrigerator operating normally.
- **Long Vacations:** If the refrigerator will not be used for an extended period, unplug it, empty all food, defrost (if applicable), clean the interior, and leave the door slightly ajar to prevent odors and mold growth.

## TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; power outage.	Check power cord connection; reset circuit breaker; check household power supply.
Temperature is too warm.	Temperature control set too high; door opened too frequently; warm food placed inside; poor ventilation.	Adjust temperature control to a colder setting; minimize door openings; allow hot food to cool; ensure adequate clearance around the unit.
Excessive frost buildup.	Door not sealed properly; high humidity; frequent door openings.	Check door gasket for damage or obstruction; ensure door closes completely; reduce frequency of door openings. Defrost as needed.
Unusual noises.	Unit not level; objects vibrating against the unit; normal operating sounds.	Adjust leveling feet; ensure nothing is touching the back or sides; gurgling/hissing sounds are normal refrigerant flow.
Door does not close completely.	Unit not level; door gasket dirty or damaged; shelves/bins out of place.	Level the unit; clean or inspect door gasket; rearrange contents.

## SPECIFICATIONS

Feature	Detail
Brand	Hisense
Model Number	RR44D6ASE
Capacity	4.4 Cu. Ft.
Form Factor	Compact, Freestanding
Color	Stainless Silver
Number of Doors	1
Shelf Type	Wire
Refrigerant	R-600A
Certification	Energy Star, ETL
Adjustable Temperature Control	Yes

Feature	Detail
UPC	857603006607

## WARRANTY AND CUSTOMER SUPPORT

---

Hisense products are manufactured to the highest quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official Hisense website. Keep your purchase receipt as proof of purchase for warranty claims.

For technical assistance, troubleshooting beyond this guide, or to inquire about parts and service, please contact Hisense Customer Support. Contact information can typically be found on the Hisense website or in the documentation provided with your appliance.

You can visit the official Hisense store on Amazon for more information: [Hisense Store](#)