

[Manuals.plus](#) /

› [SUNMI](#) /

› SUNMI T2s Lite 15.6-inch Android POS System User Manual

SUNMI T2s Lite

SUNMI T2s Lite 15.6-inch Android POS System User Manual

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your SUNMI T2s Lite 15.6-inch Android Point of Sale (POS) system. Please read this manual thoroughly before using the device to ensure optimal performance and safety. Keep this manual for future reference.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, humidity, or direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the power adapter supplied with the device. Using an incorrect adapter may cause damage or fire.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Keep the device away from water or other liquids.
- Ensure proper ventilation around the device during operation.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- SUNMI T2s Lite POS Terminal
- Power Adapter
- Power Cable
- Quick Start Guide (if applicable)
- Warranty Card (if applicable)

If any items are missing or damaged, please contact your vendor immediately.

4. PRODUCT OVERVIEW

The SUNMI T2s Lite is an integrated Android-based POS system designed for retail environments. It features a

15.6-inch capacitive touchscreen display and various connectivity options.



Figure 4.1: Front view of the SUNMI T2s Lite POS system. This image displays the main 15.6-inch touchscreen, which is the primary interface for operating the device. The design is compact and suitable for various retail settings.

4.1 Key Components

- **15.6-inch Touchscreen Display:** High-resolution (1920x1080) capacitive touch interface.
- **Power Button:** Located typically on the side or rear for turning the device on/off.
- **USB Ports:** For connecting peripherals such as barcode scanners, external printers, or cash drawers.
- **Ethernet Port:** For wired network connectivity.
- **Power Input:** For connecting the power adapter.
- **Front Camera:** For specific applications requiring image capture.

5. SETUP

5.1 Unpacking and Placement

1. Carefully remove the device and all accessories from the packaging.
2. Place the POS terminal on a stable, flat surface in a well-ventilated area.
3. Ensure there is sufficient space around the device for cable connections and heat dissipation.

5.2 Connecting Power

1. Connect the power cable to the power adapter.
2. Plug the power adapter into the power input port on the back of the SUNMI T2s Lite.
3. Plug the other end of the power cable into a grounded electrical outlet.

5.3 Initial Boot and Network Connection

1. Press and hold the power button until the screen lights up. The device will boot into the Android operating system.
2. Follow the on-screen prompts for initial setup, including language selection and time zone.
3. **Wi-Fi Connection:** Go to *Settings > Network & internet > Wi-Fi*, select your network, and enter the password.
4. **Ethernet Connection:** Connect an Ethernet cable from your router/switch to the Ethernet port on the device. The device should automatically connect to the wired network.

5.4 Connecting Peripherals

- **USB Devices:** Plug USB peripherals (e.g., barcode scanner, external printer, cash drawer) into the available

USB ports. The system will typically recognize them automatically.

- **Bluetooth Devices:** Go to *Settings > Connected devices > Bluetooth*, enable Bluetooth, and pair with your desired device.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

- **To Power On:** Press and hold the power button until the screen lights up.
- **To Power Off:** Press and hold the power button until a power menu appears. Select "Power off" and confirm. Alternatively, a short press of the power button will put the device to sleep.

6.2 Touchscreen Usage

- **Tap:** To select an item or activate a button.
- **Tap and Hold:** To open context menus or drag items.
- **Swipe:** To scroll through lists or navigate between screens.
- **Pinch-to-Zoom:** To zoom in or out on images or web pages.

6.3 Android OS Navigation

- **Home Screen:** The central hub for your applications and widgets.
- **App Drawer:** Access all installed applications.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.
- **Settings:** Configure Wi-Fi, Bluetooth, display, sound, and other system options.

6.4 Basic POS Functions

The specific POS functions will depend on the software application installed on your device. Refer to the documentation provided with your POS software for detailed instructions. Generally, you will:

1. Launch your POS application from the home screen or app drawer.
2. Log in with your user credentials.
3. Process transactions using the touchscreen and connected peripherals (e.g., scanning items, accepting payments).
4. Print receipts if an external or integrated printer is configured.

7. MAINTENANCE

7.1 Cleaning the Device

- Always power off and unplug the device before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaner to wipe the screen and exterior surfaces.
- Do not spray liquids directly onto the device.
- Avoid using harsh chemicals, solvents, or abrasive materials.

7.2 Software Updates

Regularly check for and install system and application updates to ensure optimal performance, security, and access to new features. You can usually find system updates in *Settings > System > System update*

7.3 Storage

When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures. If storing for a long time, ensure the battery is charged to about 50% to prolong its lifespan.

8. TROUBLESHOOTING

This section addresses common issues you might encounter. For more complex problems, contact customer support.

- **Device will not power on:**
 - Ensure the power adapter is securely connected to the device and a working power outlet.
 - Verify the power outlet is functional.
 - Try holding the power button for 10-15 seconds to force a restart.
- **Touchscreen is unresponsive:**
 - Restart the device.
 - Ensure the screen is clean and free of debris or liquids.
- **Network connection issues (Wi-Fi/Ethernet):**
 - Check if the Wi-Fi is enabled and you are connected to the correct network with the right password.
 - For Ethernet, ensure the cable is properly connected and your router/switch is working.
 - Restart your router/modem.
- **Peripherals (e.g., printer, scanner) not working:**
 - Ensure the peripheral is properly connected to the correct port.
 - Check if the peripheral has its own power supply and is turned on.
 - Verify that the necessary drivers or software for the peripheral are installed and configured within your POS application.

9. SPECIFICATIONS

The following are key technical specifications for the SUNMI T2s Lite:

Feature	Specification
Brand	SUNMI
Manufacturer	Sunmi
Native Display Resolution	1920x1080 pixels
Connectivity Technology	Bluetooth, Ethernet, USB, WLAN
Camera Description	Frontal
ASIN	B0B53FLFT8

10. WARRANTY AND SUPPORT

The SUNMI T2s Lite POS system comes with a standard manufacturer's warranty. Please refer to the warranty card

included in your package for specific terms and conditions, including warranty period and coverage details.

For technical support, service, or warranty claims, please contact your authorized SUNMI dealer or the customer support channel specified in your purchase documentation. Ensure you have your product model number (T2s Lite) and ASIN (B0B53FLFT8) ready when contacting support.