

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HUYVMAY](#) /

› [User Manual: HUYVMAY Fitness Tracker Pedometer Watch](#)

HUYVMAY B0B6CH4R69

User Manual: Fitness Tracker Pedometer Watch

Model: B0B6CH4R69 (Black+Pink)

Brand: HUYVMAY

INTRODUCTION

This manual provides comprehensive instructions for the HUYVMAY Fitness Tracker Pedometer Watch. This device is designed for users aged 5 to 16 years, offering essential fitness tracking features without requiring a smartphone application or Bluetooth connection. Key functionalities include time and date display, step counting, distance tracking, calorie calculation, alarm clock, and stopwatch. It features an IP68 waterproof rating and a long-lasting battery life of up to 20 days on a single charge.

Please read this manual thoroughly to ensure proper use and maintenance of your fitness watch.

SETUP GUIDE

1. Charging the Device

The HUYVMAY Fitness Watch features a direct USB charging design, eliminating the need for a separate charging cable. Simply remove the watch face from the wristband and plug it directly into any standard USB port (e.g., computer, USB wall adapter).



Image Description: A close-up view of the fitness watch module detached from its band, plugged directly into a USB power adapter. This illustrates the convenient cable-free charging method. The watch is white in this image, demonstrating the charging mechanism.

- **Charging Time:** Approximately 1 hour for a full charge.
- **Battery Life:** A full charge provides over 20 days of continuous use.
- **Low Battery Indication:** The watch will display an indication when the battery level is low.

2. Initial Configuration (Time, Date, User Data)

Upon first use or after a full discharge, you may need to set the time, date, and personal data for accurate tracking. Refer to the specific button functions in the 'Operating Instructions' section for detailed steps on navigating the settings menu.

- **Time/Date Setting:** Adjust the current time and date.
- **User Profile:** Input your height and weight. This data is crucial for the watch to accurately calculate distance traveled and calories burned based on your steps.

Pedometer Function

Count steps & distance & calories



Image Description: A person's wrist wearing the black and pink fitness watch, displaying the time and activity icons. Text overlay emphasizes "Pedometer Function" and "Please set correct user's weight and height in the watch," highlighting the importance of accurate user data for tracking.

OPERATING INSTRUCTIONS

The watch operates using a single button (Button A) to cycle through functions and activate the display. To conserve power and prevent distraction, the screen requires a button press to activate.

Multifunctional Kid's Watch



Image Description: The black and pink fitness watch with various icons surrounding it, representing its multiple functions: Pedometer, Calories, Distance, IP68 Waterproof, Time/Date, Alarm Clock, 21-Day Runtime, Stopwatch, and USB Charging. The image highlights the watch's comprehensive features.

Key Functions:

1. Time and Date Display:

Press Button A to activate the screen and view the current time and date. The display shows numbers and symbols in bright pink for clear visibility, even in low light conditions.

Clear Display Even In The Dark

Warm light does NOT hurt eyes




Image Description: A close-up of the fitness watch display in a dark environment, showing the time in bright pink digits. Text indicates "Clear Display Even In The Dark" and "Warm light does NOT hurt eyes," emphasizing readability and user comfort.

2. Pedometer (Step Counting):

The watch automatically counts your steps throughout the day. Ensure your height and weight are correctly set in the watch for accurate step-to-distance and calorie conversions.

3. Distance Traveled:

Calculates the distance covered based on your steps and configured user data.

4. Calories Burned:

Estimates calories burned based on your activity and personal profile.

5. Alarm Clock:

Set an alarm that provides a silent vibrating alert, designed not to disturb others.

Silent Vibrating Alarm Clock



Image Description: A hand wearing the fitness watch, with wavy lines emanating from it, symbolizing vibration. Text labels "Vibrating Alarm Clock" and "Not Bother Others," illustrating the silent alarm feature.

6. Stopwatch:

Utilize the stopwatch function for timing activities.

Resetting Pedometer Data:

You can easily reset the pedometer data (steps, calories, distance) at any time by pressing a specific button combination. Refer to the watch's on-screen prompts or the full user manual (PDF link provided in product details) for the exact procedure.

CARE AND MAINTENANCE

Water Resistance (IP68 Rating)

The HUYVMAY Fitness Watch is rated IP68 waterproof, meaning it is resistant to dust and can withstand immersion in water up to 1.5 meters for up to 30 minutes. This allows for use during:

- Washing hands

- Exposure to rain
- Showering (avoid hot water)
- Swimming for 1-2 hours

Important Note: Do not expose the watch to hot water, as this can compromise the waterproof seals. Avoid pressing buttons underwater.



Image Description: The black and pink fitness watch with water splashing around it, illustrating its IP68 waterproof capability. Icons depict washing hands, rain, showering, and swimming, reinforcing its suitability for various water activities.

Cleaning

Clean the watch and strap regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

Strap Care

The silicon strap is designed to be skin-friendly, soft, and elastic. Ensure the strap is not overly tight to allow for air

circulation and prevent skin irritation.

TROUBLESHOOTING

- **Screen Not Displaying:** Press Button A firmly to activate the screen. The display is designed to turn off automatically to save power.
- **Inaccurate Pedometer Readings:**
 - Ensure your height and weight are accurately entered in the watch settings.
 - Movement patterns can affect accuracy; consistent walking or running provides the most reliable data.
- **Watch Not Charging:**
 - Ensure the watch module is fully and correctly inserted into the USB port.
 - Try a different USB port or power adapter.
- **Alarm Not Vibrating:** Check that the alarm function is enabled and correctly set.

If you encounter issues not listed here, please refer to the full user manual (PDF) or contact customer support.

PRODUCT SPECIFICATIONS

Brand	HUYVMAY
Model	B0B6CH4R69
Color	Black+Pink
Item Weight	1.1 Ounces
Item Dimensions (LxWxH)	9 x 1.34 x 0.49 inches
Screen Size	1.3 Inches
Waterproof Rating	IP68
Battery Capacity	65 Milliamp Hours
Charging Time	Approx. 1 hour
Battery Runtime	Over 20 days
Connectivity	USB (for charging), No Bluetooth/App required
Special Feature	Activity Tracker, Silent Vibrating Alarm

WARRANTY AND SUPPORT

Your HUYVMAY Fitness Tracker Pedometer Watch comes with a comprehensive warranty and dedicated customer service:

- **Money Back Guarantee:** 30 days money back to ensure worry-free purchase.
- **Product Warranty:** 12-month product warranty from the date of purchase.
- **Customer Service:** 7x24 hours friendly customer service is available to assist you with any questions or concerns.

For support, please refer to the contact information provided with your purchase or visit the official HUYVMAY store page on Amazon.

