

## Beyution RM-SNXT10J

# Beyution RM-SNXT10J Replacement Remote Control User Manual

For JVC Compact Component Systems

## 1. INTRODUCTION

---

This manual provides instructions for the Beyution RM-SNXT10J replacement infrared remote control. This remote is designed to function as a direct replacement for the original remote controls of various JVC Compact Component Systems without requiring any programming or setup.

### Compatible JVC Models:

- NX-T10
- CA-NXT10
- SP-NXT10F
- SP-NXT10W
- NXT10
- CANXT10
- SPNXT10F
- SPNXT10W




Image 1.1: Comparison showing the original JVC remote control and the Beyution replacement remote control. The replacement remote offers similar functionality in a modified style.

## 2. SETUP

The Beyution RM-SNXT10J remote control does not require any programming or complex setup. Simply install the batteries, and it will be ready for use with your compatible JVC Compact Component System.

### 2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two (2) AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image 2.1: The back of the remote control with the battery cover removed, illustrating the correct placement for two AAA batteries.

**Note:** Always use new alkaline batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.

### 3. OPERATING INSTRUCTIONS

After installing the batteries, the remote control is ready for immediate use. Point the remote control directly at your JVC Compact Component System and press the desired function button.



Image 3.1: Front view of the Beyution RM-SNXT10J remote control, displaying the layout of all functional buttons.

#### 3.1 Key Functions Overview

- **Power Button (U/I):** Turns the component system on or off.
- **Number Buttons (0-9):** Used for direct track selection, radio station tuning, or menu navigation.
- **DVD/CD, HDMI 1/2, INPUT, FM:** Selects the audio/video input source.
- **MUTING:** Mutes or unmutes the audio output.
- **VOLUME (+/-):** Adjusts the audio volume level.
- **PRESET (+/-):** Navigates through preset radio stations.
- **DIMMER:** Adjusts the display brightness of the component system.
- **Navigation Buttons (Up, Down, Left, Right, ENTER):** Used for menu navigation and selection.
- **Play/Pause, Stop, Fast Forward, Rewind, Skip:** Controls media playback functions.
- **REC:** Initiates recording (if supported by the component system).
- **FM MODE:** Toggles between FM stereo and mono modes.
- **SETUP:** Accesses the system's setup menu.
- **SURROUND, SCAN MODE, PLAY MODE, REPEAT, REPEAT A-B, TIME SEARCH, SLEEP:** Controls various audio and playback settings.
- **DISPLAY, ANGLE, SUBTITLE, BASS/TREBLE:** Adjusts display options, DVD angles, subtitles, and audio equalization.

The remote control has an effective operating distance of up to 10 meters (approximately 33 feet) under optimal conditions.

## 4. MAINTENANCE

---

Proper care and maintenance will ensure the longevity and reliable performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in liquid.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries simultaneously.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Store in a cool, dry place away from direct sunlight.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

## 5. TROUBLESHOOTING

---

If you encounter issues with your remote control, please refer to the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the infrared sensor on your JVC component system.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Limited Range or Intermittent Functionality:**
  - Replace the batteries. Weak batteries can reduce the remote's range.
  - Ensure the remote's infrared emitter (at the front tip) is clean and unobstructed.
  - Avoid strong light sources (like direct sunlight or bright fluorescent lights) that might interfere

with the infrared signal.

- **Specific Buttons Not Working:**

- This is often an indication of low batteries. Try replacing them.
- If only one specific button is unresponsive after battery replacement, the remote may be damaged.

If these steps do not resolve the issue, please refer to the Support section for further assistance.

## 6. SPECIFICATIONS

Feature	Specification
Model Number	RM-SNXT10J (Internal: WY-MBE419-US)
Connectivity Technology	Infrared
Maximum Distance	10 Meters (approx. 33 feet)
Material	ABS Plastic
Color	Black
Batteries Required	2 x AAA (not included)
Product Dimensions	6.3 x 1.57 x 0.39 inches
Item Weight	2.82 ounces
Special Feature	Ergonomic Design

## 7. WARRANTY

This Beyution RM-SNXT10J replacement remote control comes with a **6-month warranty period** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as intended under normal use.

Please retain your proof of purchase for warranty claims.

## 8. SUPPORT

If you experience any issues with your Beyution RM-SNXT10J remote control, such as receiving a damaged unit or if it does not work as expected, please contact our customer service team.

Our customer service staff is committed to providing a satisfactory solution within 24 hours. When contacting support, please provide your order details and a clear description of the issue.

For assistance, please refer to the contact information provided by your retailer or on the product packaging.

