

## Old Skool os-8194

# Old Skool os-8194 Switch Sports Accessories Bundle User Manual

## INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, and maintenance of your Old Skool 15-in-1 Switch Sports Accessories Bundle. This kit is designed to enhance your gaming experience with Nintendo Switch and Switch OLED consoles, offering a variety of attachments for immersive gameplay across sports and driving titles. Please read these instructions carefully before use to ensure proper functionality and safety.

## PRODUCT OVERVIEW

---

The Old Skool 15-in-1 Switch Sports Accessories Bundle is a comprehensive collection of gaming peripherals compatible with Nintendo Switch and Switch OLED Joy-Con controllers. It includes accessories for various game types, allowing users to simulate real-world actions such as swinging a tennis racket or golf club, steering a vehicle, or wielding a sword. The bundle aims to provide a more interactive and engaging gaming experience.



An image showing the complete Old Skool 15-in-1 Switch Sports Accessories Bundle, including tennis rackets, golf clubs, steering wheels, swords, arm bands, and a zapper, arranged neatly.

## PACKAGE CONTENTS

Your Old Skool 15-in-1 Switch Sports Accessories Bundle includes the following items:

- 2 x Tennis Rackets
- 2 x Extendable Golf Clubs
- 2 x Steering Wheels
- 2 x Swords
- 2 x Controller Grips (for Joy-Cons)
- 2 x Wrist Straps
- 2 x Leg Straps
- 1 x Zapper

## SETUP INSTRUCTIONS

Follow these steps to prepare your accessories for gameplay:

1. **Unpacking:** Carefully remove all accessories from the packaging.
2. **Joy-Con Attachment:** For each accessory, gently slide your Nintendo Switch Joy-Con controller into the designated slot until it clicks securely into place. Ensure the Joy-Con is firmly seated to prevent accidental detachment during gameplay.
3. **Wrist Strap Usage:** Always attach the included wrist straps to your Joy-Cons and loop them around your wrist before playing. This is crucial for preventing accidental drops or impacts, especially during active gameplay.
4. **Leg Strap Usage:** For games requiring leg movement, insert a Joy-Con into a leg strap pouch and secure the strap comfortably around your thigh.

## OPERATING INSTRUCTIONS

---

Each accessory is designed to mimic real-world objects for an enhanced gaming experience. Ensure your Joy-Cons are fully charged before use.

### Tennis Rackets

- Attach a Joy-Con to the racket handle.
- Hold the racket as you would a real tennis racket.
- Perform swinging motions to control your character's actions in compatible tennis games.

### Golf Clubs

- Attach a Joy-Con to the golf club handle.
- Hold the club as you would a real golf club.
- Execute swinging motions to control your character's actions in compatible golf games.

### Steering Wheels

- Insert a Joy-Con into the center of the steering wheel.
- Hold the wheel with both hands.
- Rotate the wheel left or right to steer vehicles in compatible driving games.

### Swords

- Attach a Joy-Con to the sword handle.
- Hold the sword and perform slashing or thrusting motions to control sword-based actions in compatible games.

### Arm Bands

- Insert a Joy-Con into the designated pouch on the arm band.
- Secure the arm band comfortably around your upper arm.
- Used for games that track arm movements, such as Ring Fit Adventure.

### Zapper

- Insert a Joy-Con into the zapper accessory.
- Hold the zapper like a firearm.

- Aim and press the trigger or other buttons to perform shooting actions in compatible games.

## Controller Grips

- Slide a Joy-Con into each grip.
- These grips provide enhanced comfort and a more substantial feel for individual Joy-Con use.

## MAINTENANCE

---

Proper care will extend the life of your accessories:

- **Cleaning:** Use a soft, dry cloth to wipe down the accessories. For stubborn dirt, a slightly damp cloth can be used, but ensure the accessories are completely dry before storage. Avoid using harsh chemicals, abrasive cleaners, or solvents.
- **Storage:** Store all accessories in a cool, dry place away from direct sunlight and extreme temperatures. Keep them organized to prevent damage or loss.
- **Inspection:** Periodically inspect accessories for any signs of wear or damage. Discontinue use if any part is broken or compromised.

## TROUBLESHOOTING

---

If you encounter issues with your accessories, consider the following:

- **Accessory Not Responding:** Ensure the Joy-Con controller is correctly and securely inserted into the accessory. Verify that the Joy-Con is fully charged and properly paired with your Nintendo Switch console.
- **Unstable Attachment:** If a Joy-Con feels loose within an accessory, re-insert it firmly until you hear or feel a click. Always use wrist straps during active gameplay.
- **Game Compatibility:** Confirm that the game you are playing supports the specific accessory type. Some games may require specific controller settings or calibration.
- **General Issues:** If problems persist, try restarting your Nintendo Switch console.

## SPECIFICATIONS

---

- **Model Number:** os-8194
- **Item Weight:** Approximately 2.19 pounds (0.99 kg)
- **Package Dimensions:** 15.39 x 7.28 x 4.25 inches (39.1 x 18.5 x 10.8 cm)
- **Compatibility:** Nintendo Switch, Nintendo Switch OLED
- **Manufacturer:** Old Skool
- **Date First Available:** November 30, 2022

## WARRANTY AND SUPPORT

---

For product support, warranty information, or any inquiries regarding your Old Skool 15-in-1 Switch Sports Accessories Bundle, please contact Old Skool customer service directly through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

