

## WantJoin B0BRBDLCNB

# WantJoin Multifunctional Cooking Blender User Manual

Model: B0BRBDLCNB

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the WantJoin Multifunctional Cooking Blender. Retain this manual for future reference.

- **Electrical Safety:** Ensure the appliance is connected to a grounded 110V AC power outlet. Do not immerse the motor base in water or other liquids. Unplug when not in use or before cleaning.
- **Blade Safety:** Blades are sharp. Handle with extreme care. Avoid contact with moving parts.
- **Hot Liquids:** When blending hot liquids, do not fill the pitcher beyond the 'Hot Drink' maximum fill line (1400ml). Hot liquids can create steam and pressure, which may cause injury. Always ensure the lid is securely fastened.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

## 2. PRODUCT OVERVIEW

The WantJoin Multifunctional Cooking Blender is designed for both hot and cold food preparation, featuring a robust motor and intuitive controls.

### 2.1 Components

- **Blender Base:** Contains the motor, control panel, and power cord.
- **Glass Pitcher:** 60 oz (1800ml) capacity, made of food-grade thickened glass with integrated stainless

steel blades. Features measurement markings for both hot and cold liquids.

- **Lid:** Securely fits onto the glass pitcher, with a removable measuring cup insert.
- **Measuring Cup Insert:** Allows for adding ingredients during blending.



Figure 2.1: WantJoin Multifunctional Cooking Blender with various ingredients.

## 2.2 Control Panel

The digital touch control panel offers various pre-set programs and manual controls.



Figure 2.2: Digital Touch Control Panel.

- **Pre-set Programs:** Smoothie, Milkshake, Juice, Sauce, Soy Milk, Congee, Bisque.
- **Manual Controls:** Mode, Set, Hot Clean, Cool Clean, Start/Cancel, Warm, Pulse, Time +/-, Speed +/-

### 3. SETUP

1. **Unpack:** Carefully remove all components from the packaging.

2. **Initial Cleaning:** Before first use, wash the glass pitcher, lid, and measuring cup insert with warm, soapy water. Rinse thoroughly and dry. Wipe the blender base with a damp cloth.
3. **Placement:** Place the blender base on a stable, flat, and dry surface. Ensure it is away from heat sources and has adequate ventilation.
4. **Assemble:** Place the clean glass pitcher onto the blender base, ensuring it is seated correctly.

## 4. OPERATING INSTRUCTIONS

### 4.1 General Blending

1. Add ingredients to the glass pitcher. Do not exceed the maximum fill line (1800ml for cold, 1400ml for hot).
2. Secure the lid onto the pitcher and insert the measuring cup.
3. Plug the blender into a 110V AC power outlet. The display will illuminate.
4. Select a desired pre-set program (e.g., Smoothie, Soy Milk) or use the 'Mode' button to cycle through options.
5. Press 'Start/Cancel' to begin blending.
6. To stop blending, press 'Start/Cancel' again.

Video 4.1: Official product video demonstrating the WantJoin Multifunctional Cooking Blender's features, including blending various ingredients and automatic heating.

### 4.2 Hot Blending (Soups, Congee, Bisque)

The blender features a heating function for hot preparations.

1. Add ingredients for your hot recipe. Ensure the liquid level does not exceed the 1400ml 'Hot Drink' mark.
2. Select the appropriate pre-set program (e.g., 'Congee' or 'Bisque').
3. Press 'Start/Cancel'. The blender will automatically heat and blend the ingredients.



Figure 4.2: Example of a hot recipe: Pumpkin Soup.

### 4.3 Cold Blending (Smoothies, Milkshakes, Juices)

For cold beverages, fill up to the 1800ml 'Cool Drink' mark.

1. Add your desired cold ingredients.
2. Select the 'Smoothie', 'Milkshake', or 'Juice' pre-set program.
3. Press 'Start/Cancel' to begin.



Figure 4.3: Example of a cold recipe: Strawberry Milkshake.

#### 4.4 DIY Mode and Speed Regulation

For customized blending, use the 'Mode' button to enter DIY mode.

- **Speed +/-:** Adjust the blending speed across 10 gears.
- **Time +/-:** Set custom blending times from 5 seconds to 3 minutes.
- **Pulse:** Use for short bursts of high-speed blending to chop or mix ingredients.

#### 4.5 Delay Cook Function

The 'Set' button allows for a 12-hour delay cook function, primarily for hot drinks like soy milk.

1. Add ingredients for your desired hot drink (e.g., soy milk).
2. Press the 'Set' button and use 'Time +/-' to set the desired delay time (up to 12 hours).
3. Press 'Start/Cancel' to activate the delay function. The blender will start automatically after the set delay.



Figure 4.5: Setting the delay cook function.

## 5. CLEANING AND MAINTENANCE

---

### 5.1 Self-Cleaning Modes

The blender offers two convenient self-cleaning modes:

- **Hot Clean (4 minutes):** Ideal for thorough cleaning after preparing hot items. Uses high heat and 24000 RPM rotation.
  - **Cool Clean (2 minutes):** Suitable for quick cleaning of food residue after preparing cold items.
1. After use, add water and a small amount of dish soap to the pitcher.
  2. Select 'Hot Clean' or 'Cool Clean' on the control panel.
  3. Press 'Start/Cancel' to initiate the cleaning cycle.
  4. Once complete, discard the water and rinse the pitcher thoroughly.

# EASY TO CLEAN

Fast instant cleaning in seconds



Figure 5.1: Easy to Clean feature with Hot and Cool Clean modes.

## 5.2 Manual Cleaning

- **Glass Pitcher:** The glass pitcher is dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge. Be cautious around the blades.
- **Lid and Measuring Cup:** Hand wash with warm, soapy water.
- **Blender Base:** Wipe with a damp cloth. Do not immerse in water.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; pitcher not correctly seated; lid not properly closed.	Ensure power cord is securely plugged in. Verify pitcher is correctly placed on the base. Ensure lid is securely fastened.
Ingredients are not blending smoothly.	Too many ingredients; not enough liquid; ingredients are too large.	Reduce ingredient quantity. Add more liquid. Cut ingredients into smaller pieces. Use 'Pulse' mode for stubborn items.
Burning smell during operation.	Overloading the motor; prolonged continuous operation.	Unplug immediately. Reduce load. Allow motor to cool down. Refer to manual for maximum continuous operation times.
Leakage from pitcher.	Lid not sealed properly; pitcher not seated correctly.	Ensure lid is firmly pressed down and sealed. Check that the pitcher is correctly aligned and locked onto the base.

## 7. SPECIFICATIONS

- **Brand:** WantJoin
- **Model:** B0BRBDLCNB
- **Product Dimensions:** 17.32"D x 12.6"W x 12.2"H
- **Material:** Food Grade Thickened Glass (Pitcher), Stainless Steel (Blade)
- **Capacity:** 60 oz (1800ml for cold drinks, 1400ml for hot drinks)
- **Motor Speed:** Up to 24000 RPM
- **Voltage:** 110 Volts
- **Controls Type:** Digital Touch
- **Number of Speeds:** 10 (DIY mode)
- **Special Features:** Adjustable Speed Control, Adjustable Time, Heating Function, Multiple Pre-Programmed Modes, 12-Hour Delay Cook, Two Self-Cleaning Modes.
- **Dishwasher Safe:** Yes (Pitcher)

# PRODUCT DIMENSION

Customized for every age need



Figure 7.1: Product Dimensions.

## 8. WARRANTY AND SUPPORT

The WantJoin Multifunctional Cooking Blender comes with a limited warranty. For detailed warranty information, product support, or service inquiries, please refer to the warranty card included in your product packaging or contact WantJoin customer service directly.

