

manuals.plus /

› [TOPUTURE](#) /

› [TOPUTURE Walking Pad Treadmill User Manual](#)

TOPUTURE TP-TM01W

TOPUTURE Walking Pad Treadmill User Manual

Model: TP-TM01W

[Introduction](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &
Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your TOPUTURE Walking Pad Treadmill. This 2-in-1 treadmill is designed for both walking and jogging, making it suitable for home or office use. It features an LED touchscreen, app and remote control capabilities, and a robust design for a comfortable exercise experience.



Figure 1: TOPUTURE Walking Pad Treadmill in walking and jogging modes.

2. KEY FEATURES

- **2-in-1 Design:** Functions as an under-desk walking pad (0.6-2 MPH) and a jogging treadmill (3-6.2 MPH), adapting to various fitness needs.
- **Advanced Display & Control:** Features an ultra-large 18x6 inch LED touchscreen displaying time, speed, calories, and distance. Control via remote or the FITSHOW App.
- **Powerful & Quiet Motor:** Equipped with a 2.25HP motor, providing consistent power and supporting up to 300 lbs, with low noise operation (below 45db).
- **Spacious & Safe Running Belt:** A 40x16 inch non-slip, 5-layer shock-absorbing running belt ensures comfort and safety for knees, joints, and muscles.
- **Portable & Easy Storage:** Arrives fully assembled. Built-in wheels allow for easy movement and storage under a desk,

bed, or sofa.

- **Pre-set Programs:** Includes 12 pre-set programs to simulate various sports scenes and enhance your workout.

2 in 1 Treadmill

More Scientific and Safer Speed Range



Figure 2: The treadmill supports both walking and jogging modes.

Non-Slip Shock-Absorbing Running Belt

- 1 Non-slip and wear-resistant surface
- 2 PEP sound insulation layer
- 3 EVA sound-absorbing layer
- 4 Shock-absorbing cushion layer
- 5 Shock-absorbing reinforcement layer




Figure 3: Detailed view of the 5-layer shock-absorbing running belt for enhanced comfort and safety.

3. SETUP GUIDE

3.1 Unpacking and Placement

1. Carefully remove the treadmill from its packaging. The unit arrives fully assembled.
2. Place the treadmill on a flat, stable surface. Ensure there is adequate clear space around the unit for safe operation.
3. Verify all included components are present: Treadmill, Power Cord, User Manual, Tool Kit.

3.2 Power Connection

- Connect the power cord to the treadmill's power input port.
- Plug the other end of the power cord into a standard electrical outlet.

3.3 Initial Power On

- Locate the main power switch, usually near the power cord input, and turn it to the 'ON' position.
- The LED display should illuminate, indicating the treadmill is ready for use.



Figure 4: The treadmill's compact design and wheels make it easy to move and store.

4. OPERATING INSTRUCTIONS

4.1 Using the LED Touchscreen

The integrated LED touchscreen provides real-time feedback on your workout. It displays:

- **Speed:** Current speed in MPH.
- **Time:** Duration of your workout.
- **Calories:** Estimated calories burned.
- **Distance:** Distance covered in miles.

Use the touch controls on the display to adjust settings or select programs.

Multifunction LED Display



Figure 5: The LED display provides clear workout metrics.

4.2 Remote Control Operation

The remote control allows for convenient adjustment of the treadmill without needing to reach the display.

- **Power Button:** Turns the treadmill on/off.
- **Speed +/-:** Increases or decreases the running belt speed.
- **Mode/Program Selection:** Cycles through pre-set programs or changes operating modes.

4.3 Using the FITSHOW App

Download the FITSHOW App from your device's app store to connect to your treadmill via Bluetooth. The app allows you to:

- Track and record your fitness data.
- Control the treadmill remotely.

- Access professional fitness courses.
- Share your progress with friends.

APP Control & Remote Control

professional fitness course and experience sharing , real-time recording of exercise data.



Figure 6: Control your treadmill and track progress with the FITSHOW App and remote.

4.4 Operating Modes

The treadmill supports two primary operating modes:

- **Walking Mode (0.6-2 MPH):** Ideal for use under a desk or for light activity.
- **Jogging Mode (3-6.2 MPH):** For more intense workouts, allowing for faster walking or light jogging.

4.5 Official Product Videos

Your browser does not support the video tag.

Video 1: Official overview of the TOPUTURE Under Desk Walking Treadmill, demonstrating its features and use.

Your browser does not support the video tag.

5. MAINTENANCE

5.1 Lubrication

Regular lubrication of the running belt is crucial for optimal performance and longevity of your treadmill. Use silicone lubricant specifically designed for treadmills.

- Refer to the user manual for specific lubrication frequency and procedure, typically every few months depending on usage.
- Locate the lubricating hole on the treadmill for easy application.

5.2 Belt Adjustment

If the running belt starts to slip or drift to one side, it may need adjustment. Use the provided tool kit for this procedure.

- Consult the user manual for detailed instructions on how to tension and center the running belt.

5.3 Cleaning

- Wipe down the treadmill with a damp cloth after each use to remove sweat and dust.
- Avoid using abrasive cleaners or solvents that could damage the display or finish.

6. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|----------------------------------|---|---|
| Treadmill does not power on. | Power cord not connected; Main switch off; Circuit breaker tripped. | Ensure power cord is securely plugged in. Turn main switch ON. Check household circuit breaker. |
| Running belt slips or hesitates. | Belt needs lubrication; Belt tension is too loose. | Apply silicone lubricant to the belt. Adjust belt tension as per maintenance instructions. |
| Unusual noise during operation. | Loose components; Belt misalignment; Motor issue. | Check for loose screws and tighten. Adjust belt alignment. If noise persists, contact customer support. |
| Remote control not responding. | Dead batteries; Obstruction between remote and treadmill. | Replace remote control batteries. Ensure clear line of sight to the treadmill's receiver. |
| App connection issues. | Bluetooth not enabled; App not updated; Treadmill not discoverable. | Ensure Bluetooth is on your device. Update FITSHOW App. Restart treadmill and try connecting again. |

7. SPECIFICATIONS

| Feature | Detail |
|--------------------|---------------------|
| Brand | TOPUTURE |
| Model Name | TP-TM01W |
| Product Dimensions | 50"D x 5"W x 22.4"H |

| Feature | Detail |
|-------------------------------|--|
| Item Weight | 50 Pounds |
| Material | Alloy Steel |
| Maximum Speed | 6.2 Miles per Hour |
| Minimum Speed | 0.6 Miles per Hour |
| Maximum Horsepower | 2.25 Horsepower |
| Maximum Weight Recommendation | 300 Pounds |
| Deck Length | 40 Inches |
| Deck Width | 16 Inches |
| Display Type | LED |
| Screen Size | 18 Inches |
| Number of Programs | 12 |
| Power Source | Corded Electric |
| Assembly Required | No (Fully Assembled) |
| Included Components | Treadmill, Power Cord, User Manual, Tool Kit |

8. WARRANTY & SUPPORT

8.1 Warranty Information






The TOPUTURE Walking Pad Treadmill comes with a **24 Months Warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact TOPUTURE customer support. Refer to the contact information provided in your product packaging or visit the official TOPUTURE website for the most up-to-date support details.

We are committed to providing professional customer support to ensure your satisfaction with our product.



| | |
|---|--|
| <div><div>Toputure</div><div></div><div>USER MANUAL (Model TP3) INCLINE WALKING PAD</div></div> | <p>Toputure TP3 Incline Walking Pad User Manual</p> <p>Comprehensive user manual for the Toputure TP3 Incline Walking Pad, covering installation, safety precautions, features, operation, maintenance, and troubleshooting. Includes technical specifications, error codes, and FCC compliance information.</p> |
| <div><div>Toputure</div><div></div><div>USER MANUAL (Model TP1) FOLDING TREADMILL</div></div> | <p>Toputure TP1 Folding Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP1 Folding Treadmill, covering installation, operation, safety, maintenance, and troubleshooting.</p> |
| <div><div>Toputure</div><div></div><div>USER MANUAL (Model TP3) INCLINE WALKING PAD</div></div> | <p>Toputure TP3 Incline Walking Pad User Manual</p> <p>User manual for the Toputure TP3 Incline Walking Pad, covering installation, usage, maintenance, and troubleshooting.</p> |
| <div><div>Toputure</div><div></div><div>USER MANUAL (Model TP1) FOLDING TREADMILL</div></div> | <p>Toputure TP1 Folding Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP1 Folding Treadmill, covering installation, operation, maintenance, and troubleshooting.</p> |
| <div><div>Toputure</div><div></div><div>USER MANUAL (Model TP2) HOME TREADMILL</div></div> | <p>Toputure TP2 Home Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP2 Home Treadmill, covering installation, operation, maintenance, safety, and troubleshooting. Includes detailed instructions, parameters, and fault diagnostics.</p> |
| <div><div>TOPUTURE</div><div>AT: TOPUTURE EN: TOPUTURE FR: TOPUTURE DE: TOPUTURE ES: TOPUTURE IT: TOPUTURE PT: TOPUTURE RU: TOPUTURE CN: TOPUTURE US: TOPUTURE</div><div>USER GUIDE</div></div> | <p>Toputure TP2 Home Treadmill User Manual</p> <p>User manual for the Toputure TP2 Home Treadmill, covering installation, operation, maintenance, and safety guidelines.</p> |