

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ROCAM](#) /
- › [ROCAM 1018i Loud Digital Alarm Clock User Manual](#)

ROCAM 1018i

ROCAM 1018i Loud Digital Alarm Clock User Manual

Model: 1018i | Brand: ROCAM

INTRODUCTION

This manual provides detailed instructions for the ROCAM 1018i Loud Digital Alarm Clock. Please read this manual carefully before using the product to ensure proper operation and to maximize its features. Keep this manual for future reference.



Figure 1: ROCAM 1018i Loud Digital Alarm Clock (Black)

Key Features:

- 8.7-inch LED Digital Display with Mirror Effect
- Dual Alarm Functionality
- Adjustable Brightness (7 levels)
- Adjustable Alarm Volume (7 levels, 92dB to 110dB)
- Snooze Function (9 minutes)
- Includes Bed Shaker for heavy sleepers
- 12/24 Hour Time Display
- USB Charging Port (5V 1A)
- DC Adapter and Backup Battery included

SETUP

1. Unpacking and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- ROCAM 1018i Digital Alarm Clock
- DC Power Adapter
- USB Charging Cable
- Bed Shaker (Vibrator)
- User Manual (this document)

Inspect the clock for any visible damage. If any components are missing or damaged, contact customer support.

2. Power Connection

1. Connect the DC power adapter to the power input port on the back of the alarm clock.
2. Plug the DC power adapter into a standard electrical outlet. The clock display will illuminate.
3. The alarm clock requires continuous power to operate. The included button cell battery serves as a backup to retain time and alarm settings during a power outage, but the display will not be active.

DUAL ALARM CLOCK SELECTION WITH ADJUSTABLE VOLUME

You can set different alarm time according to your schedule



Two time display modes for you to choose



Figure 2: Power connection and USB charging port. The clock requires a DC adapter for operation.

3. Removing Protective Film

A protective film is applied to the mirror surface of the display. Gently peel off this film to reveal a clear mirror surface.

OPERATING INSTRUCTIONS

1. Setting the Time

Refer to the buttons on the back or top of the clock. Typically, there is a "TIME SET" or similar button.

Press and hold this button, then use the "+" or "-" buttons to adjust hours and minutes. Press "TIME SET" again to confirm.

To switch between 12-hour and 24-hour (military) time format, locate the "12/24H" button and press it.



Figure 3: The clock supports both 12-hour and 24-hour time display formats.

2. Setting Alarms (Dual Alarm)

The clock supports two independent alarms (Alarm 1 and Alarm 2).

1. Press the "ALARM 1" button (or "ALARM 2" for the second alarm). The alarm time will flash.
2. Use the "+" or "-" buttons to set the desired alarm hour and minute.

3. Press "ALARM 1" (or "ALARM 2") again to confirm the time.
4. After setting the time, you can usually select the alarm mode (sound, vibrator, or both) and volume. Refer to the specific buttons for these settings, often labeled "MODE" or "VOL".



Figure 4: The dual alarm feature allows setting two distinct wake-up times.

3. Alarm Modes and Volume

The ROCAM 1018i offers three alarm modes:

- **Alarm Sound Only:** The clock will emit an audible alarm.
- **Bed Shaker Only:** The connected bed shaker will vibrate.

- **Alarm Sound & Shaker:** Both the audible alarm and bed shaker will activate simultaneously.

To select the alarm mode, press the "MODE" button after setting the alarm time. The alarm volume can be adjusted from 92 dB to 110 dB across 7 levels using the "VOL" or "+"/"-" buttons when the alarm is active or in setup mode.



Figure 5: Choose from three alarm modes for personalized wake-up experience. The bed shaker cable is approximately two meters long.

4. Snooze Function

When an alarm sounds, press the large "SNOOZE" button located on the top of the clock. The alarm will

pause for 9 minutes and then sound again. You can repeat the snooze function multiple times.




Figure 6: The convenient snooze button provides an additional 9 minutes of sleep.

5. Adjusting Display Brightness

The LED display brightness can be adjusted to 7 levels to suit your preference, day or night. Locate the "DIMMER" or "BRIGHTNESS" button (often represented by a sun icon) and press it repeatedly to cycle through the brightness levels.




Figure 7: The display brightness can be adjusted across 7 levels for optimal visibility in any lighting condition.

6. USB Charging Port

The alarm clock features a 5V 1A USB charging port on the side. You can use this port to charge small electronic devices such as smartphones, smartwatches, or earphones. Connect your device's USB charging cable to this port.

Note: This port is for charging only and does not support data transfer.

MAINTENANCE

1. Cleaning

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish and electronic components.

Ensure the clock is unplugged from the power outlet before cleaning.

2. Battery Replacement (Backup Battery)

The alarm clock uses a Lithium-metal button cell battery (included) for backup power. This battery retains time and alarm settings during a power outage. If the clock consistently loses settings after a power interruption, the backup battery may need replacement. Refer to the battery compartment on the back of the unit for replacement instructions. Use only the specified battery type.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power supply.	Ensure the DC power adapter is securely plugged into the clock and a working electrical outlet.
Alarm does not sound/vibrate.	Alarm not activated, volume too low, or incorrect mode selected.	Verify alarm is set and enabled. Check alarm volume. Ensure correct alarm mode (sound, shaker, or both) is selected. Check bed shaker connection.
Time/settings are lost after power outage.	Backup battery is depleted or missing.	Replace the Lithium-metal button cell backup battery. Ensure it is correctly installed.
USB charging port not working.	Device not compatible, cable faulty, or clock not powered.	Ensure the clock is powered. Try a different USB cable and device. The port provides 5V 1A.
Display is too bright/dim.	Brightness setting is not optimal.	Press the "DIMMER" or "BRIGHTNESS" button to adjust through the 7 available levels.

SPECIFICATIONS

Model Number	1018i
Brand	ROCAM
Display Type	Digital LED (8.7-inch)
Color	Black
Product Dimensions	Approx. 20.6 cm (W) x 9.2 cm (H) x 3.81 cm (D)
Weight	Approx. 130 g
Power Source	DC Adapter (Mains Powered)
Backup Battery	1 x Lithium-metal battery (included)
Alarm Volume	7 levels, 92 dB to 110 dB

Display Brightness	7 adjustable levels
USB Output	5V 1A
Special Features	Large screen, Snooze, Dual Alarm, Bed Shaker, USB Charging Port

WARRANTY INFORMATION

ROCAM offers an 18-month warranty for this product from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, please retain your proof of purchase.

CUSTOMER SUPPORT

If you have any questions, encounter issues with your ROCAM 1018i Loud Digital Alarm Clock, or require technical assistance, please contact our customer support team.

Contact information for support is typically provided on the product packaging or through the retailer where the product was purchased. Please have your model number (1018i) and purchase details ready when contacting support.

We also offer a 30-day free return policy. For returns, please follow the procedure of your retailer.