

EDSACE B0C4GH5PBB

EDSACE Indoor Security Camera User Manual

Model: B0C4GH5PBB

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your EDSACE Indoor Security Camera. Please read this manual thoroughly before using the product to ensure proper function and safety. Keep this manual for future reference.

PRODUCT FEATURES

The EDSACE Indoor Security Camera is designed to provide comprehensive home monitoring with advanced features:

- **Intelligent AI Recognition:** Detects people and pets, sending notifications and recording moments automatically.
- **Flexible Monitoring with 360° Tracking:** Offers 355° horizontal and 100° vertical rotation for complete area coverage.
- **Motion Detection & Tracking:** Triggers alarms and sends notifications upon detecting human shapes or movement.
- **Clear Night Vision:** Automatically switches to day/night mode, providing up to 33 feet of visibility in total darkness.
- **Two-Way Audio:** Built-in microphone and speaker for real-time communication.
- **Storage Options:** Supports up to 128GB SD card (not included) and includes 3 days of free cloud storage (recycled).
- **1080P Resolution:** Provides clear, high-definition video recording.

SUPERIOR 1080P RESOLUTION

Indoor Security Camera



1080P
Resolution



Motion
Detection



Private
Mode



Pan-Tilt
Control



2-Way
Audio



Night
Vision



3 Days
Free Storage



Smart
Sharing



Image: A side-by-side comparison demonstrating the superior clarity and detail of 1080p HD video recording compared to standard resolution.

REMOTELY PAN/TILT CONTROL Android ALMOST 360 DEGREE VIEWING iPhone






Image: A child interacting with the camera's two-way audio feature, allowing real-time communication.




Image: Comparison of the camera's full color day vision and infrared night vision, showing clear visibility in different lighting conditions.

PACKAGE CONTENTS

Please check the package contents upon unboxing:

- EDSACE Indoor Security Camera
- Power Adapter
- USB Cable
- Mounting Accessories (screws, wall anchors)
- User Manual (this document)

SETUP GUIDE

Follow these steps to set up your EDSACE Indoor Security Camera:

1. Step 1: Download the App

Download the "Vicohome Cloud APP" from your smartphone's app store (available for iOS and Android).



Image: A smartphone screen showing the Vicohome Cloud APP download page.

2. Step 2: Power On the Camera

Plug the provided power adapter into the camera and then into a power outlet. The camera will power on and initiate its startup sequence.

QUICK INSTALLATION GUIDE




Image: The camera plugged into a wall outlet for power supply.

3. Step 3: Connect to Wi-Fi

Open the Vicohome Cloud APP and follow the in-app instructions to connect the camera to your 2.4GHz Wi-Fi network. Ensure your phone is connected to the same 2.4GHz network during setup.

QUICK INSTALLATION GUIDE




Image: A smartphone screen displaying the Vicohome app interface for controlling the camera, including pan/tilt and audio options.

For wall mounting, use the included mounting accessories. Choose a location with a clear view and within range of your Wi-Fi signal.

OPERATING INSTRUCTIONS

Live View and Remote Control

Once connected, open the Vicohome Cloud APP to access the live feed from your camera. You can remotely control the camera's pan (355° horizontal) and tilt (100° vertical) functions to view different areas of your room.

REMOTELY PAN/TILT CONTROL Android ALMOST 360 DEGREE VIEWING iPhone



Image: Diagram illustrating the camera's 355° horizontal and 100° vertical rotation for comprehensive viewing.

Two-Way Audio

Use the two-way audio feature to communicate with individuals near the camera. Tap the microphone icon in the app to speak, and listen through the camera's built-in speaker.

TWO-WAY AUDIO

Listen in and talk back to your family in real time



Image: A child speaking into the camera, demonstrating the two-way audio feature for real-time communication.

Motion Detection and AI Recognition

The camera features intelligent AI recognition to detect human and pet movement. When motion is detected, the camera will automatically record and send notifications to your phone. You can adjust sensitivity settings within the app.



Image: An illustration showing the camera's automatic motion tracking and AI detection capabilities for humans and pets, with a phone notification example.

Night Vision

The camera automatically switches between day and night vision modes based on ambient light. Infrared night vision provides clear black and white images in low-light conditions up to 33 feet.




Image: A visual comparison demonstrating the camera's clear full-color daytime video and detailed infrared night vision.

Storage Options

The camera supports local storage via a Micro SD card (up to 128GB, not included). It also offers 3 days of free cloud storage, which recycles automatically.

To install an SD card, gently tilt the camera lens upwards to reveal the SD card slot. Insert the card with the contacts facing down until it clicks into place.

Preset Positions

You can set up to 5 preset positions within the app. This allows the camera to quickly move to specific areas you frequently monitor with a single tap.



Image: An illustration showing how to set up to 5 preset positions for quick camera movement to desired viewing angles.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using harsh chemicals or

abrasive cleaners.

- **Placement:** Ensure the camera is placed in a stable location, away from direct sunlight, heat sources, and moisture.
- **Software Updates:** Regularly check the Vicohome Cloud APP for firmware updates to ensure optimal performance and security.

TROUBLESHOOTING

Camera Not Connecting to Wi-Fi

- Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.
- Check your Wi-Fi password for accuracy.
- Move the camera closer to your Wi-Fi router to improve signal strength.
- Reset the camera: Locate the reset button (often by tilting the lens up) and press and hold it for several seconds until the camera indicates a reset. Then, attempt to reconnect via the app.
- Restart your router and try connecting again.

Poor Video Quality

- Ensure a stable Wi-Fi connection. Weak signals can affect streaming quality.
- Clean the camera lens with a soft, dry cloth.
- Check app settings for video resolution options.

No Motion Detection Notifications

- Verify that motion detection is enabled in the Vicohome Cloud APP settings.
- Adjust motion detection sensitivity.
- Check your phone's notification settings to ensure the app is allowed to send alerts.
- Ensure the camera's field of view is clear and not obstructed.

Two-Way Audio Issues

- Ensure your phone's microphone is enabled for the Vicohome Cloud APP.
- Check the volume settings on both your phone and within the app.
- Ensure there is no obstruction blocking the camera's microphone or speaker.

SPECIFICATIONS

Feature	Detail
Brand	EDSACE
Model Number	B0C4GH5PBB
Connectivity Technology	Wireless (Wi-Fi)

Video Capture Resolution	1080p
Effective Still Resolution	2 MP
Night Vision Range	Up to 33 Feet
Pan Range	355° Horizontal
Tilt Range	100° Vertical
Special Features	Motion Sensor, Night Vision, Two-Way Audio, AI Recognition
Storage Options	Micro SD Card (up to 128GB), 3-Day Free Cloud Storage
Power Source	Corded Electric
Compatible Devices	Smartphone (iOS, Android)
Indoor/Outdoor Usage	Indoor
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	10.2 ounces
Package Dimensions	5.98 x 3.78 x 3.7 inches

Safety Information

- Do not expose the camera to extreme temperatures, humidity, or dust.
- Use only the provided power adapter to prevent damage.
- Keep the camera and its accessories out of reach of children and pets.
- Avoid placing the camera near strong magnetic fields.
- Do not attempt to disassemble or repair the camera yourself. Contact customer support for assistance.

Warranty and Support

For warranty information and technical support, please refer to the product packaging or contact EDSACE customer service directly. Contact details are typically available on the manufacturer's official website or within the Vicohome Cloud APP.