

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SPLITSKY](#) /

› [SPLITSKY NZFS Kids Alarm Clock User Manual - White Noise Sleep Aid & RGB Night Light](#)

## SPLITSKY NZFS

# SPLITSKY NZFS Kids Alarm Clock

## INSTRUCTION MANUAL

### 1. Introduction

Thank you for choosing the SPLITSKY NZFS Kids Alarm Clock. This device combines an alarm clock, white noise sleep aid, and an 8-mode RGB night light, designed to assist with sleep and wake-up routines for children and adults. Please read this manual thoroughly to understand its features and ensure proper operation.

#### Safety Information:

- Keep the device away from water and high humidity environments.
- Do not attempt to disassemble or repair the device yourself.
- Use only the provided USB-C power cable or a certified equivalent.
- Ensure proper ventilation around the device.

### 2. Package Contents

Verify that all items are present in your package:

- SPLITSKY NZFS Kids Alarm Clock
- 1.2M (4.7 inch) USB-C Power Cable
- User Manual (this document)
- 1 x CR2032 Lithium Ion Battery (pre-installed for memory backup)

# Product Accessories Are as Follows



Image: The SPLITSKY NZFS Kids Alarm Clock, a USB-C power cable, and the user manual are included in the package.

## 3. Product Overview

Familiarize yourself with the buttons and ports on your alarm clock:




Image: Detailed view of the alarm clock's top buttons and side ports, including Alarm 1, Time Setting, Light Minus/Settings, Snooze/Light Mode Switch, Light Plus/Setup, Music Switch, Alarm 2, Volume Setting, Time Brightness Setting, USB Output Charging Port, and Type-C Input Interface.

- **Alarm 1 Button:** Set and activate Alarm 1.
- **Time Setting Button:** Adjust the current time.
- **Light Minus / Settings Button:** Decrease light brightness or navigate settings.
- **Snooze / Light Mode Switch Button:** Activate snooze, or cycle through light modes.
- **Light Plus / Setup Button:** Increase light brightness or confirm settings.
- **Music Switch Button:** Cycle through white noise sounds.
- **Alarm 2 Button:** Set and activate Alarm 2.
- **Volume Setting Wheel (Side):** Adjust alarm and white noise volume.
- **Time Brightness Setting Wheel (Side):** Adjust display brightness.
- **USB Output Charging Port (Side):** Charge external devices.
- **Type-C Input Interface (Side):** Connect power cable to the alarm clock.

## 4. Setup

### 4.1 Power Connection

1. Connect the provided USB-C power cable to the Type-C Input Interface on the side of the alarm clock.
2. Plug the other end of the USB-C cable into a compatible USB power adapter (not included) or a USB port.
3. The display will illuminate, indicating the clock is powered on.



Image: The SPLITSKY NZFS Kids Alarm Clock is shown powered on and connected via its USB-C port, also demonstrating its capability to charge a smartphone.

## 4.2 Battery Installation (Memory Backup)

The alarm clock includes a pre-installed CR2032 battery. This battery serves as a memory backup to retain time and alarm settings during a power outage or when the main power is disconnected. It does not power the clock for regular operation.

- If the battery needs replacement, locate the battery compartment on the back of the unit.
- Use a small screwdriver to open the compartment.
- Replace with a new CR2032 battery, ensuring correct polarity.
- Close the compartment securely.

## 5. Operating Instructions

### 5.1 Setting the Time (12H/24H Format)

1. Press and hold the **Time Setting Button** until the hour digits begin to flash.

2. Use the **Light Minus / Settings Button** (down) or **Light Plus / Setup Button** (up) to adjust the hour.
3. Press the **Time Setting Button** again to move to minute adjustment. Adjust minutes using the Light Minus/Plus buttons.
4. Press the **Time Setting Button** a third time to select 12-hour or 24-hour format. Adjust using the Light Minus/Plus buttons.
5. Press the **Time Setting Button** once more to confirm and exit time setting mode.

## 5.2 Setting Alarms (Dual Alarm, Daily/Weekday/Weekend Mode)

The clock supports two independent alarms (Alarm 1 and Alarm 2).

1. Press and hold the **Alarm 1 Button** (for Alarm 1) or **Alarm 2 Button** (for Alarm 2) until the alarm hour digits flash.
2. Use the **Light Minus / Settings Button** or **Light Plus / Setup Button** to adjust the hour.
3. Press the respective Alarm Button again to move to minute adjustment. Adjust minutes using the Light Minus/Plus buttons.
4. Press the respective Alarm Button again to select the alarm mode:
  - **Daily Mode:** Alarm sounds every day.
  - **Weekday Mode:** Alarm sounds Monday to Friday.
  - **Weekend Mode:** Alarm sounds Saturday and Sunday.
5. Press the respective Alarm Button once more to confirm and exit alarm setting mode.
6. To enable/disable an alarm, short press the **Alarm 1 Button** or **Alarm 2 Button**. An alarm icon will appear/disappear on the display.

## 5.3 Snooze Function

When an alarm sounds, tap the **Snooze / Light Mode Switch Button** on top to activate snooze. The alarm will pause for 9 minutes and then sound again. This can be repeated multiple times.

## 5.4 Night Light (8 Modes RGB, 10-level dimming)

The alarm clock features 6 solid color lights and 2 ambient colorful lights.

1. Short press the **Snooze / Light Mode Switch Button** to turn on the night light and cycle through the 8 color modes.
2. To adjust the brightness (10 levels), use the **Light Minus / Settings Button** or **Light Plus / Setup Button** while the night light is active.
3. To turn off the night light, continue pressing the **Snooze / Light Mode Switch Button** until the light turns off.

# 8 LED Night Light Alarm Clocks

Digital alarm clock for kids



Image: Multiple SPLITSKY NZFS Kids Alarm Clocks are shown, each displaying a different color from the 8 available RGB night light modes.

## 5.5 White Noise Sleep Aid (8 Sounds)

The clock offers 8 soothing sounds to aid sleep.

1. Short press the **Music Switch Button** to turn on the white noise and cycle through the available sounds.
2. To adjust the volume (16 levels), use the **Volume Setting Wheel** on the side of the clock.
3. To turn off the white noise, continue pressing the **Music Switch Button** until the sound stops.

## Gradually increase volume from soothing

The left VOLUME wheel adjusts the volume level 1-16



Image: The SPLITSKY NZFS Kids Alarm Clock is displayed on a bedside table, with icons illustrating the various white noise options such as rain, cicadas, piano, bonfire, waves, birdsong, and church bells.

### 5.6 Sleep Timer (10-120 minutes)

The sleep timer allows you to set a duration for the white noise and/or night light to play before automatically turning off.

1. While white noise or night light is active, press and hold the **Music Switch Button** (for white noise timer) or **Snooze / Light Mode Switch Button** (for light timer).
2. Use the **Light Minus / Settings Button** or **Light Plus / Setup Button** to select the desired timer duration (10, 20, 30, 60, 90, 120 minutes).
3. Press the respective button again to confirm the timer setting. The timer icon will appear on the display.

### 5.7 Display Brightness Adjustment

Adjust the brightness of the LED time display using the **Time Brightness Setting Wheel** on the side of the clock.

### 5.8 USB Charging Port

The USB output charging port on the side of the alarm clock can be used to charge other small electronic devices, such as smartphones. Connect your device's charging cable to this port.

## 6. Maintenance

### 6.1 Cleaning

- Ensure the device is unplugged before cleaning.
- Wipe the surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays.

### 6.2 Storage

When not in use for extended periods, store the alarm clock in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. Troubleshooting

If you encounter issues with your SPLITSKY NZFS Kids Alarm Clock, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Clock display is off or dim.	Not connected to power; Time brightness set too low.	Ensure USB-C cable is securely connected to a power source. Adjust the Time Brightness Setting Wheel.
Alarm does not sound.	Alarm not activated; Alarm volume too low.	Check if the alarm icon is displayed. If not, short press the respective Alarm Button to activate. Adjust the Volume Setting Wheel.
Time/settings reset after power disconnection.	CR2032 backup battery is depleted or missing.	Replace the CR2032 battery in the battery compartment.
Night light or white noise not working.	Function not activated; Sleep timer active.	Short press the <b>Snooze / Light Mode Switch Button</b> or <b>Music Switch Button</b> to activate. Check if a sleep timer is set.

## 8. Specifications

Feature	Detail
Brand	SPLITSKY
Model Number	NZFS
Display Type	Digital LED
Product Dimensions	3.17"W x 3.17"H (approximately 8.05 cm W x 8.05 cm H)
Item Weight	8.1 Ounces (approximately 230 grams)
Power Source	Corded Electric (USB-C), Battery Powered (CR2032 for memory)
Night Light Modes	8 (6 solid colors, 2 ambient colorful) with 10-level dimming
White Noise Sounds	8 soothing sounds

Feature	Detail
Alarm Tones	7 wake-up alarm tones with 16-level volume control
Alarm Features	Dual Alarm, Daily/Weekday/Weekend modes, 9-minute Snooze
Timer Function	10-120 minute sleep timer for sounds and lights
Connectivity	USB-C Input, USB-A Output (for charging external devices)
Material	Acrylonitrile Butadiene Styrene

## 9. Warranty and Support

### 9.1 Warranty Information

Please refer to the warranty information provided at the time of purchase or contact your retailer for details regarding the product warranty. Keep your proof of purchase for any warranty claims.

### 9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or general inquiries, please contact the seller through the platform where you purchased the product. Provide your order number and a detailed description of the issue for prompt support.