

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [REACHER](#) /

> [Reacher Digital Alarm Clock & White Noise Sound Machine, 21 Soothing Sounds, 7 Wake Up Sounds, 8 Night Lights, 32-Level Volume, 9 Sleep Timer, Memory Function for Adult, Kid, Bedside, Bedroom](#)

REACHER

REACHER Digital Alarm Clock & White Noise Sound Machine User Manual

Model: A1S

INTRODUCTION

The REACHER Digital Alarm Clock & White Noise Sound Machine is designed to enhance your sleep and wake-up experience with a variety of soothing sounds, customizable lighting, and convenient alarm features. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance of your device.

PACKAGE CONTENTS

- REACHER Digital Alarm Clock & White Noise Sound Machine (Model: A1S)
- Power Adapter (AC/DC Adapter, Model: KA09E-0501200US, Input: 100-240V~, 50/60Hz, 0.25A Max; Output: 5V, 1200mA)
- User Manual



Image: The main unit of the REACHER Digital Alarm Clock and White Noise Sound Machine.

SETUP

1. Initial Power-Up

1. Connect the power adapter to the DC 5V input port located at the back of the device.
2. Plug the power adapter into a standard electrical outlet. The large LED display will illuminate, showing the current time.
3. Locate the CR2032 backup battery compartment on the bottom of the unit. Pull out the clear plastic sheet from the battery compartment to activate the memory function. This ensures that time and settings are retained during power outages.



Image: The power cord connected to the back of the alarm clock.

2. Setting the Time

1. Press the **Time Setting** button () once. The hour digits on the display will flash.
2. Use the **Backward** (<) or **Forward** (>) buttons to select the desired hour.
3. Press the **Time Setting** button again. The minute digits will flash.
4. Use the **Backward** (<) or **Forward** (>) buttons to select the desired minute.
5. Press the **Time Setting** button a third time to select the 12/24-hour format. Use the **Backward** (<) or **Forward** (>) buttons to toggle between formats.
6. Press the **Time Setting** button a fourth time to confirm and finish the time setting.

3. Setting the Alarm

1. Press the **Alarm Setting** button () once. The hour digits of the alarm will flash.
2. Use the **Backward** (<) or **Forward** (>) buttons to select the desired alarm hour.
3. Press the **Alarm Setting** button again. The minute digits of the alarm will flash.
4. Use the **Backward** (<) or **Forward** (>) buttons to select the desired alarm minute.
5. Press the **Alarm Setting** button a third time. The ringtone will sound. Use the **Backward** (<) or **Forward** (>) buttons to change the ringtone (7 wake-up sounds available).
6. Press the **Alarm Setting** button a fourth time to finish the alarm setting.
7. To adjust the alarm volume (32 levels), use the **Backward** (<) or **Forward** (>) buttons when the ringtone is active.

7 Wake Up Sounds with 32-level Volume

Gradual sound, allowing you to naturally wake up.



Image: Visual representation of the 7 available wake-up sounds.

OPERATING INSTRUCTIONS

1. Sound Machine Operation

1. To turn ON the sound machine, press the **Music Note** button ().
2. To select a sound, press the **Music Note** button repeatedly (21 soothing sounds available: 5 white noise, 3 fan, 11 nature, 2 lullabies, meditation).
3. To adjust the volume, use the **Backward** (<) or **Forward** (>) buttons.
4. To turn OFF the sound machine, long press the **Music Note** button.

Immersive Soothing Sounds Promote Better Sleep

5 White Noises

different frequency

3 Fan Sounds

mechanical/industrial
/household

11 Nature Sounds

rain/thunder/waves/
frogs/bubbles
...

2 Lullabies

Meditation



Image: Overview of the 21 immersive soothing sounds available for relaxation and sleep.

2. Night Light Operation

1. To turn ON the night light, press the **Light Bulb** button ().
2. To switch colors (8 colors available), press the **Light Bulb** button repeatedly.
3. To turn OFF the night light, long press the **Light Bulb** button.

Colorful Night Light & Backlit Button

Creates a relaxing sleep ambience while making it easy to find buttons at night.



Image: The alarm clock showcasing its colorful night light feature and backlit buttons for easy nighttime use.

3. Auto-Off Timer

1. Press the **Timer** button (🕒) repeatedly to select the desired auto-off time for the soothing sound and/or nightlight (5, 15, 30, 45 minutes, 1, 1.5, 2, 2.5, 3 hours, or OFF).
2. Long press the **Timer** button to turn OFF the timer function.

5-180 min Auto-off Timer for Sound and Light or Leave it On



Image: Various auto-off timer settings displayed around a sleeping child, indicating the timer's use for sleep.

4. Display Dimmer

Adjust the display brightness by repeatedly pressing the **Snooze/Display Dimmer** button (). There are 6 levels of dimming, including turning the display completely off.

Large LED Display with 6 Dimmer

See the time clearly during the day, soft light guard at night is not dazzling.



Image: The large LED display showing different brightness levels, from off to full brightness.

5. Alarm Pause & Snooze

- To stop the alarm when it goes off, press the **Alarm Setting** button ().
- To snooze for 9 minutes when the alarm goes off, press the **Snooze/Display Dimmer** button (). The snooze mode can be cycled infinitely.
- If the alarm is not stopped, it will continue ringing for 1 hour.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use liquid cleaners or aerosol sprays.
- Keep the device away from water or excessive moisture.
- Avoid exposing the device to direct sunlight or extreme temperatures.
- Ensure the ventilation holes on the sides are not blocked to prevent overheating.

TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the power adapter is securely plugged into both the device and a working electrical outlet. Check if the outlet is functional.
Time/settings are lost after power outage.	Verify that the plastic pull-tab from the CR2032 backup battery compartment on the bottom of the unit has been removed. If the memory function is abnormal, refer to the manual's setup section for images to better fasten the battery, or replace it if it has run out.
Alarm is not loud enough or too loud.	Adjust the alarm volume using the Backward (<) or Forward (>) buttons when setting the alarm or when the alarm is ringing.
Sound machine or night light turns off unexpectedly.	Check if the auto-off timer is activated. Long press the Timer button () to turn off the timer function if continuous operation is desired.
Display is too bright or too dim.	Press the Snooze/Display Dimmer button () repeatedly to cycle through the 6 brightness levels.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5 x 1.5 x 3 inches
Item Weight	13.7 ounces
Model Name	A1S
Power Source	Corded Electric
Material	Plastic
Color	Black
Backup Battery	1 CR2032 battery required (included)
White Noise Sounds	21 (5 white noise, 3 fan, 11 nature, 2 lullabies, meditation)
Wake Up Sounds	7
Night Light Colors	8
Volume Levels	32
Sleep Timer Options	9 (5/15/30/45 min, 1/1.5/2/2.5/3 hr)
Display Dimmer	6 levels

WARRANTY & SUPPORT

REACHER offers a 45-day refund policy and a 12-month warranty for products purchased in their store.
 For any questions or support, please feel free to contact customer service via email at customer@reachershop.com.

Your browser does not support the video tag.

Video: Official product overview of the Reacher White Noise Sound Machine & Digital Alarm Clock, demonstrating its features and benefits.

© 2023 REACHER. All rights reserved.

Related Documents -

 <p>Reacher R2 User Manual and Warranty</p>	<p>Reacher R2 User Manual and Warranty</p> <p>User manual and warranty information for the Reacher R2, a sound machine and night light with 31 soothing sounds, 8-color night light, and sleep timer. Suitable for babies, children, adults, and seniors.</p>
	<p>Reacher A1S White Noise Machine Alarm Clock User Manual</p> <p>Official user manual for the Reacher A1S White Noise Machine Alarm Clock, providing instructions on setup, features, alarm settings, sound machine, nightlight, and troubleshooting.</p>
	<p>Reacher K2 User Manual: Bedside Clock and Sound Machine Guide</p> <p>Comprehensive user manual for the Reacher K2 bedside clock and sound machine, detailing setup, features, and operation of its alarm, sound, and light functions.</p>
	<p>R9 Wireless Charging Sound Machine User Manual - Reacher</p> <p>User manual for the Reacher R9 Wireless Charging Sound Machine, detailing setup, functions, alarm settings, sound machine features, wireless charging, and safety instructions.</p>
 <p>Reacher R7 User Manual</p> <p>12 Months Warranty If a faulty product is found when setting up please Email us at customer@reachershop.com</p>	<p>Reacher R7 Sunrise Alarm Clock User Manual - Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the Reacher R7 Sunrise Alarm Clock. Learn how to set up, use features like the alarm, sound machine, nightlight, and understand safety instructions and warranty information.</p>
	<p>Reacher GX Alarm Clock User Manual: Setup, Features, and Safety Guide</p> <p>Comprehensive user guide for the Reacher GX portable alarm clock. Learn how to set time, alarms, wake-up modes, vibration, auto-dimming, and safety features. Includes troubleshooting and support information.</p>