

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GIZMORE](#) /

› [GIZMORE TWS 801 Air Bluetooth Headset User Manual](#)

GIZMORE 801

GIZMORE TWS 801 Air Bluetooth Headset User Manual

Model: GIZMORE 801 Air

INTRODUCTION

Thank you for choosing the GIZMORE TWS 801 Air Bluetooth Headset. This manual provides essential information for setting up, operating, and maintaining your new wireless earbuds. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image: The GIZMORE TWS 801 Air earbuds are shown resting inside their sleek white charging case, ready for use or charging.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- 2 x Gizbud Earpieces (Left and Right)
- 1 x Carry Case / Charging Case
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

SETUP GUIDE

1. Initial Charging

Before first use, it is recommended to fully charge your GIZMORE TWS 801 Air headset.

1. Connect the provided Type-C charging cable to the charging port on the case.
2. Connect the other end of the cable to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The indicator light on the charging case will show charging status. A full charge typically takes approximately 2 hours.

Note: The headset supports fast charging, providing up to 100 minutes of playtime with just 15 minutes of charging.



Image: An illustration demonstrating the Type-C rapid charging capability of the GIZMORE TWS 801 Air earbuds, highlighting quick charge times.

2. Bluetooth Pairing

To connect your GIZMORE TWS 801 Air headset to your device:

1. Ensure the earbuds are charged and placed inside the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing light (refer to product for specific light behavior).
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings.

4. Search for available devices and select "GIZMORE 801 Air" from the list.
5. Once connected, the indicator light on the earbuds will stop flashing, and your device will confirm the connection.

The headset utilizes Bluetooth version 5.3 for stable and efficient connectivity.

OPERATING INSTRUCTIONS

Touch Controls

The GIZMORE TWS 801 Air features intuitive touch controls on each earbud for easy management of music and calls.

- **Single Touch:** Play / Pause music, Answer / End call.
- **Right Bud Double Tap:** Previous track.
- **Left Bud Double Tap:** Next track.
- **Right Bud Triple Tap:** Volume down.
- **Left Bud Triple Tap:** Volume up.
- **Long Press (either bud):** Activate Voice Assistant.




Image: A woman is shown wearing a GIZMORE TWS 801 Air earbud, illustrating the ease of touch controls for wireless freedom.

Voice Assistant

Access your device's voice assistant (e.g., Google Assistant, Siri) with a simple long press on either earbud. This allows for hands-free control and quick access to information.




Image: A man is depicted interacting with his smartphone, using the GIZMORE TWS 801 Air earbud to activate a voice assistant like "OK Google" or "Hey Siri".

Playback and Battery Life

Enjoy extended listening sessions with up to 25 hours of total playback time (including charges from the case). The earbuds themselves provide several hours of continuous playback on a single charge.

PLAY ALL DAY LONG

25 Hours Playtime



Image: The GIZMORE TWS 801 Air earbuds are shown within their charging case, with a prominent overlay indicating "25 Hours Playtime", emphasizing their long battery life.

MAINTENANCE

Cleaning Your Earbuds

To maintain optimal sound quality and hygiene, regularly clean your earbuds.

- Use a soft, dry, lint-free cloth to wipe the surface of the earbuds and charging case.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Gently clean the speaker mesh with a dry cotton swab or a soft brush to remove any earwax or debris.
- Ensure the charging contacts on both the earbuds and the case are clean and dry.

Water Resistance

The GIZMORE TWS 801 Air headset is rated IPX5 water-resistant. This means it is protected against low-pressure water

jets from any direction. It is suitable for use during workouts or in light rain.

Important: IPX5 rating does not mean the earbuds are waterproof. Do not submerge them in water or expose them to high-pressure water jets. The charging case is not water-resistant.




Image: A pair of black GIZMORE TWS 801 Air earbuds are shown with water splashing around them, visually representing their water-resistant capabilities. Note: The product is IPX5 rated, suitable for light splashes.

TROUBLESHOOTING

If you encounter any issues with your GIZMORE TWS 801 Air headset, please refer to the following common solutions:

Earbuds Not Charging

- Ensure the Type-C cable is securely connected to both the charging case and the power source.
- Verify that the power source is active and functioning.
- Check the charging contacts on both the earbuds and inside the case for any debris or obstruction. Clean them gently if necessary.
- Try using a different Type-C charging cable and/or power adapter.
- Ensure the earbuds are correctly seated in the charging case.

Earbuds Not Pairing / Connecting

- Make sure Bluetooth is enabled on your device.
- Ensure the earbuds are fully charged.
- Place the earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to re-enter pairing mode.
- On your device, forget or unpair "GIZMORE 801 Air" from your Bluetooth list, then attempt to pair again.
- Move the earbuds closer to your device.
- Restart your device and try pairing again.

One Earbud Not Working

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then open it again. This often re-syncs them.
- Clean the charging contacts of the non-working earbud and its slot in the case.
- Try resetting the earbuds (refer to the manufacturer's website or contact support if a specific reset procedure is not detailed here).

Poor Sound Quality / No Sound

- Ensure the earbuds are properly seated in your ears.
- Check the volume level on both your device and the earbuds.
- Clean the speaker mesh of the earbuds to remove any obstructions.
- Move closer to your connected device to avoid interference.
- Disconnect and reconnect the Bluetooth connection.
- Ensure the earbuds are fully charged.

13MM HIGH FIDELITY ACOUSTICS



Microwoofer

Immersive
Sound



Extra **Bass**

Image: A detailed diagram illustrating the internal components of the GIZMORE TWS 801 Air earbud, highlighting the 13mm high fidelity acoustics and microwoofer for immersive sound and extra bass.

ENC NOISE REDUCTION



Image: The GIZMORE TWS 801 Air earbud is shown both in an ear and as a standalone unit, emphasizing its Environmental Noise Cancellation (ENC) feature for clearer audio.

SPECIFICATIONS

Feature	Detail
Model Name	GIZMORE 801 Air
Connectivity Technology	Wireless (Bluetooth 5.3)
Playback Time	Up to 25 Hours (with charging case)
Charging Time	Approx. 2 Hours (earbuds + case)
Fast Charging	15 mins charge for 100 mins playtime

Charging Port	Type-C
Water Resistance	IPX5 Rated
Control Type	Touch Control, Voice Control
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Environmental Noise Cancellation (ENC)
Item Weight	35 Grams
Product Dimensions	5.3 x 4.5 x 2.4 cm
Compatible Devices	Smartphones, PCs
Included Components	2 Earpieces, 1 Carry Case, 1 Type-C Cable, 1 User Manual
Manufacturer	ZAZZ Technology Connect Pvt.Ltd
Country of Origin	India

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your package or visit the official GIZMORE website.

Manufacturer: ZAZZ Technology Connect Pvt.Ltd

Address: B-65, 2nd Floor, Sector 60, Noida, Uttar Pradesh 201301, India

For further assistance, you may contact GIZMORE customer service through their official channels.

