

Giantex GT10003-JL

Giantex Full Body Massage Chair User Manual

Model: GT10003-JL

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the massage chair. Retain this manual for future reference.

- This product is not a toy and should be kept out of reach of children.
- Consult a physician before use if you have any medical conditions, are pregnant, or have a pacemaker.
- Do not use the chair in wet or damp environments.
- Ensure the power cord is not damaged and is properly connected to a grounded outlet.
- Do not attempt to repair or disassemble the chair yourself. Contact qualified service personnel.

2. PRODUCT OVERVIEW

The Giantex Full Body Massage Chair GT10003-JL offers a comprehensive massage experience with advanced features designed for relaxation and muscle relief. Key features include zero-gravity recline, an SL track massage system, heat therapy, foot rollers, yoga stretching, and airbag compression.

Key Features:

- **Zero Gravity Recline:** Three levels of zero-gravity positioning to reduce heart load and promote circulation.
- **SL Track Massage:** A 53-inch (135 cm) SL track provides massage from the neck to the thighs, conforming to the body's natural curve.
- **Full Body Air Massage:** 28 strategically placed airbags target shoulders, arms, calves, and feet.
- **Heat Therapy:** Far infrared heat in the back area helps relieve muscle soreness.
- **Foot Roller Massage:** Rollers in the footrest stimulate reflexology points.
- **Yoga Stretching Function:** Gently stretches the body to relax muscles.
- **Voice Control & Bluetooth:** Convenient voice commands and integrated Bluetooth speakers for music.

- **Customizable Massage:** 12 auto modes, 5 manual techniques, adjustable speed, width, and air pressure intensity.
- **Space-Saving Design:** Requires only 2 inches of clearance from a wall when reclining.

3. SETUP AND INSTALLATION

The Giantex massage chair features an installation-free design, meaning minimal assembly is required. However, proper placement and initial setup are crucial.

Unpacking and Placement:

1. Carefully remove the chair from its packaging. Keep the original packaging for potential returns or future transport.
2. Ensure your doorway is at least 30.7 inches wide to allow the package to pass through.
3. Place the chair on a flat, stable surface. Allow at least 2 inches of clearance from any wall for the reclining function.
4. The chair is equipped with built-in wheels for easier movement. Tilt the chair backward and roll it to your desired location.

Connecting Power:

- Connect the power cord to the chair's power input.
- Plug the power cord into a standard 110-120V, 60Hz grounded electrical outlet.
- Ensure the power switch on the chair is in the 'OFF' position before plugging it in.



Figure 1: Product dimensions in upright and reclined positions. Upright: 61.5" L x 30" W x 44.5" H. Reclined: 69.5" L x 30" W x 33" H.

Blue-tooth Music Player & Intelligent Voice Control



Figure 2: Illustration of the space-saving design, requiring only 2 inches from the wall, and the three zero-gravity recline positions.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the control methods to fully utilize your massage chair's features.

Remote Control Overview:

The chair is operated primarily via the LCD color screen controller. Refer to Figure 3 for button identification.

Yoga Stretching

Relax the muscles of the whole body



Figure 3: Detailed view of the remote control with LCD screen, showing buttons for power, timing, shoulder adjustment, recline modes, footrest, air pressure, manual massage, foot roller, and heating.

Armrest Shortcut Keys:

Quick access buttons are located on the armrest for common functions.



Figure 4: Close-up of convenient armrest shortcut keys, USB charging port, remote controller slot, PU leather head cushion, and retractable calf frame.

Starting a Massage:

1. Press the power button on the remote or armrest to turn on the chair.
2. The chair will perform an automatic shoulder positioning detection. Adjust the shoulder position using the remote if needed (10 levels available).
3. Select an automatic massage mode from the 12 available options, or choose a manual massage technique.
4. Adjust massage speed, width, and air pressure intensity to your preference.
5. The default massage time is 20 minutes. You can adjust this using the timing key.

Specific Functions:

- **Zero Gravity:** Press the zero-gravity button to cycle through the three recline angles.
- **SL Track Massage:** The 53-inch SL track ensures massage rollers cover from your neck to your thighs.
- **Airbag Massage:** Activate full-body air compression massage for shoulders, arms, calves, and feet.
- **Heat Therapy:** Turn on the back heating function for soothing warmth.

- **Foot Rollers:** Activate the foot roller massage for foot sole stimulation.
- **Yoga Stretching:** Select the yoga stretch mode to gently extend and relax your body.
- **Retractable Calf Frame:** Adjust the calf frame length to suit your height.




Zero Gravity Design


Easy to adjust the reclining angles with one button



Initial Zero Gravity



Comfort Zero Gravity



Deep Zero Gravity

Figure 5: Illustration of the 53-inch SL track mechanism with 4 rollers and the three different massage widths for varied body types.



Convenient armrest shortcut keys



USB charging port & remote controller or mobile phone placement slot



PU leather head cushion for cushioning massage strength



Retractable calf frame to adapt to people of different heights

Figure 6: Diagram showing the carbon fiber far infrared back heater, illustrating its effect on the user's back and waist.

53" SL Track

Mechanism with 4 rollers to move up & down, right & left.



VS



SL Track

- More fit the body curve & more comfortable
- Massage from neck, shoulder, back, waist, hip to thigh

8 Fixed Points Massage Rollers

- Poor experience
- Small massage area

3 different massage widths for people of different figure




Figure 7: Visual representation of the yoga stretching function, designed to relax muscles throughout the body.

Bluetooth and Voice Control:

- **Bluetooth Pairing:** Enable Bluetooth on your mobile device and connect to the chair's Bluetooth speaker. You can then play music through the chair.
- **Voice Control:** Use voice commands for hands-free operation. Refer to the specific voice command list in the quick start guide (if provided separately) for available commands.
- **USB Charging:** Use the integrated USB port to charge your mobile phone or other electronic devices during your massage.



Figure 8: Image depicting the Bluetooth music player and intelligent voice control features, showing a phone connected to the chair's speakers.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your massage chair.

Cleaning:

- **Exterior:** For general cleaning, wipe the chair's surface with a soft, damp cloth.
- **Spot Cleaning:** For stains, use a mild soap solution and a soft cloth. Gently blot the stained area. Do not rub vigorously.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the PU leather and other materials.
- Ensure the chair is unplugged before cleaning.

Storage:

- When not in use for extended periods, unplug the chair and store it in a cool, dry place away from direct sunlight.

- Avoid placing heavy objects on the chair.

6. TROUBLESHOOTING

If you encounter issues with your massage chair, refer to the following common problems and solutions.

Chair Does Not Power On:

- Check if the power cord is securely plugged into both the chair and the electrical outlet.
- Ensure the power switch on the chair is in the 'ON' position.
- Verify that the electrical outlet is functioning by plugging in another device.
- Check for any tripped circuit breakers in your home.

Massage Rollers Not Moving:

- Ensure a massage mode (auto or manual) has been selected.
- Check if the chair is in a paused state. Press the Pause/Start button on the remote.
- The chair may be performing an initial body scan; wait for it to complete.

Airbags Not Inflating:

- Verify that the air pressure massage function is activated on the remote control.
- Adjust the air pressure intensity settings.

No Heat from Back Heater:

- Ensure the heating function is turned on via the remote control.
- Allow a few minutes for the heating elements to warm up.

If these steps do not resolve the issue, please contact customer support.

7. SPECIFICATIONS

Feature	Specification
Model Number	GT10003-JL
Material	PP + ABS + Iron + PU Leather + Sponge Pad
Upright Dimensions (L x W x H)	61.5" x 30" x 44.5" (156 x 76 x 113 cm)
Reclined Dimensions (L x W x H)	69.5" x 30" x 33" (176.5 x 76 x 84 cm)
Seat Width	19.5" (49.5 cm)
Seat Depth	19" (48.3 cm)
Minimum Doorway Size	30.7" (78 cm)
Suitable Height Range	4.92 - 6.23 ft (150 - 190 cm)
Weight Capacity	330 lbs (150 kg)

Feature	Specification
Net Weight	199 lbs (90.3 kg)
Rated Voltage	110-120V 60Hz
Rated Power Input	120W
Rated Time	20 Mins
SL Track Length	53" (135 cm)
Airbags	28
Automatic Massage Modes	12
Manual Massage Techniques	5
Adjustable Speeds	5 levels
Adjustable Widths	3 levels
Air Pressure Intensity	3 levels
Zero Gravity Angles	3 levels

8. WARRANTY AND SUPPORT

Your Giantex Full Body Massage Chair is designed for durability and performance. For any concerns or assistance, please refer to the following information.

Return Policy:

This product is eligible for return or refund within 30 days of receipt. Please ensure to keep the original packaging if you intend to return the product.

Customer Support:

For technical support, warranty claims, or any questions regarding your massage chair, please contact Giantex customer service. Refer to your purchase documentation or the Giantex official website for contact details.