

PHILIPS HD9285/93

Philips Airfryer 5000 Series XXL Connected HD9285/93 User Manual

Model: HD9285/93

[Introduction](#) [Safety](#) [Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Philips Airfryer 5000 Series XXL Connected, model HD9285/93. Please read this manual thoroughly before first use and retain it for future reference.

The Philips Airfryer HD9285/93 is designed to be an everyday cooking companion, facilitating the preparation of various meals for the entire family. It features a large capacity, Rapid Air Technology, and connectivity to the NutriU app for enhanced cooking experiences.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not immerse the appliance in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not use the appliance if the plug, the main cord, or the appliance itself is damaged.
- Keep the main cord away from hot surfaces.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Children should be supervised to ensure they do not play with the appliance.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Hot air is released through the air outlet opening during operation. Keep your hands and face at a safe distance from the air outlet opening.
- The surfaces may become hot during use.
- Always unplug the appliance after use and before cleaning.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Philips Airfryer.



Figure 1: Front view of the Philips Airfryer 5000 Series XXL Connected HD9285/93, showing the digital display and control panel.



Figure 2: The Philips Airfryer unit alongside its removable cooking basket, illustrating the large capacity.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch controls for temperature, time, and preset functions.
- **Cooking Basket:** Non-stick basket for holding food.
- **Pan:** Collects oil and food drippings.
- **Air Inlet:** Located on the top of the appliance.
- **Air Outlet:** Located at the back of the appliance.
- **Power Cord:** For connecting to an electrical outlet.

4. SETUP AND FIRST USE

Before First Use:

1. Remove all packaging materials and stickers.
2. Clean the basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge.

3. Wipe the inside and outside of the appliance with a moist cloth.
4. Place the Airfryer on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces.
5. Ensure there is adequate ventilation around the appliance.

Connecting to NutriU App:

1. Download the NutriU app from your device's app store.
2. Follow the in-app instructions to pair your Philips Airfryer with your mobile device. This enables remote control and access to a wide range of recipes.

5. OPERATING INSTRUCTIONS

Basic Operation:

1. Plug the main plug into a grounded wall socket.
2. Carefully pull the pan out of the Airfryer.
3. Place the ingredients in the basket. Do not exceed the MAX indication.
4. Slide the pan back into the Airfryer.
5. Tap the power button to turn on the appliance.
6. Use the temperature and time control buttons to set the desired cooking parameters.
7. Press the start/pause button to begin cooking.
8. Some ingredients require shaking halfway through the preparation time. Pull the pan out by the handle and shake it. Then slide the pan back into the Airfryer.
9. When you hear the timer bell, the set preparation time has elapsed. Pull the pan out of the appliance and place it on a heat-resistant surface.
10. Check if the ingredients are ready. If not, slide the pan back into the appliance and set the timer for a few extra minutes.
11. Empty the basket into a bowl or onto a plate.



Figure 3: The Airfryer basket containing cooked food, demonstrating its capacity for family-sized meals.

Using Preset Programs:

The Airfryer comes with several preset programs for common dishes. Refer to the control panel icons for specific functions. These programs automatically adjust temperature and time for optimal results.

Rapid Air Technology:



Figure 4: A visual representation of Rapid Air Technology, showing hot air circulating within the Airfryer for even cooking.

The Philips Airfryer utilizes Rapid Air Technology, which circulates hot air at high speed, ensuring food is cooked evenly and crisply with little to no added oil.

6. MAINTENANCE AND CLEANING

Clean the appliance after every use.

Cleaning the Pan and Basket:

1. Unplug the Airfryer and allow it to cool down completely.
2. Remove the pan and basket. Both are dishwasher safe.
3. Alternatively, clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak the pan and basket in hot water with some dish soap for approximately 10 minutes.

Cleaning the Interior and Exterior:

- Wipe the exterior of the appliance with a moist cloth.
- Clean the inside of the appliance with hot water and a non-abrasive sponge.
- Clean the heating element with a cleaning brush to remove any food residues.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
The Airfryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
Ingredients are not cooked evenly.	Too many ingredients in the basket; temperature too low; cooking time too short.	Reduce the amount of ingredients; increase temperature; increase cooking time; shake ingredients halfway through.

Problem	Possible Cause	Solution
White smoke comes out of the appliance.	Fatty ingredients are being prepared; pan contains grease residues from previous use.	Wipe off excess oil from ingredients; clean the pan and basket thoroughly after each use.
Fresh fries are not crispy.	Not enough oil used; incorrect potato type; fries not properly dried before frying.	Add a little more oil; use fresh potatoes suitable for frying; dry potato sticks thoroughly before adding oil.

8. SPECIFICATIONS

- **Model:** HD9285/93
- **Brand:** PHILIPS
- **Capacity:** 7.2 Litres (1.4 kg)
- **Output Wattage:** 2000 Watts
- **Control Method:** Touch
- **Special Feature:** Temperature Control, Connected to NutriU app
- **Material:** Aluminium
- **Color:** Black & Dark Silver
- **Item Weight:** 6.2 Kilograms
- **Item Dimensions (LxWxH):** 41 x 30 x 33 Centimeters
- **Non-stick Coating:** Yes
- **Dishwasher Safe Parts:** Yes (Basket and Pan)

9. WARRANTY AND SUPPORT

For detailed warranty information, product support, or to register your product, please visit the official Philips website or contact Philips customer service in your region. Keep your purchase receipt as proof of purchase.

Online Support: www.philips.com/support

Brand Store: [Philips Store on Amazon.in](https://www.amazon.in/Philips)

