

[Manuals.plus](#) /

> [Netzu](#) /

> Netzu Toast Alarm Clock User Manual

Netzu 6228B

Netzu Toast Alarm Clock User Manual

Model: 6228B

INTRODUCTION

Thank you for purchasing the Netzu Toast Alarm Clock. This digital alarm clock is designed to be a charming and functional addition to any bedroom, especially for kids and teens. It features a unique toast-shaped night light, adjustable brightness, snooze function, nap timer, and sleep training capabilities. This manual provides detailed instructions on how to set up, operate, and maintain your new alarm clock to ensure optimal performance and a pleasant user experience.

PRODUCT OVERVIEW

The Netzu Toast Alarm Clock combines a digital time display with a soft night light, designed to be user-friendly and visually appealing. Key features include:

- **Toast Night Light:** A warm glow with 5 adjustable brightness levels, controlled by a toggle lever.
- **Dimmable LED Display:** Clear time display with 6 adjustable brightness levels and 12/24-hour format options.
- **Adjustable Alarm Volume:** 5 levels of beeping sound for the alarm.
- **Snooze Function:** Provides an extra 9 minutes of sleep by pressing the toggle lever.
- **Nap Timer:** Countdown options for 15, 30, 60, 90, or 120 minutes.
- **Sleep Training Function:** Uses sun and moon icons to indicate day and night.
- **Power Failure Memory:** Retains settings during power outages with a CR2032 battery (included).



Figure 1: Front view of the Netzu Toast Alarm Clock.

SETUP

1. Power Connection

The alarm clock operates via a plug-in power supply. Connect the provided USB cable to the clock and then to the adapter. Plug the adapter into a standard wall outlet.

Plug-in Alarm Clock & Power-off Memory



Figure 2: Connecting the alarm clock to power and the CR2032 battery for power-off memory.

2. Power Failure Memory Battery

A CR2032 battery is included and pre-installed to ensure that your alarm settings are retained during a power outage. The clock will not function without external power, but settings will be saved.

3. Initial Time Setting

Upon first power-up, the display will show a default time. Refer to the "Setting Time" section under Operating Instructions to set the current time.

OPERATING INSTRUCTIONS

1. Setting Time and 12/24H Format

Locate the time setting buttons, usually on the back or bottom of the clock. Press the "SET" button (or similar) to enter time setting mode. Use the "+" and "-" buttons to adjust hours and minutes. Press "SET" again to confirm. To switch between 12-hour and 24-hour formats, press the "12/24H" button (or similar) while in time setting mode or during normal display.

5-Level Brightness Display

Find your most comfortable brightness



Figure 3: The dimmable LED display offers 6 brightness levels for comfortable viewing.

2. Night Light Operation and Brightness Adjustment

The toast-shaped night light provides a warm glow. To turn the night light on or off, simply toggle the lever located on the side of the clock. To adjust the brightness, press the designated light brightness button (often integrated with the toggle lever or a separate button). There are 5 brightness levels to choose from.

Eye-care Toaster Night Light

Toggle the lever to turn on/off the light



Figure 4: Toggle the lever to control the night light and press to switch between 5 brightness levels.

3. Alarm Setting and Volume Adjustment


To set the alarm, press the "ALARM" button (or similar) to enter alarm setting mode. Use the "+" and "-" buttons to set your desired alarm time. Press "ALARM" again to confirm and activate the alarm. The alarm sound is a beeping sound. To adjust the alarm volume, locate the volume control buttons (often labeled "VOL" or integrated with "+"/"-"). There are 5 volume levels available, from gentle to assertive.

4. Snooze Function

When the alarm sounds, press the toaster's toggle lever to activate the snooze function. This will silence the alarm for 9 minutes, allowing for a brief extension of sleep before the alarm sounds again.

Snooze Function

Toggle the lever to get 9 minutes of sleep



5 Adjustable Volume

Set the right volume to start your day!



Figure 5: Use the toggle lever for snooze and adjust alarm volume.

5. Nap Timer

The nap timer function allows for convenient countdowns. Press the "TIMER" button (or similar) to cycle through preset options: 15, 30, 60, 90, or 120 minutes. The clock will sound an alarm once the selected time has elapsed.



Figure 6: Utilize the Nap Timer for productive rest periods.

6. Sleep Training Function

This feature helps children understand day and night cycles. A sun icon will be displayed on the screen during daytime hours, and a moon icon will appear during nighttime hours, based on the set day and night start times (refer to specific settings in the full manual if available, otherwise assume automatic based on time).

Sleeping Training

Tell the day and night and regulate your routine



Time to Wake Up

The sun icon will be displayed from night start time to day start time.



Time for Bed

The moon icon will be displayed from day start time to night start time.

Figure 7: The Sleep Training function uses sun and moon icons to indicate day and night.

MAINTENANCE

Cleaning

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the unit in water. Ensure the clock is unplugged before cleaning.

Battery Replacement (CR2032)

If the power failure memory function is no longer working, the CR2032 battery may need replacement. Locate the battery compartment (usually on the bottom or back of the unit), open it, and replace the old battery with a new CR2032 battery, ensuring correct polarity. Dispose of old batteries responsibly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off or not working.	Not plugged in; power outage; adapter issue.	Ensure power adapter is securely plugged into the clock and wall outlet. Check if the outlet is working.
Alarm does not sound.	Alarm not set; alarm volume too low; alarm deactivated.	Verify alarm time is set correctly. Increase alarm volume. Ensure alarm is activated (check alarm icon on display).
Night light is not working.	Toggle lever not activated; brightness set to lowest.	Toggle the lever to turn the light on. Increase the brightness level.
Settings are lost after power outage.	CR2032 battery is dead or missing.	Replace the CR2032 battery in the battery compartment.

SPECIFICATIONS

Brand: Netzu

Model Number: 6228B

Product Dimensions: 13.5 x 3.81 x 10.5 cm

Item Weight: 272 g

Material: Acrylonitrile Butadiene Styrene (ABS)

Power Source: Plug-in (Adapter & USB Cable)

Memory Battery: 1 x CR2032 (included)

Display Type: Digital LED

Special Features: Night Light, Timer, Snooze, Adjustable Brightness, Sleep Training

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the manufacturer directly through their official website or customer service channels. Keep your purchase receipt for any warranty claims.