

[manuals.plus](#) /

› [Ankilo](#) /

› [Ankilo 5.8" LED Digital Alarm Clock Instruction Manual](#)

## Ankilo WA131-MA06US-HY

# Ankilo 5.8" LED Digital Alarm Clock

Model: WA131-MA06US-HY

Brand: Ankilo

## 1. PRODUCT OVERVIEW

The Ankilo 5.8" LED Digital Alarm Clock is designed for bedrooms, offering a clear display, adjustable brightness, and volume. It includes features such as Daylight Saving Time (DST), calendar, and a convenient snooze function. Its modern design makes it suitable for various settings including offices and nightstands.



Front view of the Ankilo 5.8" LED Digital Alarm Clock displaying '10:30' with DST and AM indicators.

# Multifunctional Alarm Clock



Diagram illustrating the alarm clock's dimensions (5.5 x 2.2 inches) and the functions of its control buttons: Time, Alarm, Snooze/Light, Volume (+/-), and DST.

## 2. SETUP GUIDE

### 2.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the package contents are present and undamaged. Retain packaging for future storage or shipping.




Contents of the Ankilo alarm clock package, including the clock, USB cable, and instruction manual.

## 2.2 Powering the Device

The alarm clock supports dual power supply options:

- **USB Power (Recommended for continuous display):** Connect the provided USB power cord (1.5m/59") to the clock and a USB power adapter (not included). The screen will remain continuously lit.
- **Battery Power (Backup only):** Insert 3 AAA batteries (not included) into the battery compartment. On battery power alone, the screen will automatically enter power save mode after 10 seconds and will only light up when a button is pressed. This mode is primarily for backing up time, date, and alarm settings during power outages.

# DUAL POWER SUPPLY



Rear view of the alarm clock illustrating the dual power options: 3 AAA batteries (not included) and USB power (cable included).

## 2.3 Initial Time and Date Setting

1. Press the **"Time"** button to enter time setting mode.
2. Use the **"Volume +"** and **"Volume -"** buttons to adjust the hour.
3. Press **"Time"** again to move to minute setting, then adjust with **"Volume +"** and **"Volume -"**.
4. Continue pressing **"Time"** to cycle through year, month, and day settings, adjusting each with **"Volume +"** and **"Volume -"**.
5. Press **"Time"** one last time or wait for 10 seconds for the settings to save automatically.

## 3. OPERATING INSTRUCTIONS

### 3.1 Setting the Alarm

1. Press the **"Alarm"** button to enter alarm setting mode.
2. Use the **"Volume +"** and **"Volume -"** buttons to set the desired alarm hour.
3. Press **"Alarm"** again to move to minute setting, then adjust with **"Volume +"** and **"Volume -"**.
4. Press **"Alarm"** one last time or wait for 10 seconds for the alarm to be set.

5. To activate or deactivate the alarm, short press the "Alarm" button outside of setting mode. An alarm icon will appear/disappear on the display.

### 3.2 Snooze Function

When the alarm sounds, press the "SNOOZE/LIGHT" button located on the top of the clock. The alarm will pause for five minutes and then sound again. This can be repeated multiple times.



Image of a person in bed, reaching for the alarm clock, highlighting the 'Snooze / Light' button for easy snooze.

### 3.3 Brightness Adjustment

The clock features four adjustable brightness levels (Off, Low, Medium, High). To adjust, short press the "SNOOZE/LIGHT" button when the alarm is not sounding. Note: Brightness cannot be adjusted when powered solely by battery, as the screen enters power-saving mode.

## 4 Level Dimmer



Illustration demonstrating the four adjustable brightness levels of the LED display: Off, Low, Medium, and High.

### 3.4 Volume Adjustment

The alarm volume can be set to three levels: 50dB (Low), 70dB (Medium), and 90dB (Loud). To adjust, press the "**Volume +**" or "**Volume -**" buttons outside of time/alarm setting mode.

### 3 Adjustable volumes



Image of a person waking up, with an overlay showing the three adjustable volume levels for the alarm: L03 (90db), L02 (70db), and L01 (55db).

#### 3.5 Daylight Saving Time (DST) Setting

To activate or deactivate DST mode, long press the "Volume -" button. The DST indicator will appear or disappear on the display.





Illustration showing how to activate and deactivate Daylight Saving Time (DST) by long-pressing the volume minus button.

#### 3.6 12/24 Hour Format

To switch between 12-hour and 24-hour time formats, short press the "Time" button outside of setting mode. The display will change accordingly, with an AM/PM indicator for the 12-hour format.



Comparison image showing the alarm clock displaying time in both 12-hour (11:30 AM) and 24-hour (23:30) formats.

## 4. MAINTENANCE

### 4.1 Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.

### 4.2 Battery Replacement

If using battery backup, replace the 3 AAA batteries when the display becomes dim or settings are not retained during power outages. Ensure correct polarity when inserting new batteries.

## 5. TROUBLESHOOTING

### 5.1 Common Issues and Solutions

| Problem                                  | Possible Cause                                       | Solution   |
|--|--|--|
| Display is off or dim (on battery power) | Power-saving mode activated; low batteries.          | Press any button to light up the display. Replace AAA batteries if low. For continuous display, use USB power. |
| Alarm does not sound.                    | Alarm not activated; volume too low.                 | Ensure alarm icon is displayed. Adjust alarm volume using Volume +/- buttons.                                  |
| Time/settings reset after power loss.    | No backup batteries installed or batteries are dead. | Install 3 fresh AAA batteries for backup.  |
| Buttons are unresponsive.                | Temporary software glitch.                           | Disconnect USB power and remove batteries for 1 minute, then reconnect.  |

## 6. SPECIFICATIONS

| Feature            | Detail  |
|--------------------|---|
| Model Number       | WA131-MA06US-HY   |
| Display Type       | Digital LED (5.8")  |
| Product Dimensions | 14 x 5.5 x 2.3 cm (5.5 x 2.2 x 0.9 inches)  |
| Power Source       | USB (Corded Electric) / 3 x AAA Batteries (for backup)  |
| Material           | Acrylonitrile Butadiene Styrene (ABS)   |
| Brightness Levels  | 4 (Off, Low, Medium, High)  |
| Volume Levels      | 3 (50dB, 70dB, 90dB)  |
| Special Features   | Adjustable Brightness, Adjustable Volume, Snooze Function, DST Mode, 12/24 Hour Format, Calendar Display, Battery Indicator |
| Item Weight        | 95 Grams (3.35 ounces)  |

## 7. WARRANTY AND SUPPORT

Ankilo is committed to providing high-quality products and customer satisfaction.

- 6 Months Return Policy:** For any issues within the first six months.
- 24 Months Warranty:** Covers manufacturing defects for two years from the date of purchase.
- Lifetime Support:** Dedicated customer service available for the lifespan of the product.



Badges indicating 6 Months Return, 24 Months Warranty, and Lifetime Support.

For technical assistance, troubleshooting, or warranty claims, please contact Ankilo customer support through the retailer's platform or the contact information provided with your purchase.



Customer service representatives are available to assist you.

## 8. OFFICIAL PRODUCT VIDEOS

---

No official product videos from the seller were found for this product.

© 2025 Ankilo. All rights reserved.