

BERGNER BGMP-9234

Bergner Master Pro Air Fryer (Model BGMP-9234) User Manual

Brand: BERGNER | Model: BGMP-9234

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Bergner Master Pro Air Fryer. Please read all instructions carefully before first use and retain this manual for future reference.

The Bergner Master Pro Air Fryer utilizes 360° Cooking Airflow Technology to cook food with little to no oil, offering a healthier alternative to traditional frying methods. Its 3.0L capacity and digital touch panel with multi-preset cooking menus make meal preparation convenient.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the appliance housing in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure the air fryer is placed on a stable, heat-resistant surface with adequate ventilation around it.
- Never block the air inlet or outlet vents during operation.

3. PRODUCT OVERVIEW

The Bergner Master Pro Air Fryer is designed for efficient and healthy cooking. Familiarize yourself with its components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital touch interface for setting time, temperature, and selecting presets.
- **Frying Basket:** Non-stick coated basket for holding food.
- **Handle:** For safely inserting and removing the frying basket.
- **Air Inlet/Outlet:** Vents for proper airflow during cooking.



Image 1: Front view of the Bergner Master Pro Air Fryer, showing the main unit, handle, and basket area.

4. SETUP

1. **Unpack:** Carefully remove all packaging materials, stickers, and labels from the air fryer.
2. **Initial Cleaning:** Wipe the exterior of the appliance with a damp cloth. Wash the frying basket with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry all parts.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and above the appliance, to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

5. OPERATING INSTRUCTIONS

Before First Use

It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal and will dissipate.

General Operation

1. **Prepare Food:** Place the ingredients you wish to air fry into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks securely into place.
3. **Power On:** The digital touch panel will illuminate.
4. **Set Time and Temperature:** Use the temperature control feature to set the desired cooking temperature (e.g., 80°C to 200°C) and the timer for the required cooking duration.
5. **Use Preset Menus:** The air fryer features a Multi PreSet Cooking Menu. Select the appropriate preset for common foods like fries, chicken, or fish. The appliance will automatically set the optimal time and temperature.
6. **Start Cooking:** Press the start button to begin the cooking process.
7. **Shake Basket (Optional):** For some foods, especially smaller items, shaking the basket halfway through the cooking time can ensure more even results. Carefully pull out the basket, shake, and reinsert. The air fryer will resume cooking.
8. **Completion:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket and transfer the cooked food to a plate.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity and optimal performance of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Frying Basket:** The non-stick coated basket is **not dishwasher safe**. Wash it with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak the basket in warm soapy water for about 10 minutes before cleaning.
3. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasive cleaners or scouring pads.
4. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. If necessary, a soft brush can be used to remove food residue from the heating element.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake the basket halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and interior thoroughly after each use. For fatty foods, absorb excess oil with a paper towel.

Problem	Possible Cause	Solution
Food is not crispy.	Too much moisture; insufficient oil (for some recipes).	Pat food dry before cooking. Lightly brush or spray with oil for extra crispiness.

8. SPECIFICATIONS

- **Model:** BGMP-9234
- **Power:** 1200 Watts
- **Capacity:** 3.0 Litres
- **Control Method:** Digital Touch Panel
- **Special Feature:** Temperature Control, 360° Cooking Airflow Technology, Multi PreSet Cooking Menu
- **Dimensions (D x W x H):** 21.5 cm x 21.5 cm x 26.5 cm
- **Weight:** 2.6 kg
- **Material:** Aluminium, Metal, Plastic, Stainless Steel
- **Color:** Black
- **Non-stick Coating:** Yes (Basket)
- **Dishwasher Safe:** No (Basket)
- **Included Components:** Air Fryer, Accessories

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Bergner customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official BERGNER website or contact their authorized service centers.