

WELLFIT WP026

WELLFIT 10% Incline Walking Pad - Under Desk Treadmill WP026 User Manual

Model: WP026

1. INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your WELLFIT 10% Incline Walking Pad, Model WP026. Please read this manual thoroughly before initial use and retain it for future reference.

Important Safety Information:

- Always consult with a healthcare professional before starting any new exercise program.
- Ensure the walking pad is placed on a flat, stable surface.
- Keep children and pets away from the equipment during operation.
- Do not operate the walking pad if it is damaged or malfunctioning.
- Wear appropriate athletic footwear during use.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- Treadmill Body x 1
- Lubrication Oils x 2
- Remote Control x 1
- Tool Kit x 1 (includes wrenches for adjustment)
- User Manual x 1
- Power Cord x 1

Package Includes

- Treadmill Body *1
- Lubrication Oils *2
- Remote Control *1
- Tools Pack *1
- Manual *1



Image: The WELLFIT Walking Pad package includes the main unit, remote control, power cord, lubrication oil, and a tool kit.

3. PRODUCT OVERVIEW

The WELLFIT WP026 Walking Pad is designed for home use, offering a compact and quiet solution for walking and light jogging. Key features include:

- **Ultra-Slim Design:** With a thickness of 9cm and a weight of 13kg, it fits easily under beds or sofas.
- **2.5HP Peak Motor:** Provides smooth and quiet operation for speeds between 1.6-6.4 km/h (1.0-4.0 MPH).
- **10% Manual Incline:** Features 3-level manual incline/decline options (3%, 6%, 10% uphill; 8%, 5%, 3% downhill) for varied workout intensity.
- **Smart Connectivity:** Syncs via Bluetooth with Kinomap, Zwift, and Apple Health, offering voice control through the WELLFIT app.
- **LED Display:** Tracks time, speed, distance, and calories burned.
- **Alloy Steel Frame:** Supports users up to 136kg (300lbs).
- **Low Noise Operation:** Operates at less than 40 dB, minimizing disturbance.



Image: A woman running on the WELLFIT Walking Pad, showcasing its compact design and remote control.

Smart Treadmill: Connect, Run, Enjoy!

Enjoy APPs integration, voice control, and fun outdoor scenes



Image: The WELLFIT Walking Pad connected to various fitness apps like Zwift, Kinomap, WELLFIT Fitness, and Apple Health.

4. SETUP

4.1 Unpacking and Placement

1. Carefully remove the walking pad and all components from the packaging.
2. Place the walking pad on a firm, level surface. Ensure there is adequate clear space around the unit for safe operation (at least 0.5 meters on all sides).
3. Avoid placing the unit on thick carpets, which may obstruct ventilation or affect belt movement.

4.2 Manual Incline Setup

The WP026 features manual incline adjustment using detachable feet. To adjust the incline:

1. Ensure the walking pad is powered off and unplugged.
2. Lift the rear of the walking pad.
3. Insert the appropriate incline feet into the designated slots at the rear of the unit to achieve the desired

incline level (3%, 6%, or 10%).

4. Ensure the feet are securely in place before use.

Activate a New Mode for Efficient Fat Burning



- 🌿 Simulate outdoor environments
- 🏃 Enhance muscle training
- 🔥 Increase calorie burn
- 🫀 Improve cardiovascular function
- 👉 Reduce impact on the knees

Image: Visual representation of the 3%, 6%, and 10% incline options for the walking pad.

4.3 Power Connection

1. Connect the power cord to the walking pad's power inlet.
2. Plug the other end of the power cord into a grounded electrical outlet.
3. Flip the main power switch (usually located near the power inlet) to the 'ON' position. The LED display should illuminate.

4.4 Remote Control Pairing

The remote control is essential for operating the walking pad. It may require pairing upon first use or after battery replacement.

1. Ensure the walking pad is powered on.
2. Press and hold the 'Start' button on the remote control for 3-5 seconds until the walking pad beeps or the display indicates successful pairing.

3. If pairing fails, ensure the remote control batteries are correctly installed and charged, then repeat the process.

4.5 App Connection (Bluetooth)

To enhance your workout experience, connect your walking pad to the WELLFIT app or other compatible fitness apps.

1. Download the WELLFIT app from your device's app store.
2. Enable Bluetooth on your smartphone or tablet.
3. Open the WELLFIT app and follow the on-screen instructions to search for and connect to your walking pad (usually listed as 'WELLFIT WP026' or similar).
4. Once connected, you can control the walking pad, track your progress, and access additional features like voice control and virtual scenes.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- **To Power On:** Ensure the main power switch is 'ON'. Press the 'Start' button on the remote control. The walking pad will typically start with a low speed after a brief countdown.
- **To Power Off:** Press the 'Stop' button on the remote control. The belt will gradually slow down and stop. For complete power off, switch the main power switch to 'OFF' and unplug the unit.

5.2 Using the Remote Control

The remote control allows you to manage your workout without interrupting your stride.

- **Start/Stop:** Initiates or halts the walking belt.
- **Speed Up (+):** Increases the belt speed.
- **Speed Down (-):** Decreases the belt speed.
- **Mode/Program:** Cycles through different display modes or pre-set programs (if available).

Caution: Be mindful of button placement to avoid accidentally pressing 'Stop' when intending to adjust speed.

Convenient Large Display

Track All Your Running Data



TIME



SPEED



DISTANCE



CALORIE



Image: Close-up of the WELLFIT Walking Pad's LED display showing workout data and the remote control.

5.3 Understanding the LED Display

The integrated LED display provides real-time workout metrics:

- **Time:** Duration of your current workout.
- **Speed:** Current walking speed (in km/h or MPH).
- **Distance:** Total distance covered during the workout.
- **Calories:** Estimated calories burned.

5.4 Speed Range

The WELLFIT WP026 operates within a speed range of 1.6 km/h (1.0 MPH) to 6.4 km/h (4.0 MPH), suitable for walking and light jogging.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your walking pad.

6.1 Lubrication

The walking belt requires periodic lubrication to reduce friction and wear. Use the provided lubrication oil.

1. Turn off and unplug the walking pad.
2. Carefully lift one side of the walking belt.
3. Apply a small amount of lubricant (approximately 5-10ml) evenly along the center of the deck, underneath the belt.
4. Repeat on the other side if necessary.
5. Plug in and power on the walking pad, then run it at a low speed (e.g., 1.6 km/h) for 2-3 minutes to distribute the lubricant.
6. Lubricate every 3-6 months, or after approximately 100 hours of use, depending on usage frequency.

6.2 Cleaning

- Wipe down the walking pad's surface with a damp cloth after each use to remove sweat and dust.
- Avoid using abrasive cleaners or solvents.
- Regularly vacuum around and under the unit to prevent dust accumulation.

6.3 Belt Adjustment

If the walking belt feels like it is slipping or drifting to one side, it may need adjustment.

1. Turn off and unplug the walking pad.
2. Locate the adjustment bolts at the rear of the walking pad (use the tool kit provided).
3. If the belt is drifting to the right, turn the right bolt clockwise a quarter turn. If drifting left, turn the left bolt clockwise a quarter turn.
4. If the belt is slipping, turn both bolts clockwise a quarter turn to tighten the belt.
5. Plug in and power on the walking pad, run it at a low speed, and observe the belt. Adjust further in small increments if needed.

6.4 Storage

Due to its compact design, the WELLFIT WP026 is easy to store.

- Ensure the walking pad is powered off and unplugged.
- It can be stored flat under furniture (e.g., bed, sofa) or upright against a wall to save space.

Compact Design & Save Space

Assembly Free



Only 13KG



110 x 46 x 9 cm



Easy to store

Image: The WELLFIT Walking Pad demonstrating its compact design for easy storage under furniture or upright.

7. TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Walking pad does not power on.	Power cord not connected, main switch off, power outlet issue.	Ensure power cord is securely plugged in, main switch is 'ON', and test the outlet with another device.
Remote control not responding.	Batteries low/dead, remote not paired.	Replace batteries. Re-pair the remote control (refer to Section 4.4).

Problem	Possible Cause	Solution
Walking belt slips or hesitates.	Belt too loose, insufficient lubrication.	Adjust belt tension (refer to Section 6.3). Apply lubrication oil (refer to Section 6.1).
Walking belt drifts to one side.	Belt alignment issue.	Adjust belt alignment (refer to Section 6.3).
Unusual noise during operation.	Loose components, belt friction, motor issue.	Check for loose screws. Lubricate the belt. If noise persists, contact customer support.
App connection issues.	Bluetooth off, app not updated, interference.	Ensure Bluetooth is enabled. Update the app. Restart both the walking pad and your device.

If you encounter an issue not listed here, or if the problem persists after attempting the suggested solutions, please contact WELLFIT customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	WP026
Product Dimensions (L x W x H)	121.92 x 52.58 x 14.48 cm (48 x 20.7 x 5.7 inches)
Packed Size (L x W x H)	110 x 46 x 11.2 cm (43.3 x 18.1 x 4.4 inches)
Item Weight	13.15 kg (29 lbs)
Maximum Weight Capacity	136 kg (300 lbs)
Motor Horsepower	2.5 HP (Peak)
Speed Range	1.6 - 6.4 km/h (1.0 - 4.0 MPH)
Incline Levels	3-level Manual (3%, 6%, 10%)
Display Type	LED
Metrics Tracked	Time, Speed, Distance, Calories Burned
Frame Material	Alloy Steel
Power Source	Corded Electric
Special Features	Compact Design, Lightweight, Manual Incline, Portable, Shock Absorbent

9. WARRANTY AND SUPPORT

WELLFIT products are manufactured to high-quality standards and are backed by a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical assistance, troubleshooting, or warranty claims, please contact WELLFIT customer support through the following channels:

- **Website:** Visit the official WELLFIT website for support resources and contact information.
- **Email:** Refer to your warranty card or product packaging for the customer service email address.
- **Phone:** Check the WELLFIT website for regional customer service phone numbers.

When contacting support, please have your model number (WP026) and proof of purchase readily available.