

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Topski](#) /

› [Topski RGB Vibrating Alarm Clock User Manual](#)

Topski 8010Z

Topski RGB Vibrating Alarm Clock User Manual

Model: 8010Z

INTRODUCTION

Thank you for purchasing the Topski RGB Vibrating Alarm Clock. This device is designed to provide a reliable and versatile alarm solution, especially for heavy sleepers, individuals with hearing impairment, and seniors. It features a loud alarm, a powerful bed shaker, a large dimmable display, and a vibrant RGB night light. Please read this manual carefully to ensure proper use and maintenance of your alarm clock.

PACKAGE CONTENTS

- Topski RGB Vibrating Alarm Clock
- Bed Shaker
- USB Power Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the main components of your alarm clock:



Figure 1: Front view of the alarm clock with bed shaker and a phone connected for charging.

- **Large LED Display:** Shows time, alarm indicators, and AM/PM.
- **RGB Night Light Bar:** Located at the top, provides customizable ambient lighting.
- **Control Buttons:** Located on the back for time setting, alarm setting, brightness, and volume control.
- **USB Charging Ports:** One port for powering the clock, and an additional USB-A port for charging external devices.
- **Bed Shaker Port:** Connects the included bed shaker for silent or combined alarm.
- **Battery Compartment:** For backup batteries (2x AAA, not included).

SETUP

Powering On

1. Connect the provided USB power cable to the DC 5V input port on the back of the alarm clock.
2. Plug the other end of the USB cable into a standard USB power adapter (not included) and then into a wall outlet.
3. The display will light up, and the clock will be ready for setup.

Battery Backup Installation

For time and alarm settings memory during power outages, install backup batteries.



Figure 2: Location of the battery backup compartment.

1. Open the battery compartment cover on the back of the clock.
2. Insert 2 AAA batteries (not included) according to the polarity markings (+ and -).
3. Close the battery compartment cover securely.

Connecting the Bed Shaker

The bed shaker provides a powerful vibration to wake heavy sleepers.

3 Wake-up Modes for You



Figure 3: The bed shaker connected to the alarm clock, placed under a pillow.

1. Plug the bed shaker's cable into the dedicated port on the back of the alarm clock.
2. Place the bed shaker under your pillow or mattress for optimal vibration.

OPERATING INSTRUCTIONS

Setting the Time

1. Press and hold the "TIME SET" button (or similar button, refer to physical clock for exact label) on the back of the clock. The hour digits will start flashing.
2. Use the "+" and "-" buttons to adjust the hour.
3. Press "TIME SET" again to confirm the hour and move to minute setting.
4. Use the "+" and "-" buttons to adjust the minutes.
5. Press "TIME SET" one more time to save the time.

12/24 Hour Format



Figure 4: Example of 12-hour and 24-hour time display options.

To switch between 12-hour and 24-hour time format, press the "12/24H" button (or similar) on the back of the clock.

Setting Alarms (Dual Alarm)

This clock supports two independent alarms (Alarm 1 and Alarm 2).

Big Snooze Button



Figure 5: The dual alarm feature allows setting two separate wake-up times.

1. Press the "ALARM 1 SET" button (or "AL1") once. The alarm hour digits will flash.
2. Use the "+" and "-" buttons to adjust the alarm hour.
3. Press "ALARM 1 SET" again to confirm the hour and move to minute setting.
4. Use the "+" and "-" buttons to adjust the alarm minutes.
5. Press "ALARM 1 SET" one more time to save Alarm 1.
6. Repeat the process for "ALARM 2 SET" (or "AL2") if a second alarm is desired.

Alarm Modes (Ring, Vibration, Both)

3 Wake-up Modes for You



Figure 6: Three wake-up modes: Vibration Only, Ringing Only, and Ringing + Vibration.

After setting an alarm, press the "MODE" button (or similar) to cycle through the alarm modes:

- **Ring Only:** The alarm will sound audibly.
- **Vibration Only:** The bed shaker will vibrate (if connected).
- **Ring + Vibration:** Both the audible alarm and bed shaker will activate.

Adjusting Alarm Volume



Figure 7: Adjustable alarm volume ranging from 85dB to 100dB.

While the alarm is sounding or in alarm setting mode, use the "VOL +" and "VOL -" buttons to adjust the alarm volume. The clock offers up to 100dB loudness.

Snooze Function




Figure 8: The large snooze button provides an additional 9 minutes of sleep.

When the alarm sounds, press the large "SNOOZE" button on top of the clock to temporarily silence the alarm for 9 minutes. The alarm will sound again after the snooze period.

Display Brightness Adjustment

Fit for Different People



Figure 9: Adjustable display brightness from 0% to 100% for comfortable viewing.

Press the "BRIGHTNESS" button (or similar) repeatedly to cycle through different display brightness levels (e.g., High, Medium, Low, Off). This allows you to customize the display visibility to your preference, especially for nighttime use.

RGB Night Light Control



Figure 10: The alarm clock features 9 dynamic RGB night light effects.

Press the "LIGHT" button (or similar) to turn the night light on/off and cycle through its various color modes and effects. The night light brightness can also be adjusted.

USB Charging Port

The alarm clock includes a USB-A port on the back for charging your mobile devices. Simply connect your device's USB charging cable to this port.

MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the clock away from water and high humidity.
- Avoid placing the clock in direct sunlight or near heat sources.
- If not using the clock for an extended period, remove the backup batteries.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power, or display brightness is set to off.	Ensure the power adapter is properly connected. Press the BRIGHTNESS button to increase display brightness.
Alarm does not sound/vibrate.	Alarm not set, alarm mode incorrect, or bed shaker not connected/faulty.	Verify alarm time and ensure alarm is activated. Check alarm mode (Ring, Vibration, or Both). Ensure bed shaker is securely plugged in.
Time is incorrect after power outage.	Backup batteries are dead or not installed.	Install or replace 2 AAA backup batteries.
USB charging port not working.	Device not properly connected, or power draw too high.	Ensure cable is fully inserted. Try a different USB cable or device. Ensure the clock is powered by the main adapter.

SPECIFICATIONS

- **Brand:** Topski
- **Model:** 8010Z
- **Display Type:** Digital LED
- **Power Source:** Corded Electric (DC 5V)
- **Battery Backup:** 2 x AAA batteries (not included)
- **Alarm Volume:** Up to 100dB
- **Special Features:** Adjustable Brightness, Large Display, Loud Alarm, Snooze, Dual Alarm, Bed Shaker, RGB Night Light, USB Charging Port
- **Product Dimensions:** 6.57"W x 3.19"H
- **Material:** Plastic (Acrylonitrile Butadiene Styrene)
- **Color:** RGB

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Topski website. Keep your purchase receipt for warranty claims.