

Stabo 51136

Stabo multifon Security V 51136 Wireless Surveillance Set

Model: 51136 | **Brand:** Stabo
User Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Stabo multifon Security V 51136 Wireless Surveillance Set. This system is designed to provide reliable monitoring with a high-resolution camera and a dedicated monitor for live viewing and recording. Please read this manual thoroughly before using the product to ensure proper setup and functionality.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package. If any items are missing or damaged, please contact your retailer.

- 1x Stabo multifon Security V 51136 Wireless Camera
- 1x 7-inch LCD Color Monitor with Integrated Recorder
- Installation Hardware (screws, wall plugs)
- Power Adapters for Camera and Monitor
- User Manual (this document)



Image 1: The Stabo multifon Security V 51136 Wireless Surveillance Set, featuring the 7-inch LCD monitor on the left displaying a multi-view of different locations, and the white outdoor bullet camera with an antenna on the right.

3. SAFETY INFORMATION

- **Power Supply:** Use only the provided power adapters. Incorrect power sources can damage the device and void the warranty.
- **Water and Moisture:** The camera is designed for outdoor use, but avoid submerging it in water. The monitor is for indoor use only; keep it away from water and high humidity.
- **Temperature:** Operate the device within the specified temperature range. Extreme temperatures can affect performance and lifespan.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Do not use liquid or aerosol cleaners.
- **Installation:** Ensure the camera is securely mounted to prevent it from falling. Follow local regulations for surveillance camera placement.
- **Interference:** Avoid placing the camera or monitor near strong electromagnetic fields or large metal structures that may interfere with the wireless signal.

4. SETUP

4.1 Camera Installation

1. **Choose a Location:** Select an outdoor location that provides the desired viewing angle and is within range of the monitor's wireless signal. Ensure the camera is protected from direct, prolonged sunlight and heavy rain if possible.

2. **Mount the Camera:** Use the provided installation hardware to securely mount the camera to a wall or suitable surface. Drill pilot holes if necessary. Adjust the camera's angle for optimal coverage.
3. **Connect Power:** Connect the camera to its power adapter and plug it into a power outlet. The camera will power on automatically.

4.2 Monitor Setup

1. **Placement:** Place the 7-inch LCD monitor in a central indoor location where you can easily view it and access controls.
2. **Connect Power:** Connect the monitor to its power adapter and plug it into a power outlet. The monitor will power on.
3. **Automatic Pairing:** The camera and monitor are factory-matched and should automatically connect upon power-up. The camera's live feed should appear on the monitor. If not, refer to the Troubleshooting section.
4. **Initial Configuration:** Use the monitor's controls to set the date, time, and preferred recording settings (e.g., continuous, motion detection).

4.3 Smartphone Connectivity (Optional)

If your model supports smartphone integration, download the official Stabo app from your device's app store. Follow the in-app instructions to connect your monitor to your home Wi-Fi network and pair it with your smartphone for remote viewing and notifications.

5. OPERATING INSTRUCTIONS

5.1 Live View

Once powered on and paired, the monitor will display the live video feed from the camera. You can typically switch between single-camera view and multi-camera view (if additional cameras are connected) using the monitor's buttons.

5.2 Recording

The integrated recorder allows you to capture video footage. The monitor supports various recording modes:

- **Continuous Recording:** Records constantly.
- **Motion Detection Recording:** Records only when motion is detected by the camera. This saves storage space.
- **Scheduled Recording:** Records during specific times of the day or week.

Refer to the monitor's on-screen menu for detailed settings and to configure your preferred recording mode. Ensure a compatible storage device (e.g., SD card, not included) is inserted into the monitor for recording.

5.3 Playback

To review recorded footage, access the playback menu on the monitor. You can browse recordings by date and time. Use the navigation buttons to play, pause, fast-forward, or rewind footage.

5.4 System Settings

The monitor's menu allows you to adjust various system settings, including:

- Date and Time
- Video Resolution
- Motion Detection Sensitivity
- Alarm Settings

- Storage Management
- Network Settings (for smartphone connectivity)

6. MAINTENANCE

- **Cleaning:** Regularly wipe the camera lens and monitor screen with a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals.
- **Firmware Updates:** Check the Stabo website periodically for firmware updates for your device. Updates can improve performance and add new features.
- **Storage Management:** Regularly back up important recordings and format the storage device (e.g., SD card) on the monitor to ensure optimal recording performance.
- **Power Cycle:** If you experience minor issues, try power cycling the camera and monitor by unplugging them for a few seconds and then plugging them back in.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image on monitor	Camera or monitor not powered on; Camera out of range; Pairing issue.	Check power connections. Move camera closer to monitor. Re-pair camera and monitor (refer to monitor's menu for pairing option).
Poor video quality	Weak wireless signal; Dirty camera lens; Obstructions.	Relocate camera or monitor to improve signal. Clean camera lens. Remove obstructions between camera and monitor.
No recording	No storage device (SD card) inserted; Storage device full; Incorrect recording settings.	Insert a compatible SD card. Format or replace the SD card. Check recording settings in the monitor's menu.
Cannot connect to smartphone app	Monitor not connected to Wi-Fi; Incorrect Wi-Fi password; App issues.	Ensure monitor is connected to your home Wi-Fi. Verify Wi-Fi password. Restart the app and your smartphone.

8. SPECIFICATIONS

Feature	Detail
Model Number	51136
Resolution	2304 x 1296 pixels
Wireless Frequency	2.4 GHz
Monitor	7-inch LCD Color Monitor with Integrated Full HD Recorder
Connectivity Technology	Wi-Fi (Wireless Communication), Wired (Power)
Usage Environment	Camera: Outdoor; Monitor: Indoor

Feature	Detail
Mounting Type	Wall Mount
Power Source	Battery powered (camera, likely for backup/short-term) / AC Adapter (main)
Wattage	3 watts
Dimensions (L x W x H)	9 x 2 x 13 cm (Product); 676 g (Weight)
Included Components	Installation hardware
Compatible Devices	Smartphone

9. WARRANTY AND SUPPORT

Stabo products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Stabo website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Stabo customer service through their official channels.

Online Resources: For additional support and updated information, please visit the official Stabo website:www.stabo.de

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question