

[manuals.plus](#) /› [TOSHIBA](#) /› [Toshiba 7.7QT Air Fryer Instruction Manual - Model AF-74CSROUS\(H\)](#)**TOSHIBA AF-74CSROUS(H)**

Toshiba 7.7QT Air Fryer Instruction Manual

Model: AF-74CSROUS(H)

1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance features intelligent safeguards, automatically pausing when the inner pot is out of place and performing an auto shut-off if the unit ever overheats.
- The non-stick coating is 100% food contact safe.

2. PRODUCT OVERVIEW

The Toshiba 7.7QT Air Fryer is designed for efficient and healthy cooking, utilizing rapid hot air circulation to achieve crispy results with significantly less oil. Its large capacity and smart features make it suitable for family meals and various culinary tasks.

Key Features:

- **Menu-IQ Technology:** Automatically adjusts cooking time based on food quantity for optimal results.
- **12 Preset Menus:** Pre-programmed settings for common dishes, with manual adjustment options.
- **7.7QT Family-Size Capacity:** Accommodates large portions, such as 20 chicken wings or a 9-inch pizza.
- **1°F Accuracy Control:** Maintains consistent cooking temperature for precise results.
- **HEAT-Q Technology:** Powerful motor and heater for rapid hot air circulation, ensuring crispy texture with less oil.

- **Memory Function:** Save preferred temperature and time settings for frequently cooked recipes.

Air Fryer Just Got Smarter



Image: Toshiba 7.7QT Air Fryer in Metal Gray.

3. SETUP

Unpacking:

- Carefully remove the air fryer and all packaging materials from the box.
- Remove any stickers or labels from the appliance.

Initial Cleaning:

- Before first use, wipe the exterior of the air fryer with a damp cloth.
- Wash the removable basket and crisper plate with warm, soapy water. Rinse thoroughly and dry completely.
- Do not use abrasive cleaning materials.

Placement:

- Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.
- Ensure the power cord is not pinched or hanging over the edge of a counter.

5 Smart Menu Functions

5 MENU-IQ Smart Functions: French Fries, Fish, Chicken Wings, Thighs, Shrimp



Image: Detachable basket and crisper plate.

4. OPERATING INSTRUCTIONS

Control Panel:

The air fryer features an intuitive control panel with a central dial and touch buttons for various functions.

DESIGN STATEMENT

We design products that are genuine, innovative, and specially engineered to our brand design philosophy: Integrity, Innovation & Inclusion.



Image: Control panel with various cooking modes and Menu-IQ presets.

Getting Started:

1. Plug the air fryer into a grounded electrical outlet.
2. Place food in the crisper plate within the basket. Do not overfill.
3. Slide the basket firmly back into the air fryer until it clicks into place.

Using Preset Menus (Menu-IQ & 12 Presets):

- Turn the central dial to select one of the 12 preset cooking functions (e.g., Air Fry, Roast, Bake, Dehydrate, French Fries, Chicken Wings, Fish, Shrimp).
- For Menu-IQ programs, the air fryer will automatically adjust cooking time based on the quantity of food.
- Press the Start/Pause button to begin cooking.

Manual Operation:

- To manually set temperature, press the 'TEMP' button and turn the dial to adjust the temperature (1°F precision).
- To manually set time, press the 'TIME' button and turn the dial to adjust the cooking duration.
- Press the Start/Pause button to begin cooking.

Preheating:

- Some recipes may require preheating. Select the desired temperature and time, then press the 'Preheat' button (if available) or allow the unit to run empty for a few minutes before adding food.

Shaking/Turning Food:

- For even cooking, especially with smaller items like fries or wings, the air fryer may prompt you to 'TURN' or 'SHAKE' the basket. Carefully remove the basket, shake or turn the food, and reinsert the basket to resume cooking.

Memory Function:

- To save a custom setting, press the '♡' button after setting your desired temperature and time. The air fryer will store this setting for future use.

Your browser does not support the video tag.

Video: Official Toshiba demonstration of the 7.7QT Air Fryer's features and operation.

5. CLEANING AND MAINTENANCE

Cleaning the Basket and Crisper Plate:

- After each use, unplug the air fryer and allow it to cool completely.
- Remove the basket and crisper plate. While the product specifications indicate it is dishwasher safe, handwashing with warm, soapy water is recommended to prolong the life of the non-stick coating.
- Use a non-abrasive sponge or cloth to clean. For stubborn food residue, soak the basket and plate in warm, soapy water for 10-15 minutes before cleaning.

Cleaning the Main Unit:

- Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Clean the interior cavity with a damp cloth and mild detergent if necessary. Ensure no water enters the heating element area.

Storage:

- Ensure all parts are clean and dry before storing.
- Store the air fryer in a cool, dry place.

6. TROUBLESHOOTING

If you encounter any issues with your Toshiba Air Fryer, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet malfunction; Basket not fully inserted.	Check power cord connection; Test outlet with another appliance; Ensure basket is securely closed.
Food not cooked evenly	Basket overcrowded; Food not shaken/turned.	Cook in smaller batches; Shake or turn food halfway through cooking.
White smoke from appliance	Grease residue from previous use; Fatty ingredients.	Clean basket and crisper plate thoroughly; Remove excess fat from food.
Food not crispy	Not enough oil (if desired); Temperature too low; Cooking time too short.	Lightly spray food with oil; Increase temperature or cooking time.

For further assistance, please contact customer support as indicated in the Warranty and Support section.

7. SPECIFICATIONS

Feature	Specification
Model Number	AF-74CSROUS(H)
Capacity	7.7 Quarts
Product Dimensions	13.85"D x 13.54"W x 16.18"H
Item Weight	12.3 Pounds
Color	Metal Gray
Material	Metal, Stainless Steel, Polypropylene
Output Wattage	1700 Watts
Voltage	120 Volts
Control Method	Touch
Min Temperature Setting	1 Degrees Fahrenheit
Air Frying Technology	Rapid Air Circulation
Has Nonstick Coating	Yes
Is Dishwasher Safe (Removable Parts)	Yes (Handwashing recommended for longevity)

8. WARRANTY AND SUPPORT

Warranty Information:

Your Toshiba 7.7QT Air Fryer comes with a **1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Customer Support:

For any questions, technical assistance, or warranty claims, please refer to the customer service information provided with your product packaging or visit the official Toshiba support website.