

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SALENTE](#) /

› [Salente AirFit 3.5L 1500W Air Fryer Instruction Manual](#)

## SALENTE AirFit

# Salente AirFit 3.5L 1500W Air Fryer Instruction Manual

Model: AirFit | Brand: SALENTE

## 1. INTRODUCTION

Thank you for choosing the Salente AirFit Air Fryer. This appliance is designed to provide a healthy and efficient way to prepare a variety of meals, combining baking, grilling, drying, and defrosting functions. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

## 2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- The appliance features a CoolTouch handle and is thermally insulated for safe operation.

### 3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Salente AirFit Air Fryer.



**Figure 3.1:** Front view of the Salente AirFit Air Fryer, showcasing its sleek black design and control panel.



**Figure 3.2:** The air fryer with its cooking drawer slightly pulled out, revealing the handle and part of the interior.



**Figure 3.3:** A top-down view of the open cooking basket, showing the non-stick surface and perforated design for air circulation.



**Figure 3.4:** Rear view of the air fryer, highlighting the ventilation outlets and power cord connection.



**Figure 3.5:** Close-up of the digital touch control panel, displaying temperature, time, and various preset program icons.

## 4. SETUP AND FIRST USE

- Unpacking:** Carefully remove the air fryer and all packaging materials. Keep packaging for future storage or disposal.
- Cleaning:** Before first use, clean the cooking basket and grill plate with warm soapy water. Wipe the exterior of the appliance with a damp cloth. Ensure all parts are completely dry before assembly.
- Placement:** Place the air fryer on a stable, heat-resistant, and level surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm of free space around the appliance.
- Power Connection:** Plug the power cord into a grounded wall outlet.
- Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 180°C to burn off any manufacturing residues. A slight odor may be present, which is normal.

## 5. OPERATING INSTRUCTIONS

The Salente AirFit Air Fryer offers both preset programs and manual control for versatile cooking.

### 5.1. General Operation

- Pull out the cooking drawer by the CoolTouch handle.
- Place food items into the cooking basket. Do not overfill.
- Slide the cooking drawer back into the appliance until it clicks into place.
- Press the power button to turn on the display.

### 5.2. Using Preset Programs

The air fryer features 12 preset programs for common dishes. These programs automatically set the recommended time and temperature.



**Figure 5.1:** The control panel displaying the 12 preset program icons, each representing a different food type or cooking function.

- After turning on the appliance, select the desired preset program by tapping its icon on the touch panel.
- The display will show the default time and temperature for that program.
- You can adjust the time and temperature manually even after selecting a preset program using the temperature and

time adjustment buttons.

4. Press the start/pause button to begin cooking.

### 5.3. Manual Mode

For custom cooking, you can set the temperature and time manually.

1. After turning on the appliance, use the temperature adjustment buttons (up/down arrows) to set the desired temperature between 30°C and 200°C in 1°C increments.
2. Use the time adjustment buttons (up/down arrows) to set the desired cooking time between 1 and 60 minutes in 1-minute increments.
3. Press the start/pause button to begin cooking.

### 5.4. During Cooking

- The RapidAir technology ensures even heating, often eliminating the need to turn food. However, for some items, shaking or turning halfway through cooking may improve results.
- You can pull out the cooking drawer at any time to check or shake food. The appliance will automatically pause and resume once the drawer is reinserted.
- The air fryer will automatically shut off when the timer reaches zero.

## 6. CLEANING AND MAINTENANCE

---

Regular cleaning ensures the longevity and hygiene of your air fryer.

1. **Before Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Cooking Basket and Grill Plate:** The non-stick cooking basket and grill plate are dishwasher safe. Alternatively, they can be washed by hand with warm soapy water and a non-abrasive sponge. Ensure all food residues are removed.
3. **Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers.
4. **Interior:** If necessary, wipe the interior of the appliance with a damp cloth. Avoid getting water into the electrical components.
5. **Storage:** Store the cleaned and dry air fryer in a cool, dry place.

## 7. TROUBLESHOOTING

---

If you encounter issues with your air fryer, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overfilled. Temperature or time settings are incorrect.	Do not overfill the basket. Ensure food is in a single layer. Adjust temperature and time as needed. Shake or turn food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use. Fatty foods being cooked.	Clean the basket and grill plate thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the drawer to prevent smoke.

Problem	Possible Cause	Solution
Appliance emits a burning smell.	Food particles stuck in the heating element.	Unplug the appliance and allow it to cool. Carefully clean the interior and heating element area.

## 8. TECHNICAL SPECIFICATIONS

<b>Brand</b>	SALENTE
<b>Model</b>	AirFit
<b>Capacity</b>	3.5 Liters
<b>Power</b>	1500 Watts
<b>Temperature Range</b>	30°C - 200°C
<b>Timer Range</b>	1 - 60 minutes
<b>Dimensions (L x W x H)</b>	33.7 x 25.2 x 31.8 cm
<b>Weight</b>	3.97 Kilograms
<b>Material</b>	Metal Stainless Steel
<b>Special Features</b>	Automatic shut-off, Timer, Dishwasher safe parts

## 9. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is typically provided with your purchase documentation or on the manufacturer's official website. Please refer to those resources for details on warranty coverage, service, and contact information for technical assistance.

No official product videos are available for embedding at this time.